Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

OttLite CSP9300C-SHPR

OttLite ClearSun Flex LED Floor Lamp User Manual

Model: CSP9300C-SHPR

Introduction

The OttLite Flex Floor Lamp, featuring ClearSun LED Technology, is designed to provide optimal illumination for various tasks such as reading, crafting, and general lighting. This lamp aims to reduce eyestrain by matching the spectrum of natural sunlight, ensuring clear detail visibility and accurate color representation. Its flexible neck and touch-activated controls offer versatile positioning and adjustable brightness.



Image: The OttLite ClearSun Flex LED Floor Lamp in white, showcasing its sleek design and flexible neck.

What's in the Box

- OttLite ClearSun Flex LED Floor Lamp (main assembly)
- Power Cable



Image: A diagram illustrating the flexible neck and weighted base of the OttLite lamp, highlighting its stability and adjustability.

Setup Instructions

1. **Unpack Components:** Carefully remove all components from the packaging. Ensure all parts listed in "What's in the Box" are present.
2. **Assemble Lamp Pole:** Connect the pole sections by screwing them together clockwise until secure. The flexible neck section should be at the top.
3. **Attach Base:** Securely attach the assembled pole to the lamp base by screwing it clockwise. Ensure it is stable and upright.
4. **Connect Power:** Insert the power cable into the designated port on the lamp base. Plug the other end of the power cable into a standard electrical outlet.






Image: A close-up of the lamp's base, indicating its dimensions (8"W x 10.3"D) for placement reference.

Operating Instructions

- **Power On/Off:** The lamp features touch-activated controls. Gently touch the power icon on the lamp pole to turn the lamp on or off.
- **Adjust Brightness:** To cycle through the three available brightness levels, repeatedly touch the power icon. The lamp will adjust from low to medium to high brightness.
- **Smart Memory Feature:** The lamp is equipped with a smart memory feature that remembers your last brightness

setting. When you turn the lamp back on, it will resume the previously selected brightness level.

- **Adjust Flexible Neck:** The rubberized flexible neck allows for precise light positioning. Gently bend and adjust the neck to direct the light exactly where needed. The height of the lamp can be adjusted from 49 to 71 inches.



Image: The OttLite lamp positioned next to a sewing machine, demonstrating its adjustable height range from 49 to 71 inches, suitable for various activities.

Maintenance

- **Cleaning:** To clean the lamp, ensure it is unplugged from the power outlet. Use a soft, dry cloth to wipe down the surfaces. Do not use abrasive cleaners or solvents, as they may damage the finish.
- **LED Longevity:** The integrated LED light source is designed for long-term use and does not require bulb replacement.
- **Storage:** If storing the lamp, ensure it is clean and dry. Store in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution
Lamp does not turn on.	Not plugged in, power outlet issue, or power cable not fully inserted.	Ensure the power cable is securely plugged into both the lamp and a working electrical outlet. Test the outlet with another device.
Brightness levels do not change.	Incorrect operation of touch controls.	Ensure you are gently tapping the touch-sensitive power icon to cycle through brightness settings.
Lamp is unstable.	Pole sections or base not securely assembled.	Check that all pole sections are screwed together tightly and the base is firmly attached to the pole.

If the problem persists after attempting these solutions, please contact OttLite customer support for further assistance.

Specifications

Feature	Detail
Brand	OttLite
Model Number	CSP9300C-SHPR
Lamp Type	Floor Lamp
Light Source Type	LED (ClearSun Technology)
Wattage	13 watts
Product Dimensions (D x W x H)	10.31"D x 8"W x 49"H (adjustable up to 71"H)
Base Material	Plastic
Shade Material	Plastic
Switch Type	Touch
Special Features	Energy Efficient, Adjustable Color Temperature, Flexible, Dimmable, Adjustable Height, Smart Memory Feature
Power Source	Corded Electric

Warranty and Support

This OttLite product is covered by the manufacturer's warranty. For specific warranty details, registration, or technical support, please refer to the documentation included with your product or visit the official OttLite website.
You can also visit the OttLite Store on Amazon for more information and product resources.

© 2024 OttLite. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D2Y7VKNR

More documents and user manuals: **https://manuals.plus/**