



Manuals.plus /

- › KEEBMONKEY /
- › KEEBMONKEY WOBKEY Rainy 75 Mechanical Keyboard User Manual

KEEBMONKEY Pro Noir

KEEBMONKEY WOBKEY Rainy 75 Mechanical Keyboard User Manual

Model: Pro Noir | Brand: KEEBMONKEY

1. SAFETY INFORMATION

Please read all instructions carefully before using the KEEBMONKEY WOBKEY Rainy 75 Mechanical Keyboard. Keep this manual for future reference. Avoid exposing the keyboard to extreme temperatures, humidity, or direct sunlight. Do not attempt to disassemble or modify the keyboard, as this will void the warranty and may cause damage. Use only the provided USB cable for charging and wired connection. Keep out of reach of small children.

2. PACKAGE CONTENTS

Ensure all items are present in the package:

- KEEBMONKEY WOBKEY Rainy 75 Mechanical Keyboard (Pro - Black)
- USB Cable
- 2.4GHz Receiver
- 3 Spare Cocoa Switches
- Switch Puller
- Type-C Cable



Image: Package contents for Rainy 75 Pro and Lite/Standard versions. The Pro version includes the keyboard, manual, 2.4GHz receiver, 3 spare Cocoa switches, switch puller, and Type-C cable.

3. SETUP

3.1 Initial Charging

Before first use, connect the keyboard to a USB power source using the provided Type-C cable. The keyboard features a 7000mAh high-capacity battery (Pro version) for extended use. A full charge is recommended for optimal performance.



Image: The keyboard features a 7000mAh high-capacity battery, providing up to 900 hours of battery life without RGB lighting.

3.2 Connectivity Modes

The Rainy 75 keyboard supports three connectivity modes: Wired (USB-C), Bluetooth 5.0 (BT), and 2.4G Wireless.

- 1. Wired Mode:** Connect the keyboard directly to your device using the USB Type-C cable. This mode offers the lowest latency (2ms).
- 2. 2.4G Wireless Mode:** Insert the 2.4GHz receiver into a USB port on your device. The keyboard will automatically connect. This mode provides low latency (3ms) suitable for gaming.
- 3. Bluetooth Mode:** Turn on Bluetooth on your device. On the keyboard, switch to Bluetooth mode (refer to operating instructions for specific key combinations). Search for "Rainy 75" in your device's Bluetooth settings and pair. Latency in this mode is 7ms.

Gasket Structure



PP Lite Series/Standard Series



FR4 Pro Series



SUS304 Support Structure
 CNC Bottom Housing
 Steel/Glass Weight
 3500/7000mAh Battery
 PET Insulation Pad
 EPDM Dampening Pad
 14 PCB-Gaskets
 PET Noise Cancellation Pad
 1.2mm PCB with Flex Cuts
 8x Foaming Bottom Foam
 PP/FR4 Plate with Flex Cuts
 POPON Foam
 KAILI/HMX Switches
 Double Shot PBT Keycaps
 CNC Housing




Image: Tri-Mode Connectivity options including Bluetooth, 2.4G wireless, and USB Type-C for versatile use across devices.


4. OPERATING INSTRUCTIONS

4.1 Basic Functions

The Rainy 75 features an 81-key layout. Standard key functions operate as expected. For specific multimedia or function key operations, refer to the keycap legends or the VIA programming section.

4.2 RGB Lighting Control

The keyboard supports vibrant RGB lighting with multiple effects. Use the designated function key combinations (Fn + keys) to cycle through lighting modes, adjust brightness, and change colors. Detailed lighting controls can also be customized via the VIA software.



Switch Type:
Factory Lubed

Operating Force:
45gF(±5g)

Pre-Travel:
2.0mm(±0.4mm)

Total Travel:
3.6mm(±0.5mm)

Stem:
POM MX Cream

Factory Lubed:
Yes

Image: Dynamic, customizable RGB lighting with multiple effects enhances your setup, delivering an immersive and visually stunning experience.

4.3 VIA Programmable Features

The Rainy 75 is fully VIA programmable, allowing you to remap keys, create macros, and fine-tune lighting settings. Download the VIA software from the official WOBKEY website for seamless integration and advanced customization.




Image: VIA Programmable interface allows users to easily remap keys, create macros, and fine-tune lighting with seamless integration.

4.4 Hot-Swappable Switches

The keyboard features hot-swappable sockets, allowing you to easily change switches without soldering. This enables effortless customization of your typing experience. The Pro version comes with pre-lubricated Cocoa switches.



Image: The keyboard supports 3/5 pin switches and features pre-lubed switches and stabilizers for easy customization.

4.5 Acoustic Design

The Rainy 75 Pro model incorporates a CNC aluminum gasket mount design with five-layer foam and 14 dampening buds, along with FR4 plates with flex cuts, to provide superior acoustics and a pleasing sound feedback during typing.



Image: Exploded view illustrating the CNC Aluminum Gasket Mount structure with multiple layers for sound absorption and enhanced durability.

4.6 Product Overview Video

Your browser does not support the video tag.

Video: An official product video showcasing the KEEBMONKEY WOBKEY Rainy 75 Aluminum Mechanical Keyboard with HMX/JWK Switches and superior acoustics. This video highlights key features and design elements.

5. MAINTENANCE

5.1 Cleaning

- Use a soft, dry cloth to wipe down the keyboard surface regularly.
- For deeper cleaning, remove keycaps using the provided keycap puller. Use compressed air to clear debris from between switches.
- Wipe keycaps with a damp cloth and mild soap solution if necessary, ensuring they are completely dry before reattaching.

5.2 Storage

Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods. If storing for a long time, ensure the battery is charged to about 50% to prolong its lifespan.

6. TROUBLESHOOTING

6.1 Connectivity Issues

- **Keyboard not responding:** Ensure the keyboard is charged. Check the connection mode (wired, 2.4G, BT) and ensure it matches your device's connection.
- **2.4G Wireless not connecting:** Ensure the 2.4GHz receiver is securely plugged into a USB port. Try a different USB port.
- **Bluetooth pairing issues:** Ensure Bluetooth is enabled on your device and the keyboard is in Bluetooth pairing mode. Remove previous pairings and try re-pairing.

6.2 Key Functionality

- **Keys not registering:** Check if the switch is properly seated. If not, carefully remove and re-insert the switch using the switch puller.
- **Incorrect key output:** Verify VIA software settings if you have customized keymaps. Reset to default settings if necessary.

6.3 RGB Lighting

- **RGB not working:** Ensure RGB lighting is enabled via function keys or VIA software. Check brightness settings.

For further assistance, please visit the official KEEBMONKEY support page or contact customer service.

7. SPECIFICATIONS

Feature	Detail
Product Dimensions	12.6"L x 5.12"W x 1.57"H
Item Weight	4.4 pounds
Manufacturer	KEEBMONKEY
Item Model Number	Pro Noir
Batteries	1 Lithium Ion batteries required (included)
Brand	KEEBMONKEY
Compatible Devices	PC
Connectivity Technology	USB-C, Bluetooth 5.0, 2.4G Wireless
Keyboard Description	Gaming
Recommended Uses	Gaming
Special Feature	Ergonomic
Number of Keys	81
Keyboard Backlighting	RGB
Style	Pro - Black



Image: Comparison table detailing features across Lite, Standard, and Pro versions, including RGB, switch type, battery capacity, weight, plate material, and price.

8. WARRANTY AND SUPPORT

KEEBMONKEY products are designed for quality and durability. For information regarding product warranty, please refer to the warranty card included in your package or visit the official KEEBMONKEY website. For technical support, FAQs, or to purchase accessories, please visit the KEEBMONKEY Store on Amazon or their official support channels.