

## Ayybboo 2206

# Ayybboo Kids Digital Watch

INSTRUCTION MANUAL - MODEL 2206

## 1. Introduction

Thank you for choosing the Ayybboo Kids Digital Watch. This watch is designed for children aged 5-13, featuring a cute cat-themed design, 7-color lights, alarm, stopwatch, and 30M water resistance. This manual provides detailed instructions to help you and your child get the most out of this versatile timepiece.



Image 1.1: Front view of the Ayybboo Kids Digital Watch, highlighting its digital display and water resistance.

## 2. Setup

Your Ayybboo Kids Digital Watch comes with a pre-installed Lithium Metal battery. Follow these steps to set the time and date:

1. In normal time display mode, press the **MODE** button three times to enter time setting mode. The seconds will flash.

2. Press the **RESET** button to cycle through seconds, hours, minutes, month, date, and day of the week settings.
3. Use the **START** button to adjust the flashing value.
4. Once all settings are complete, press the **MODE** button to return to normal time display mode.

Your browser does not support the video tag.

Video 2.1: A demonstration on how to set the time and date on the Ayybboo Kids Digital Watch.

### 3. Operating Functions

The Ayybboo Kids Digital Watch offers several useful functions:

- **Time Display:** Shows hours, minutes, seconds, and day of the week.
- **Alarm:** Set a daily alarm to remind your child of important times.
- **Stopwatch:** A simple stopwatch function for timing activities.
- **7-Color Lights:** Illuminate the display with various colors for easy viewing in the dark and added fun.
- **12/24H Format:** Switch between 12-hour (AM/PM) and 24-hour time formats.



Image 3.1: Overview of the watch's multifunctional capabilities.

#### 3.1 Setting the Alarm

To set or turn off the alarm:

1. In normal time display mode, press the **MODE** button twice to enter alarm setting mode. The hour digits will flash.
2. Use the **START** button to adjust the hour.
3. Press the **RESET** button to switch to minute setting, then use **START** to adjust minutes.
4. To turn the alarm ON/OFF, press and hold the **RESET** button, then press the **START** button. An alarm icon will appear/disappear on the display.
5. Press **MODE** to exit alarm setting.

Your browser does not support the video tag.

Video 3.2: Instructions on how to set and activate the alarm function.

### 3.2 Using the 7-Color Lights

The watch features attractive 7-color lights. To activate and cycle through the colors:

- Press the **LIGHT** button (top left) to illuminate the display.
- Each press of the **LIGHT** button will cycle through the different colors.

Your browser does not support the video tag.

Video 3.3: A guide on how to operate the 7-color light feature of the watch.

### 3.3 Switching 12/24 Hour Format

To change the time display format:

- In normal time display mode, press the **RESET** button to toggle between 12-hour (with AM/PM indicator) and 24-hour formats.

Your browser does not support the video tag.

Video 3.4: Instructions for switching between 12-hour and 24-hour time formats.

## 4. Maintenance

Proper care will ensure the longevity of your Ayybboo Kids Digital Watch.

### 4.1 Water Resistance

The watch is rated for 30 meters (3 ATM) water resistance. This means it is suitable for daily use, such as hand washing, face washing, and splashes from rain. However, due to the functional buttons, it is not fully enclosed. Avoid prolonged immersion in water, hot water, or operating buttons underwater. It is not suitable for swimming, diving, or showering.



Image 4.1: The watch's 30M water resistance is suitable for everyday activities.

Your browser does not support the video tag.

Video 4.2: A demonstration of the Ayybboo Kids Digital Watch's waterproof capabilities.

## 4.2 Cleaning

Wipe the watch clean with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by drying thoroughly.

## 4.3 Battery Information

The watch uses 1 Lithium Metal battery (included). Battery replacement should be performed by a qualified technician to maintain water resistance.

## 5. Troubleshooting

If you encounter any issues with your watch, please refer to the following common problems and solutions:

- **Display is blank or dim:** The battery may be low. Consider professional battery replacement.
- **Buttons are unresponsive:** Ensure the watch is not in a locked mode (if applicable, though this model does not have a specific lock). Try pressing the **RESET** button to see if it restores functionality.
- **Time is incorrect:** Re-follow the time setting instructions in Section 2.
- **Alarm not sounding:** Verify that the alarm is set correctly and the alarm icon is displayed on the screen (refer to Video 3.2).
- **Water damage:** While the watch is water-resistant, prolonged immersion or button operation underwater can cause damage. If water enters the watch, stop using it immediately and contact customer support.

For further assistance, please contact Ayybboo customer service.

## 6. Specifications



Image 6.1: Detailed dimensions of the Ayybboo Kids Digital Watch.

Feature	Detail
Model Number	2206

Feature	Detail
Brand	Ayybboo
Department	Unisex-child
Clasp Type	Buckle
Water Resistance	30M (3 ATM)
Battery Type	1 Lithium Metal (included)
Wrist Fit Range	14.3 cm (5.6 inches) - 19.5 cm (7.67 inches)
Product Weight	0.64 ounces (approx. 18g)
Country of Origin	China

## 7. Warranty and Support

Ayybboo is committed to providing quality products and excellent customer service. Your Ayybboo Kids Digital Watch comes with the following support:

- **30-Day Returns:** Hassle-free returns within 30 days of purchase.
- **90-Day Free Replacement Service:** Enjoy a free replacement for any manufacturing defects within 90 days.
- **12-Months Replacement:** We promise a 12-month replacement for product issues.
- **Lifetime Repair Service:** Ayybboo offers lifetime repair service for your watch.
- **24-Hour Service:** Dedicated customer support available to assist you.

For any inquiries, support, or service requests, please contact us at:

**Email:** [ayybbooservice@outlook.com](mailto:ayybbooservice@outlook.com)

*We appreciate your business and are here to help!*