



Manuals.plus /

› ehozirta /

› ehozirta 3-in-1 Electric Weed Burner Instruction Manual, Model 6630A6630A857549B1

**ehozirta 6630A6630A857549B1**

# ehozirta 3-in-1 Electric Weed Burner Instruction Manual

Model: 6630A6630A857549B1

---

## 1. INTRODUCTION

---

This manual provides essential information for the safe and effective use of your ehozirta 3-in-1 Electric Weed Burner. This versatile tool is designed for various applications including weed control, roofing tasks, and melting ice. Please read this manual thoroughly before operating the device and retain it for future reference.

The electric weed burner features a 1500W heating element capable of reaching temperatures up to 650°C, facilitating efficient weed destruction by disrupting plant cell structures. It offers adjustable flame temperature settings from 80°C to 650°C to suit different operational requirements. Constructed from durable aluminum and ABS materials, the device is designed for longevity and reliable performance.

## 2. IMPORTANT SAFETY INSTRUCTIONS

---

**WARNING: Read all safety warnings and instructions. Failure to follow the warnings and instructions may result in electric shock, fire, and/or serious injury.**

- **Electrical Safety:** Ensure the power supply matches the voltage specified on the tool. Do not operate in wet conditions or near flammable liquids/gases. Always use a grounded outlet.
- **Personal Safety:** Wear appropriate personal protective equipment (PPE) including heat-resistant gloves, eye protection, and long sleeves. Keep children and bystanders away during operation.
- **Heat Hazard:** The nozzle and surrounding areas become extremely hot during use and remain hot for a period after shutdown. Avoid contact with skin and flammable materials. Allow the tool to cool completely before storing.
- **Fire Hazard:** Do not use near dry vegetation, wood, or other combustible materials without extreme caution. Always have a fire extinguisher or water source nearby when operating.
- **Proper Use:** Use the tool only for its intended purpose. Do not modify the device or use unauthorized attachments.
- **Storage:** Store the tool in a dry, secure place out of reach of children when not in use.

### 3. PACKAGE CONTENTS

Verify that all items are present and undamaged upon opening the package. If any items are missing or damaged, contact customer support.

- Electric Weed Burner Main Unit
- Extension Handle
- Various Nozzles (e.g., weed burning nozzle, paint stripping nozzle, igniter nozzle)
- Instruction Manual



Figure 3.1: Main unit and included nozzles.

### 4. PRODUCT OVERVIEW

Familiarize yourself with the components of your electric weed burner before assembly and operation.



Figure 4.1: Exploded view and key components of the electric weed burner.

- **Main Unit:** Contains the heating element and motor.
- **Extension Handle:** For extended reach and ergonomic operation.
- **Non-slip Handle:** Provides a secure grip.
- **Power Cable:** Connects to an electrical outlet.
- **Fire Power Gear (Temperature Switch):** Adjusts the heat output (e.g., 1st gear for lower temperature, 2nd gear for higher temperature).
- **Multifunctional Air Outlet:** The area where nozzles attach and heat is expelled.

## 5. SETUP AND ASSEMBLY

Follow these steps to assemble your electric weed burner:

1. **Connect the Extension Handle:** Align the main unit with the extension handle. Insert the two parts firmly until

they click into place. Ensure the connection is secure.

2. **Attach the Desired Nozzle:** Select the appropriate nozzle for your task (e.g., weed burning, paint stripping). Twist or push the nozzle onto the multifunctional air outlet until it is securely fastened.
3. **Secure the Power Cable:** If applicable, use the wire cord buckle to manage the power cable along the extension handle for tidy and safe operation.



Figure 5.1: Assembly steps for the electric weed burner.

## 6. OPERATING INSTRUCTIONS

Before operating, ensure the device is properly assembled and all safety precautions are observed.

### 6.1 Powering On and Temperature Adjustment

1. **Plug In:** Connect the power cable to a suitable grounded electrical outlet.
2. **Select Temperature:** Use the 'Fire Power Gear' switch (often labeled 1st Gear/2nd Gear or similar) to select the desired temperature setting.
  - **1st Gear:** Approximately 80°C (for lower heat applications).

- **2nd Gear:** Approximately 650°C (for high heat applications like weed burning).

3. **Activate:** Press the paddle button or trigger to start the heating process. Allow a few seconds for the device to reach the selected temperature.



Figure 6.1: Temperature adjustment switch and heat output.

## 6.2 Applications

The ehozirta 3-in-1 Electric Weed Burner can be used for various tasks:

- **Weed Control:** Direct the hot air stream onto weeds for a few seconds until the plant cells are visibly damaged (e.g., leaves wilt or change color). This method does not burn the weed to ash but rather causes it to die off.
- **Lighting Braziers/BBQs:** Use the igniter nozzle to quickly and safely light charcoal or wood.
- **Paint Stripping:** Apply heat to painted surfaces to soften the paint, then scrape it off. Use the appropriate nozzle for this task.
- **Melting Ice:** Direct the heat onto ice to melt it, useful for pathways or frozen pipes.
- **Roofing:** Can be used for specific roofing applications requiring heat, such as softening bitumen.



Figure 6.2: Examples of product applications.

# ONKRUID BESTRIJDEN ZONDER TE BUKKEN



Figure 6.3: Operating the weed burner for garden maintenance.

## 6.3 Shutting Down

To turn off the device, release the paddle button/trigger and unplug the power cable from the outlet. Allow the unit to cool down completely before handling or storing.

## 7. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your electric weed burner.

- **Cleaning:** After each use, ensure the device is unplugged and completely cool. Wipe the exterior with a damp cloth. Do not use abrasive cleaners or immerse the unit in water.
- **Nozzle Care:** Clean any debris from the nozzles. Ensure they are free from blockages to maintain proper airflow.
- **Storage:** Store the unit in a dry, clean, and secure location. Keep the power cord neatly coiled to prevent damage.
- **Inspection:** Periodically inspect the power cord for any signs of damage (cuts, fraying). If damage is found,

discontinue use and contact customer support for repair.

## 8. TROUBLESHOOTING

If you encounter issues with your electric weed burner, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Device does not turn on.	No power supply; faulty power cord; internal malfunction.	Check power outlet and cord. Ensure the device is properly plugged in. If issues persist, contact customer support.
Low heat output.	Incorrect temperature setting; blocked air outlet.	Ensure the 'Fire Power Gear' is set to the higher temperature (2nd Gear). Check nozzles and air outlet for obstructions and clean if necessary.
Overheating/Shuts off automatically.	Blocked air vents; prolonged continuous use.	Unplug the device and allow it to cool down. Clear any obstructions from the air vents. Avoid continuous operation for excessively long periods.

For problems not listed here or if solutions do not resolve the issue, please contact ehozirta customer support.

## 9. SPECIFICATIONS

Feature	Detail
Model Number	6630A6630A857549B1
Power	1500W
Temperature Range	80°C to 650°C (Adjustable)
Airflow	500 L/min (typical for high setting)
Power Source	Corded Electric (US Plug)
Material	Aluminum, ABS
Item Weight	3.02 pounds (approx. 1368 grams)
Extended Length	Approximately 35.43 inches (90 cm)

## 10. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or visit the official ehozirta website. If you require technical assistance, have questions about product operation, or need to report a defect, please contact ehozirta customer support through their official channels.

**Online Support:** Visit the ehozirta brand store on Amazon or their official website for FAQs and contact information.

