Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl 12V 2A AC-DC Adapter

onerbl 12V 2A AC-DC Adapter User Manual

Replacement Power Supply for Slabway LM-FYCST501G Heated Leg Foot Massager Pump

1. Introduction

This manual provides essential information for the safe and effective use of your onerbl 12V 2A AC-DC Adapter. This adapter is designed as a replacement power supply for devices requiring a 12V DC, 2A power input, such as the Slabway LM-FYCST501G Heated Leg Foot Massager Pump. Please read these instructions carefully before use and retain them for future reference.



Image 1.1: Front and side view of the onerbl 12V 2A AC-DC Adapter. The adapter is black with a standard US two-prong plug and a barrel connector cable.

2. Safety Information

- **Compatibility:** Only use this adapter with devices that specify a 12V DC input and a current draw of 2A or less. Using it with incompatible devices may cause damage or fire.
- **Indoor Use Only:** This adapter is designed for indoor use in dry locations. Do not expose it to water, moisture, or high humidity.
- **Ventilation:** Ensure adequate ventilation around the adapter during use. Do not cover it or place it in an enclosed space where heat can build up.
- **Cable Care:** Do not bend, twist, or pull the power cord excessively. Avoid placing heavy objects on the cord.
- **Disconnection:** Always unplug the adapter from the wall outlet before cleaning or if it will not be used for an extended period.

- **Damage:** Do not use the adapter if the casing, cord, or plug is damaged. Contact customer support for a replacement.
- **Children:** Keep the adapter out of reach of children.

3. Package Contents

Your package should contain the following item:

- 1 x onerbl 12V 2A AC-DC Adapter with Barrel Connector

4. Setup

Follow these steps to set up your AC-DC adapter:

1. **Verify Compatibility:** Confirm that your device requires a 12V DC input and draws no more than 2 Amps (2000mA). Check your device's original adapter or specifications label.
2. **Connect to Device:** Insert the barrel connector end of the adapter cable firmly into the DC input port of your device.
3. **Connect to Power Outlet:** Plug the AC prongs of the adapter into a standard 100-240V AC wall outlet. Ensure the outlet is easily accessible.



Image 4.1: The onerbl AC-DC adapter connected to a device, illustrating a typical setup on a desk.

5. Operating Instructions

Once properly connected, the adapter will supply power to your device. There are no additional operating controls on the adapter itself. The device connected to the adapter will control its own power functions.

- To power on your device, use the device's power button or controls.
- To power off your device, use the device's power button or controls.
- To disconnect power completely, unplug the adapter from the wall outlet.

6. Specifications

Feature	Specification

Feature	Specification
Input Voltage	100-240V AC, 50/60Hz, 0.3A
Output Voltage	12V DC
Output Current	2 Amps (2000mA)
Output Wattage	24W
Connector Type	Barrel Connector
Color	Black
Cable Length	76 inches (approx. 1.93 meters)
Dimensions (Adapter Body)	2.6 in x 1.6 in x 1.2 in (approx. 6.6 cm x 4.1 cm x 3.0 cm)
Protections	Over Voltage Protection, Over Heat Protection




Image 6.1: Dimensions of the onerbl AC-DC Adapter and its cable length.

7. Troubleshooting

- **No Power to Device:**
  - Ensure the adapter is fully plugged into a working wall outlet.
  - Verify the barrel connector is securely inserted into your device's power port.
  - Check if the device's power switch is in the 'ON' position.
  - Confirm that your device's power requirements match the adapter's output (12V DC, 2A).
  - Test the wall outlet with another appliance to ensure it is functional.
- **Adapter Feels Warm:**
  - It is normal for the adapter to feel slightly warm during operation.
  - If it becomes excessively hot, unplug it immediately. Ensure it is not covered and has adequate ventilation.

8. Maintenance

- **Cleaning:** Disconnect the adapter from the power outlet and the device before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or aerosols.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly winding the cable.

9. Warranty and Support

For warranty information or technical support, please refer to the retailer or manufacturer's website where you purchased this product. Keep your purchase receipt as proof of purchase.

© 2024 onerbl. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D31FQLFM

More documents and user manuals: **https://manuals.plus/**