

[Manuals.plus](#) /

› [wisekoti](#) /

› P11 Premium Space Gray Automatic Foaming Hand Soap Dispenser Touchless, Rechargeable Hand Foam Soap Dispenser for Bathroom and Kitchen

wisekoti P11

P11 Premium Space Gray Automatic Foaming Hand Soap Dispenser User Manual

Model: P11 | Brand: wisekoti

1. INTRODUCTION

The wisekoti P11 Premium Space Gray Automatic Foaming Hand Soap Dispenser is designed to provide a hygienic and convenient handwashing experience. Featuring advanced miniature diaphragm pump technology, this touchless dispenser delivers high-quality dense foam in just 0.25 seconds. Its sleek design and rechargeable battery make it a perfect addition to any bathroom or kitchen, enhancing both functionality and aesthetics.

2. SETUP

2.1. Unboxing and Components

Carefully remove all components from the packaging. You should find the P11 dispenser unit, a USB-C charging cable, a small cleaning bottle, and adhesive wall-mount hooks.

RECHARGEABLE WITH POWER INDICATOR



 Power Indicator



1200mAh
Battery



Full Charge
in 2 hrs



Lasts 2-4 Months
Per Charge



Type-C
Charging Port

Figure 2.1: The P11 dispenser unit, USB-C charging cable, and cleaning bottle.

2.2. Initial Charging

Before first use, fully charge the dispenser using the provided USB-C cable. The power indicator lights on the top of the unit will show the charging progress (25%, 50%, 75%, 100%). A full charge typically takes 2 hours and can last up to 2-4 months depending on usage.



RECHARGEABLE WITH POWER INDICATOR



1200mAh
Battery



Full Charge
in 2 hrs



Lasts 2-4 Months
Per Charge



Type-C
Charging Port

Figure 2.2: Charging the P11 dispenser via its USB-C port. The power indicator lights on top show battery level.

2.3. Filling the Dispenser with Soap

The P11 dispenser is designed for foaming soap. If using liquid hand sanitizer, it must be mixed with water to create foam. The recommended ratio is 1 part liquid soap to 3 parts water. Shake well to ensure proper mixing before filling.

1. Twist the top section of the dispenser counter-clockwise to separate it from the soap reservoir.
2. Pour your pre-mixed foaming soap solution or diluted liquid soap into the reservoir. Do not overfill.
3. Align the top section with the reservoir and twist clockwise until securely closed.

WHICH SOAPS PRODUCE FOAM?



Liquid Soap

Dilute the soap solution with 3 times as much water and shake well to get a perfect foam.



Foaming Soap

Pour the foaming soap directly into the bottle.

NOTE: The Foam Dispenser Cannot Dispense Viscous Hand Sanitizer Directly Or It Will Malfunction. Viscous Hand Sanitizer Must Be Mixed With 3 Times The Amount of Water And Shaken Well to Form Foam.

IPX5 WATERPROOF

IPX5 rated waterproof, but do not immerse the top of the unit in water or rinse it with water.



Figure 2.3: Proper soap dilution and filling method for optimal foam production.

2.4. Placement Options

The P11 dispenser offers versatile placement options:

- **Countertop:** Place the dispenser directly on any flat surface in your bathroom or kitchen. Its sleek design complements various decors.
- **Wall-Mounted:** Use the provided adhesive hooks to mount the dispenser on a wall, saving countertop space. Ensure the surface is clean and dry before applying the adhesive.





Figure 2.4: The P11 dispenser can be used on a countertop or conveniently mounted on a wall.

3. OPERATING INSTRUCTIONS

3.1. Power On/Off

To power on the dispenser, press and hold the power button (circular icon) on the top panel until the indicator lights illuminate. To power off, press and hold the power button again until the lights turn off.

3.2. Dispensing Foam

Once powered on, simply wave your hand under the high-precision smart sensor located at the front of the dispenser. Foam will be dispensed automatically within 0.25 seconds.



Figure 3.1: Place your hand under the sensor for automatic foam dispensing.

3.3. Adjusting Foam Volume

The P11 offers 4 different foam volume settings to customize your handwashing experience. Press the volume adjustment button (three vertical bars icon) on the top panel to cycle through the settings. Each press will change the dispensed amount, indicated by the corresponding light on the panel.

- Level 1: 0.5g foam
- Level 2: 1.5g foam
- Level 3: 2.4g foam
- Level 4: 3.2g foam



Figure 3.2: Choose from four foam volume settings to suit your preference.

3.4. Product Demonstration Video

Video 3.1: Official demonstration of the Wisekoti P11 Automatic Foaming Hand Soap Dispenser, showcasing its features and operation.

4. MAINTENANCE

4.1. Cleaning the Dispenser

To ensure optimal performance and prevent clogging, regularly clean the dispenser. Use the provided cleaning bottle filled with warm water to flush the internal pump and spout. Run the cleaning cycle by pressing the power button until the unit dispenses water.



Figure 4.1: Use the provided cleaning bottle for internal maintenance.

4.2. Waterproof Rating

The P11 dispenser has an IPX5 waterproof rating, meaning it is protected against low-pressure water jets from any direction. However, it is important NOT to immerse the top of the unit in water or rinse it directly with strong water streams to prevent damage to internal electronic components.



Figure 4.2: The P11 dispenser is IPX5 waterproof, suitable for bathroom and kitchen environments.

5. TROUBLESHOOTING

- **Dispenser not producing foam:**
 - Ensure the soap-to-water ratio is correct (1 part soap to 3 parts water). Viscous hand sanitizer must be diluted.
 - Check if the dispenser is powered on and fully charged.
 - Perform a cleaning cycle using warm water and the provided bottle to clear any clogs in the pump or spout.
- **Power indicator lights not working:**
 - Connect the dispenser to a power source using the USB-C cable to check if it charges. If not, contact support.
- **Foam consistency is too thin/thick:**
 - Adjust the soap-to-water ratio. For thicker foam, slightly reduce water. For thinner foam, add more water.

6. SPECIFICATIONS

Feature	Detail
Model Number	P11
Color	Space Gray
Material	Plastic (BPA Free)
Product Dimensions	4.3"L x 2.95"W x 7.9"H
Item Weight	11.6 ounces
Battery	1 Lithium Ion (included)
Charging Port	USB-C
Foam Settings	4 Levels (0.5g, 1.5g, 2.4g, 3.2g)
Sensor Response Time	0.25 seconds
Waterproof Rating	IPX5

7. WARRANTY & SUPPORT

The wisekoti P11 Automatic Foaming Hand Soap Dispenser comes with a **One Year Warranty**. This warranty covers manufacturing defects and ensures your product functions as intended. For any support inquiries, troubleshooting assistance beyond this manual, or warranty claims, please refer to the contact information provided with your product packaging or visit the official wisekoti website.

Additionally, by diluting your soap, you can significantly save on soap expenses, offering a practical and economical solution for your home.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question