

Juskys 32341

Juskys Palmira Inflatable Whirlpool User Manual

Model: 32341

1. INTRODUCTION

Thank you for choosing the Juskys Palmira Inflatable Whirlpool. This manual provides essential information for the safe and efficient setup, operation, and maintenance of your new whirlpool. Please read this manual thoroughly before installation and use, and retain it for future reference.

The Juskys Palmira is designed for both indoor and outdoor use, offering a relaxing spa experience for up to 6 persons. It features an integrated heating system, powerful massage jets, and an LED lighting system for enhanced ambiance.

Important Safety Information:

- Always supervise children around the whirlpool.
- Do not use electrical appliances near the whirlpool.
- Ensure the power outlet is properly grounded and protected by a Residual Current Device (RCD).
- Consult a physician before use if you have health concerns.

Your browser does not support the video tag.

Video: General overview of the Juskys Palmira Inflatable Whirlpool, showcasing its features and design.

2. PRODUCT COMPONENTS

Before beginning the setup, ensure all components are present and undamaged. The package typically includes:

- Inflatable Whirlpool Liner
- Control Unit / Pump (with integrated heater and filter)
- Inflatable Cover
- Ground Mat
- Inflation Hose
- Filter Cartridges
- Repair Kit
- Storage Bag

UMFANGREICHES ZUBEHÖR



Reparaturset



Bodenmatte



Filterelement



Aufblasschlauch



Pumpe

Poolabdeckung

Schutz vor Dreck/Insekten



Transporttasche

Image: Overview of the comprehensive accessories included with the Juskys Palmira Whirlpool, such as the pump, repair kit, ground mat, filter elements, inflation hose, pool cover, and transport bag.

3. SETUP INSTRUCTIONS

3.1 Site Selection

Choose a flat, stable, and level surface capable of supporting the weight of the filled whirlpool (approximately 1400 kg for 1400 liters of water plus occupants). Ensure adequate drainage and proximity to a suitable power outlet. Avoid sharp objects or uneven ground.

3.2 Inflation

1. Unfold the ground mat and place it on the selected site.
2. Place the deflated whirlpool liner on the ground mat.
3. Connect the inflation hose to the air valve on the whirlpool liner and the inflation port on the control unit.
4. Plug in the control unit and press the inflation button. Inflate until the whirlpool is firm to the touch but not over-

inflated.

5. Disconnect the inflation hose and securely close the air valve.

3.3 Connecting the Control Unit

Connect the three hoses from the whirlpool liner to the corresponding ports on the control unit. Ensure all connections are tight to prevent leaks. The control unit features an easy connection system with a protective contact plug for safety.



Image: Detailed view of the easy connection points for the control unit and the user-friendly control panel, highlighting the simple setup process.

3.4 Filling with Water

Fill the whirlpool with fresh water using a garden hose until the water level is between the minimum and maximum fill lines indicated on the inner wall of the whirlpool. Do not overfill.

4. OPERATION

The Juskys Palmira whirlpool is operated via the intuitive control panel on the pump unit. Familiarize yourself with the various functions:

- **Power Button:** Turns the unit on/off.
- **Heater Button:** Activates the heating function. Set desired temperature using the temperature adjustment buttons. The water can be heated up to 40°C (104°F).
- **Bubble Button:** Activates the 130 air jets for a relaxing massage.
- **Filter Button:** Activates the water filtration system. It is recommended to run the filter regularly to maintain water quality.
- **LED Light Button:** Controls the integrated RGB LED lighting for atmospheric illumination.



Image: The Juskys Palmira Whirlpool with active bubbling water, demonstrating the powerful massage jets in operation.

PURE ENTSPANNUNG

Die Wellnessoase in
Ihrem Zuhause

RGB-LED-Leiste für
stimmungsvolles Licht



Image: An infographic highlighting key operational features: 130 massage jets, water temperature adjustable up to 40°C, and options for heating, bubbling, or water circulation.

5. MAINTENANCE

5.1 Water Quality

Maintaining proper water chemistry is crucial for hygiene and the longevity of your whirlpool. Regularly test the water pH and chlorine/bromine levels using a test kit. Adjust chemicals as needed according to the manufacturer's instructions for your chosen water treatment products.

5.2 Filter Cartridge Cleaning and Replacement

The filter cartridge should be cleaned regularly (daily or every other day depending on usage) by rinsing it with a garden hose. Replace the filter cartridge every 1-2 weeks, or sooner if it remains dirty after cleaning, to ensure efficient filtration.

5.3 Draining and Cleaning

Drain the whirlpool completely every 1-3 months, or as needed, for thorough cleaning. Use a mild, non-abrasive cleaner

and a soft cloth to wipe down the interior and exterior surfaces. Rinse thoroughly and allow to dry before refilling or storing.

5.4 Winterization and Storage

If storing the whirlpool for an extended period or during winter in cold climates, ensure it is completely drained, cleaned, and dry. Deflate the whirlpool and store all components in a dry, protected area, ideally in the provided storage bag, away from extreme temperatures and direct sunlight.



Image: The Juskys Palmira Whirlpool with its protective inflatable cover in place, demonstrating proper storage or covering when not in use. Also shown is the remote control for the LED lighting system.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Whirlpool not heating	Heater not activated; water temperature already at set point; low water flow; dirty filter.	Ensure heater is on; check set temperature; clean/replace filter; ensure water level is adequate.

Problem	Possible Cause	Solution
No bubbles from jets	Bubble function not activated; air pump malfunction.	Press the bubble button; check power connection; contact customer support if issue persists.
Water is cloudy/dirty	Insufficient filtration; improper water chemistry; heavy usage.	Run filter longer; clean/replace filter cartridge; adjust water chemicals (pH, sanitizer); drain and refill if necessary.
Whirlpool losing air	Loose valve cap; small puncture.	Tighten valve caps; use provided repair kit to patch small holes.

7. SPECIFICATIONS

Detailed technical specifications for the Juskys Palmira Inflatable Whirlpool:

- **Model Number:** 32341
- **Product Dimensions (L x W x H):** 210 x 210 x 70 cm (82.7 x 82.7 x 27.6 inches)
- **Water Capacity:** Approximately 1400 Liters (370 US Gallons)
- **Seating Capacity:** Up to 6 Persons
- **Item Weight (empty):** 34 Kilograms (75 lbs)
- **Voltage:** 232 Volts
- **Maximum Water Temperature:** 40°C (104°F)
- **Massage Air Jets:** 130
- **Color:** Black

PLATZ FÜR BIS ZU 6 PERSONEN

Wasserspaß für die
ganze Familie

1100 L

Wasserkapazität




Image: A visual representation of the Juskys Palmira Whirlpool's dimensions, including its outer length (210 cm), inner length (170 cm), and height (70 cm). The image indicates a water capacity of 1100 liters, while the product specifications state approximately 1400 liters.

8. WARRANTY AND SUPPORT

Juskys products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your product or visit the official Juskys website. If you encounter any issues not covered in this manual or require technical assistance, please contact Juskys customer support.

For further assistance, please visit the [Juskys Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question