

[Manuals.plus](#) /

› [Bluefin SUP](#) /

› Bluefin SUP Cruise 10'8" Inflatable Paddle Board User Manual

Bluefin SUP SUP Cruise 10'8"

Bluefin SUP Cruise 10'8" Inflatable Paddle Board User Manual

Brand: Bluefin SUP | Model: SUP Cruise 10'8"

INTRODUCTION

Welcome to the user manual for your Bluefin Cruise 10'8" Inflatable Paddle Board. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your SUP board. The Bluefin Cruise 10'8" is designed for stability, versatility, and all-around leisure use, suitable for both beginners and experienced paddlers.

WHAT'S INCLUDED

Your Bluefin Cruise 10'8" package includes the following components:

- Bluefin Cruise 10'8" Inflatable Paddle Board
- Dual Action Pump
- Bluefin Travel Backpack
- 3 Smartlock Fins (1 Large, 2 Small)
- Fibreglass Paddle (2 Blades, Handle, Shaft)
- Waterproof Phone Case
- Ankle Leash
- Kayak Seat
- Instruction Manual (this document)
- Repair Kit



Image: All components included with the Bluefin Cruise 10'8" SUP board.

SETUP

1. Board Inflation

Unroll the paddle board on a flat, clean surface. Locate the inflation valve, typically at the tail of the board. Ensure the valve pin is in the 'up' position for inflation. Connect the dual action pump to the valve. Inflate the board to the recommended pressure of 15-18 PSI. The board can withstand up to 28 PSI for maximum rigidity. The dual action pump inflates on both the up and down strokes for faster inflation. Once the pressure builds, you can switch to single action mode for easier pumping.

DUAL ACTION HI PRESSURE PUMP



FEATURES

- Dual Action - Up + Down Pump Inflation
- High Pressure PSI Gauge
- Slim And Lightweight
- Ergonomic Grip Pump Handle



Image: Connecting the dual action pump to the board's inflation valve.

2. Fin Installation

The Bluefin Cruise 10'8" features a 2+1 fin setup with Smartlock fins. Simply slide the fins into their respective boxes and clip them into place. No tools are required for installation or removal. The three fins provide enhanced stability and maneuverability.

THE **ULTIMATE** **SUP** BACKPACK



FEATURES

- Travel Friendly
- Heavy Duty YKK Zippers
- Sturdy Grab Handles
- Side Mesh Pocket
- Extra Long Zip Pulls
- Extra Back, Hip And Strap Padding



Image: Attaching the Smartlock fins to the board.

3. Paddle Assembly

The fibreglass paddle is a lightweight, 4-piece design. Assemble the paddle by connecting the sections. It is height-adjustable from 175cm-225cm (approximately 5'9" to 7'4"). The paddle can also be converted into a kayak paddle by swapping the SUP handle for the extra blade supplied in the package.



TOUGH LIGHTWEIGHT PADDLE

FEATURES

- Adjustable Height
170 - 225cm
- Lightweight Fibre-Glass
Paddle Shaft
- Use As A Kayak Paddle
With Extra Blade
- Quick Release Clamp



Image: The adjustable fibreglass paddle and its kayak conversion option.

FEATURES & DESIGN

The Bluefin Cruise 10'8" incorporates advanced design and features for an enhanced paddling experience:

- **ESL Technology:** Utilizes Exo Surface Laminate technology and Pro Weave Drop Stitch for extreme rigidity and durability. This construction allows the board to hold up to 28 PSI, making it one of the stiffest inflatable SUPs on the market.
- **Crocodile Deckpad:** A non-slip deck pad with a unique crocodile texture provides comfortable footing and extra grip. It includes a kickpad at the tail for improved maneuverability and quick turns.
- **Smartlock Fins:** The durable 2+1 fin setup allows for easy clip-in installation without tools, ensuring firm placement and excellent tracking.
- **Dual Action Pump:** Efficiently inflates the board on both up and down strokes, with a switch to single action for


higher pressures.

- **Ultimate SUP Backpack:** Designed for travel, this durable backpack features heavy-duty YKK zippers, sturdy grab handles, side mesh pockets, and extra padding for comfort during transport.
- **Tough Paddle:** The 3-piece fibreglass paddle is lightweight and fully adjustable. It can be converted into a kayak paddle with an extra blade for versatile use.
- **Padded Kayak Seat:** Easily clips onto the board's D-rings, transforming your SUP into a kayak for seated paddling.
- **Safety Ankle Leash:** A coiled leash with a comfortable neoprene band ensures the board stays close if you fall. It features a Velcro rail-saver end for a secure connection.
- **Action Camera Mount:** Located at the nose of the board, this mount allows you to attach compatible action cameras (like GoPros) to capture your adventures.

THE ORIGINAL ALL-ROUNDER

OUR FLAGSHIP SUP IS THE IDEAL CHOICE FOR BEGINNERS AND ALL-ROUND LEISURE USE

SMART-LOCK Fin System	KICKPAD For Quick Turns	PADDLE STAY + Neoprene Handle	KAYAK SEAT Mounting Points	CARGO AREA Bungee Cord	ACTION CAMERA Fixed Mount
					



CRUISE

10'8"

BLUEFIN

**W-82cm
L-324cm
D-16cm**

FEATURES

- Military Grade PVC Construction
- Super Reinforced Composite Dropstitch
- UV Resistant HQ Coating
- Thermostatic Crocodile Deckpad

**KAYAK CONVERTIBLE
Kit Included**



Image: Detailed overview of the Bluefin Cruise 10'8" features.



WHAT'S IN THE BOX



CONTENTS

- 1 Cruise 10' 8 Board
- 2 Dual Action Pump
- 3 Bluefin Backpack
- 4 x3 Smartlock Fins: x1 Large, x2 Small
- 5 Fibre Glass Paddle: x2 Blades, Handle, Shaft
- 6 Waterproof Phone Case
- 7 Ankle Leash
- 8 Kayak Seat
- 9 Instruction Manual
- 10 Repair Kit



Image: The ultimate SUP backpack for easy transport.



Image: Key functional elements of the board, including the leash attachment and valve.

OPERATING INSTRUCTIONS

Paddling

Once the board is inflated and the fins are attached, carry the board to the water using the central carry handle. For initial stability, you may start by kneeling on the board. Once comfortable, slowly stand up, placing your feet shoulder-width apart in the center of the board. Use the adjustable paddle to propel yourself forward, keeping the paddle blade angled away from you during the stroke.

Your browser does not support the video tag.

Video: Demonstrates proper paddling technique and board stability on the water.

Turning

To turn, paddle on one side of the board more forcefully or sweep the paddle in a wider arc. For sharper turns, step back slightly on the board towards the kickpad, lifting the nose slightly out of the water, and sweep the paddle.

Kayak Mode

To convert to kayak mode, attach the padded seat to the side D-rings. Adjust the paddle to its double-bladed kayak configuration. This allows for a comfortable seated paddling experience, ideal for longer tours or when you prefer not to stand.

MAINTENANCE

Proper maintenance ensures the longevity of your Bluefin Cruise SUP board:

- **Cleaning:** After each use, rinse the board with fresh water to remove salt, sand, or dirt. Use mild soap and water for stubborn stains.
- **Drying:** Ensure the board is completely dry before deflating and storing to prevent mold and mildew.
- **Storage:** Deflate the board, remove the fins, and roll it up. Store it in the provided backpack in a cool, dry place away from direct sunlight and extreme temperatures.
- **Valve Care:** Periodically check the valve for debris and ensure it's tightly sealed. Use the included valve wrench if needed.

TROUBLESHOOTING

Common issues and their solutions:

- **Board not holding air:** Check the valve for proper sealing. Ensure the valve pin is in the 'up' position for inflation and 'down' for deflation. Inspect the board for any punctures. Use the included repair kit for small holes.
- **Difficulty inflating:** Ensure the pump hose is securely attached to the valve. If using the dual action pump, ensure it's in the correct mode (double action for initial inflation, single action for higher pressures).
- **Board feels wobbly:** Ensure the board is inflated to the recommended PSI. Check that all fins are securely installed. Proper foot placement (shoulder-width apart, centered) is crucial for stability.

For more complex issues, please refer to the warranty and support section.

SPECIFICATIONS

Attribute	Value
Product Dimensions	125.98"L x 35.43"W
Skill Level	All
Maximum Weight Recommendation	150 Kilograms
Item Thickness	6 Inches

Age Range (Description)	Adult
Maximum Pressure	28 Pound per Square Inch
Material	Nylon
Model Name	SUP Cruise 10'8"
Included Components	Kayak Conversion Kit
Item Weight	17.6 Kilograms

WARRANTY & SUPPORT

Bluefin SUP offers a 5-year warranty as standard for their boards, demonstrating confidence in their product quality and durability. This extended warranty provides peace of mind and highlights the robust construction of the board. For any support inquiries, troubleshooting assistance beyond this manual, or warranty claims, please visit the official Bluefin SUP website or contact their multi-channel customer support. You can also refer to the User Manual (PDF) available at <https://manuals.plus/m/420055bb20b4ea18d130e7ca245b5abf8a86665c81b18b14c322b078404b85ef>.

© 2024 Bluefin SUP. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

