

[Manuals.plus](#) /

› [Comfort Zone](#) /

› Comfort Zone CZ650BWT Baseboard Space Heater User Manual

## Comfort Zone CZ650BWT

# Comfort Zone CZ650BWT Baseboard Space Heater User Manual

Model: CZ650BWT | Brand: Comfort Zone

## 1. INTRODUCTION

Thank you for choosing the Comfort Zone CZ650BWT Baseboard Space Heater. This powerful 1500-watt convection heater is designed to provide efficient and quiet warmth for medium-sized rooms. It features a digital adjustable thermostat for precise temperature control and an advanced safety system for peace of mind. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your new heater, ensuring safe and effective use.



Figure 1.1: Front view of the Comfort Zone CZ650BWT Baseboard Space Heater.

## 2. SETUP AND PLACEMENT

The Comfort Zone CZ650BWT Baseboard Space Heater requires no assembly, making setup quick and easy. Simply remove it from its packaging and place it in your desired location.

### 2.1 Unpacking

1. Carefully remove the heater from its box.
2. Remove all packaging materials, including any protective films or ties.
3. Inspect the heater for any signs of damage. If damaged, do not use and contact customer support.

### 2.2 Placement

- Place the heater on a firm, level surface.
- Ensure the heater is placed at least 3 feet (0.9 meters) away from any walls, furniture, curtains, or other combustible materials.
- Do not place the heater in areas where it may be easily tipped over.
- Plug the heater directly into a 120V AC, 60Hz electrical outlet. Do not use extension cords or power strips.

# Durable & Sleek Design

## Low Profile and Dent-Proof end panels



Figure 2.1: Ensure proper clearance around the heater for safe operation.

## 3. OPERATING INSTRUCTIONS

Your Comfort Zone baseboard heater is equipped with a digital display and onboard controls for easy operation. It offers two heat settings and a timer function.

### 3.1 Control Panel Overview




Figure 3.1: Digital display and control buttons for power, mode, temperature adjustment, and timer.

### 3.2 Powering On/Off and Heat Settings

1. Press the **ON/OFF** button to turn the heater on. The digital display will illuminate.
2. Press the **MODE** button to cycle between heat settings: 750W (low heat) and 1500W (high heat). The corresponding indicator light will show the selected wattage.
3. To turn the heater off, press the **ON/OFF** button again.

### 3.3 Setting the Temperature

- With the heater on, press the **MODE** button until the 'TEMP' indicator light is illuminated. The display will show the current room temperature.
- Use the **UP** and **DOWN** arrow buttons to adjust your desired temperature between 35°F and 95°F.
- The heater will automatically turn on or off to maintain the set temperature.

### 3.4 Using the Timer

- Press the **MODE** button until the 'TIMER' indicator light is illuminated. The display will show '00H'.
- Use the **UP** and **DOWN** arrow buttons to set the desired operating time, from 1 to 12 hours.
- The heater will operate for the set duration and then automatically turn off.

### 3.5 Silent Operation

This electric baseboard heater is designed for whisper-quiet operation, ensuring a peaceful environment without distracting noise. This makes it ideal for bedrooms, living rooms, or home offices where quiet is preferred.

# Powerful Heating Performance

Choose between two heat settings: 750W / 1500W

Perfect for Medium sized rooms



Figure 3.2: The heater provides warmth without disruptive noise.

## 3.6 Product Overview Video

Your browser does not support the video tag.

Video 3.1: An overview of Comfort Zone heaters, showcasing various models and their general features. This video provides a broad look at the brand's heating solutions.

## 4. SAFETY FEATURES

Your Comfort Zone CZ650BWT Baseboard Space Heater is equipped with advanced safety features to ensure safe operation and provide peace of mind.

- **Safety Tip-Over Switch:** The heater will automatically shut off if it is accidentally knocked over, preventing potential hazards.
- **Overheat Protection Sensor:** This sensor actively monitors the heater's temperature and will automatically shut off the unit if it begins to overheat.
- **Stay-Cool Body:** The exterior of the heater remains cool to the touch during operation, reducing the risk of accidental burns.
- **Dent-Proof End Panels:** Designed for durability, the end panels resist dents, maintaining the heater's sleek appearance and structural integrity.



Figure 4.1: Key safety features integrated into the heater's design.

## 5. MAINTENANCE

Regular maintenance helps ensure the longevity and efficient operation of your heater. Always unplug the heater

and allow it to cool completely before performing any maintenance.

### 5.1 Cleaning

- Use a soft, damp cloth to wipe the exterior surfaces of the heater.
- Do not use abrasive cleaners or solvents as they may damage the finish.
- Ensure no water or liquid enters the interior of the heater.
- Periodically vacuum the air intake and exhaust grilles to remove dust and lint buildup.

### 5.2 Storage

- When not in use, store the heater in a cool, dry place.
- It is recommended to store the heater in its original packaging to protect it from dust and damage.

## 6. TROUBLESHOOTING

If your heater is not operating correctly, please refer to the following common issues and solutions before contacting customer support.

| Problem                        | Possible Cause                                            | Solution                                                                                                                                        |
|--------------------------------|-----------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|
| Heater does not turn on.       | No power to the unit.                                     | Ensure the heater is plugged into a working 120V outlet. Check the circuit breaker.                                                             |
| Heater turns off unexpectedly. | Overheat protection activated or tip-over switch engaged. | Unplug the heater, allow it to cool for 30 minutes. Check for obstructions around the grilles. Ensure the heater is on a stable, level surface. |
| Not enough heat.               | Incorrect heat setting or thermostat setting.             | Ensure the heater is set to 1500W. Increase the thermostat setting to a higher temperature. Ensure doors/windows are closed.                    |
| Digital display not working.   | Power issue or internal malfunction.                      | Check power connection. If issue persists, contact customer support.                                                                            |

## 7. SPECIFICATIONS

Detailed technical specifications for the Comfort Zone CZ650BWT Baseboard Space Heater.

- **Brand:** Comfort Zone
- **Model Number:** CZ650BWT
- **Power:** 1500 Watts (Two heat settings: 750W / 1500W)
- **Voltage:** 120 Volts
- **Amperage:** 12.5 Amps
- **Product Dimensions (DxWxH):** 10.83"D x 35.75"W x 6.1"H
- **Item Weight:** 5 pounds
- **Heating Coverage:** Up to 200 sq. ft.
- **Thermostat:** Digital Adjustable (35°F - 95°F)

- **Timer:** 1-12 Hours
- **Safety Features:** Overheat Protection, Safety Tip-Over Switch, Stay-Cool Body
- **UPC:** 075877128119




Figure 7.1: Key dimensions of the Comfort Zone CZ650BWT Baseboard Space Heater.

## 8. WARRANTY AND SUPPORT

The Comfort Zone CZ650BWT Baseboard Space Heater comes with a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions. For technical support, troubleshooting assistance, or warranty claims, please contact Comfort Zone customer service. Contact information can typically be found on the manufacturer's website or on the product packaging.

© 2025 Comfort Zone. All rights reserved.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question