### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- > X9 Performance /
- > X9 Performance Ergonomic Wireless Keyboard with Trackball User Manual

#### X9 Performance X9RFBLERGBAL

### X9 Performance Ergonomic Wireless Keyboard with Trackball User Manual

Model: X9RFBLERGBAL

### 1. Introduction

Thank you for choosing the X9 Performance Ergonomic Wireless Keyboard with Trackball. This keyboard is designed to enhance your typing comfort and efficiency with its split ergonomic layout, integrated trackball, and convenient features. This manual provides detailed instructions to help you set up, operate, and maintain your new keyboard.





Image: The X9 Performance Ergonomic Wireless Keyboard with Trackball, showcasing its split design and integrated trackball.

### 2. SETUP

#### 2.1. What's in the Box

- X9 Performance Ergonomic Wireless Keyboard
- USB-A 2.4GHz Wireless Adapter
- USB-C Charging Cable
- User Manual (this document)

### 2.2. Connecting Your Keyboard

The X9 Performance keyboard uses a 2.4GHz wireless connection via a USB-A adapter. No software installation is required for basic functionality.

- 1. Locate the USB-A wireless adapter. It is typically stored in a compartment on the underside of the keyboard for safekeeping.
- 2. Plug the USB-A wireless adapter into an available USB-A port on your computer (PC or Chrome device).

3. Turn on the keyboard using the power switch, usually located on the underside or side of the keyboard. The keyboard should automatically connect to your computer.

### ENJOY BACKLIT KEYS.

White backlit keys with 3 brightness settings for optimal visibility in any lighting scenario




Image: The keyboard's underside showing the USB-A dongle storage and the USB-C charging port, highlighting its wireless and rechargeable capabilities.

### 2.3. Charging the Keyboard

The keyboard features a built-in 2000mAh rechargeable battery. To charge:

- Connect the provided USB-C charging cable to the USB-C port on the keyboard.
- Connect the other end of the USB-C cable to a USB power source (e.g., computer USB port, USB wall adapter).
- The charging indicator light on the keyboard will illuminate during charging and turn off when fully charged. A full charge can provide up to 12 months of use.

### 3. OPERATING INSTRUCTIONS

### 3.1. Ergonomic Design and Comfort

The keyboard's split and sloped structure, combined with an integrated wrist rest, is designed to promote a natural hand and wrist posture, reducing strain during extended typing sessions.

### PROMOTES TYPING COMFORT.

The split and sloped structure of the keyboard paired with a wrist rest promotes natural typing posture and efficiency



Image: The keyboard's ergonomic split design and integrated wrist rest, illustrating how it promotes comfortable typing posture.

### 3.2. Integrated Trackball and Mouse Controls

The keyboard features a centralized trackball for thumb-controlled navigation, eliminating the need for a separate mouse. It includes dedicated mouse buttons and a scroll wheel.

- Trackball: Use your thumb to control the cursor movement.
- Left Click Button: Located to the left of the trackball.
- Right Click Button: Located to the right of the trackball.
- Scroll Wheel: Positioned above the trackball for vertical scrolling.

# THUMB CONTROLLED PRECISION.

Centralized trackball for easy thumb control, easy navigation, and more comfort



Image: Close-up of the keyboard's central area, highlighting the thumb-controlled trackball for precise navigation.

## INTEGRATED MOUSE CONTROLS.

Handle every click, scroll, and move directly from your keyboard to streamline workflow




Image: Diagram showing the scroll wheel, right click, left click, and trackball components on the keyboard.

### 3.3. Adjusting Trackball Sensitivity

You can fine-tune the trackball's cursor speed through your computer's operating system settings.

- For Windows PC:
  - 1. Open Settings.
  - 2. Navigate to Bluetooth & devices.
  - 3. Select Mouse.
  - 4. Adjust the Mouse pointer speed slider to your preferred sensitivity.










Image: Step-by-step visual guide on how to adjust trackball sensitivity within Windows settings.

### 3.4. Backlight Adjustment

The keyboard features white backlighting with 3 adjustable brightness levels for optimal visibility in various lighting conditions.

• To cycle through brightness levels (Off, Low, Medium, High), press the dedicated backlight control key (often indicated by a light bulb icon or similar).

### WIRELESS AND RECHARGEABLE.

The USB-A dongle offers a wireless range of 30ft Built in 2000mAh rechargeable battery for extended use



Image: The keyboard with its white backlit keys illuminated, demonstrating visibility in a dim setting.

### 3.5. Shortcut Keys

The keyboard includes 19 dedicated shortcut keys for quick access to various functions, such as volume control, media playback, and application management. Refer to the key legends for specific functions.

## **DESIGNED FOR** PC AND CHROME. Split 128-Key Layout Media Keys 19 Shortcuts 2 Spacebars

Image: An overhead view of the keyboard, pointing out the split 128-key layout, media keys, and 19 shortcut keys.

### 3.6. Product Overview Video

Watch this official product video for a visual overview of the X9 Performance Ergonomic Wireless Keyboard with Trackball, demonstrating its key features and benefits.

#### Your browser does not support the video tag.

Video: An overview of the X9 Split Wireless Keyboard with Thumb-Controlled Trackball, demonstrating its ergonomic design, integrated trackball, and other features.

### 4. MAINTENANCE

### 4.1. Cleaning the Keyboard

To ensure longevity and optimal performance, clean your keyboard regularly:

- Disconnect the keyboard from your computer before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a mild, non-abrasive cleaning solution.
- · Avoid spraying liquids directly onto the keyboard.
- · For dust and debris between keys, use compressed air.

### 4.2. Trackball Cleaning

If the trackball's movement becomes rough or inaccurate, it may need cleaning:

- Gently remove the trackball from its housing (refer to product diagrams if available for specific removal instructions).
- Clean the trackball and the inside of its housing, especially the small rollers or sensors, with a clean, lint-free cloth.
- · Reinsert the trackball into its housing.

### 4.3. Battery Care

- Avoid fully discharging the battery frequently to prolong its lifespan.
- Store the keyboard in a cool, dry place when not in use for extended periods.

### 5. TROUBLESHOOTING

If you encounter issues with your X9 Performance keyboard, try the following solutions:

### 5.1. Keyboard Not Responding / Connectivity Issues

- Check Power: Ensure the keyboard is turned on and fully charged. Connect the USB-C charging cable to verify if the battery is low.
- USB Adapter: Ensure the 2.4GHz USB-A adapter is securely plugged into a working USB port on your computer.
   Try a different USB port.
- Re-pair: If connection is lost, try unplugging and re-plugging the USB adapter. Turn the keyboard off and on again.
- Interference: Move the keyboard closer to the USB adapter or away from other wireless devices that might cause interference.

### 5.2. Trackball Not Moving Smoothly or Inaccurately

- Clean Trackball: Refer to Section 4.2 for trackball cleaning instructions. Dust or debris can affect performance.
- Adjust Sensitivity: The trackball sensitivity might be too low or too high for your preference. Refer to Section 3.3 for instructions on adjusting trackball sensitivity in your operating system settings.

### 5.3. Backlight Not Working

- Check Brightness Level: Press the backlight control key (often with a light bulb icon) to cycle through brightness levels and ensure it's not set to 'Off'.
- Battery Level: Ensure the keyboard has sufficient battery charge. Low battery might disable backlighting to conserve power.

#### 6. Specifications

Feature	Detail
Brand	X9 Performance

Model Number	X9RFBLERGBAL
Product Dimensions	18.3"L x 8.7"W x 0.3"H (18.3 x 8.7 x 0.3 inches)
Item Weight	2.42 pounds
Connectivity Technology	RF 2.4G
Compatible Devices	PC (Windows), Chrome
Keyboard Description	Built-in Trackball and Mouse Keys, Multi Functional, Multimedia, Full Size, Rechargeable, Split Ergonomic
Special Feature	Backlit wireless ergonomic keyboard, carpal tunnel keyboard, full size trackball keyboard for PC, rechargeable split keyboard, wireless keyboard with trackball
Number of Keys	128
Keyboard Backlighting Color Support	Single Color (White)
Included Components	Keyboard, USB-A adapter, USB-C charging cable, user manual



Image: Technical drawing showing the dimensions of the X9 Performance Ergonomic Wireless Keyboard.

### 7. WARRANTY AND SUPPORT

X9 Performance products are designed for reliability and performance. For specific warranty information regarding your keyboard, please refer to the warranty card included with your product or visit the official X9 Performance website. If you require technical assistance, troubleshooting, or have questions about your product, please contact X9 Performance customer support through their official channels. Contact information can typically be found on the product packaging or the brand's website.

© 2025 X9 Performance. All rights reserved.

