

[Manuals.plus](#) /

› [Redroad](#) /

› Redroad CM17 Cordless Electric Spin Mop User Manual

Redroad CM17

Redroad CM17 Cordless Electric Spin Mop User Manual

Model: CM17 | Brand: Redroad

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the Redroad CM17 Cordless Electric Spin Mop. Retain this manual for future reference.

- Do not immerse the main unit or charging base in water or other liquids.
- Use only the provided power adapter for charging.
- Keep the appliance away from children and pets.
- Do not use the mop to clean flammable or combustible liquids, or in areas where such liquids may be present.
- Ensure the mop pads are properly attached before operation.
- Do not operate the mop if it is damaged or malfunctioning. Contact customer support for assistance.
- Always unplug the charger from the power outlet before cleaning or performing maintenance.
- This appliance is intended for household use only.

2. PACKAGE CONTENTS

Verify that all items are present in the package. If any items are missing or damaged, please contact customer support.

- Redroad CM17 Main Mop Unit
- Automatic Cleaning Bucket
- Telescopic Handle
- Mop Pads (multiple sets, typically 2-3 pairs)
- Power Adapter
- User Manual (this document)



Image: Complete package contents including the mop, cleaning bucket, and multiple mop pads.

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your Redroad CM17 mop.

3.1 Mop Unit Features

- **Telescopic Handle:** Adjustable for comfortable use and compact storage.
- **Control Panel:** Located on the handle, includes power button and water spray button.

- **Mop Head:** Houses dual rotating mop pads for efficient cleaning.
- **LED Headlight:** Illuminates dark areas under furniture or in corners for thorough cleaning.
- **Water Sprayer:** Fan-shaped spray design for continuous and even moisturization of the floor.
- **Battery Indicator:** Shows remaining battery life.

LED Searchlight

Cleaning Effect is Obvious at a Glance

The dead spots under the bed and sofa can be seen instantly, and seen at a glance whether the mopping is clean or not



Image: The mop head with its integrated LED headlight, demonstrating its ability to illuminate dark areas for improved cleaning visibility.

2-in-1 Quick Cleaning No Dirty Hands

Automatic Cleaning Bucket Hand wash-free Washing and Arying



Image: The mop's flexible articulation, showing its ability to pivot 90 degrees vertically and 180 degrees horizontally for reaching under furniture and around corners.

3.2 Automatic Cleaning Bucket Features

- **Clean Water Tank:** Holds fresh water for cleaning the mop pads.
- **Sewage Tank:** Collects dirty water after the mop pads are cleaned.
- **Squeegee Mechanism:** Integrated system for washing and drying mop pads without direct hand contact.

Separate clean water and sewage Cleaner

Washing and drying 2-in-1 Quick cleaning without dirty hands



Image: A detailed diagram illustrating the separate clean water purification tank and sewage tank within the automatic cleaning bucket, highlighting the squeegee mechanism.

4. SETUP

4.1 Assembly

1. Insert the telescopic handle into the designated slot on the mop head until it clicks securely into place.
2. Attach the mop pads to the bottom of the mop head. Ensure they are centered and firmly pressed onto the hook-and-loop fasteners.

4.2 Charging the Battery

1. Locate the charging port on the mop unit.
2. Connect the power adapter to the charging port and plug the adapter into a wall outlet.
3. The battery indicator lights will show the charging status. A full charge typically takes approximately 3-4 hours.

4. For optimal battery life, fully charge the mop before first use.



Image: An illustration showing the internal battery module and the LED headlight, indicating the 2200mAh high-capacity cordless battery and its runtime capabilities.

4.3 Preparing the Cleaning Bucket

1. Open the lid of the clean water tank on the automatic cleaning bucket.
2. Fill the clean water tank with clean tap water. You may add a small amount of non-foaming floor cleaning solution if desired. Do not exceed the MAX fill line.
3. Close the lid securely.

5. OPERATING INSTRUCTIONS

5.1 Powering On/Off

- To turn on the mop, press the Power button on the handle. The mop pads will begin to rotate.
- To turn off the mop, press the Power button again.

5.2 Mopping Your Floors

1. Ensure the mop pads are clean and slightly damp before starting.
2. Turn on the mop.
3. For wet mopping, press the Water Spray button on the handle to dispense water onto the floor. The fan-shaped spray ensures even coverage.
4. Guide the mop across the floor in a steady, overlapping motion. The dual rotating pads will effectively clean the surface.
5. Utilize the LED headlight to identify and clean hidden dirt under furniture or in dimly lit areas.
6. The mop is suitable for hard floors, tile, wood, laminate, and marble.

Fan-shaped Spraying Design Continuous and Even Moisturization

Automatic Cleaning Bucket Hand wash-free Washing and Airing



Image: The Redroad CM17 mop operating on a wooden floor, illustrating its fan-shaped spraying design for continuous and even moisturization during cleaning.

Redroad

Cordless Electric Mopping Cleaner

Home daily cleaning
dry and wet mopping, waxing
easy to handle with one machine



Image: The Redroad CM17 mop effectively cleaning various types of common household stains, demonstrating its versatility on different floor surfaces.

5.3 Using the Automatic Cleaning Bucket

The automatic cleaning bucket allows for hands-free washing and drying of the mop pads.

1. When the mop pads become dirty, place the mop head into the automatic cleaning bucket, aligning it with the internal mechanism.
2. Press down gently on the mop handle to engage the cleaning mechanism. The mop pads will be washed and excess water will be squeezed out into the sewage tank.
3. Lift the mop out of the bucket. The pads are now clean and ready for further mopping.

2-in-1 Quick Cleaning No Dirty Hands

Automatic Cleaning Bucket Hand wash-free Washing and Airing



Image: The Redroad CM17 mop head positioned within its automatic cleaning bucket, illustrating the 2-in-1 quick cleaning process without dirtying hands.

Use with Disinfectant for Efficient Sterilization Maintain a Healthy Environment

Add disinfectant in the water tank and it will be evenly
sprayed to the ground. Controllable and easy to use.



Image: The Redroad CM17 mop integrated with its automatic cleaning bucket, demonstrating the separation of clean water and sewage for efficient, hands-free cleaning.

6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your Redroad CM17 mop.

6.1 Cleaning Mop Pads

- After each use, or as needed, use the automatic cleaning bucket to wash the mop pads.
- For deeper cleaning, remove the mop pads from the mop head and hand wash them with mild detergent or machine wash them on a gentle cycle.
- Allow mop pads to air dry completely before reattaching or storing.

High-speed Double Rotation Wipe

Remove Stubborn Stains with Ease




Image: A close-up view of the high-density water-locking mop cloth, highlighting its texture and suitability for various floor types and both wet and dry mopping.

6.2 Emptying and Cleaning the Cleaning Bucket

1. After each cleaning session, or when the sewage tank is full, detach the sewage tank from the cleaning bucket.

- 2. Empty the dirty water into a drain.
- 3. Rinse both the clean water tank and sewage tank with fresh water.
- 4. Allow all components to air dry before reassembling.

6.3 Storing the Mop

- Ensure the mop is clean and dry before storage.
- Store the mop and cleaning bucket in a cool, dry place, away from direct sunlight and extreme temperatures.
- The telescopic handle can be adjusted to its shortest length for compact storage.

7. TROUBLESHOOTING

Refer to this section for common issues and their solutions. If the problem persists, contact customer support.

Problem	Possible Cause	Solution
Mop not turning on.	Battery is low or depleted.	Charge the mop fully.
Mop pads not rotating.	Obstruction in the mop head; Mop not powered on.	Check for and remove any obstructions; Ensure the mop is turned on.
Water not spraying.	Water tank is empty; Spray nozzle is clogged.	Refill the clean water tank; Clean the spray nozzle.
Poor cleaning performance.	Mop pads are too dirty or worn out; Insufficient water.	Clean or replace mop pads; Ensure adequate water in the tank.
Automatic cleaning bucket not working effectively.	Insufficient water in clean tank; Sewage tank is full; Mop head not properly aligned.	Refill clean water tank; Empty sewage tank; Ensure mop head is correctly placed in the bucket.

8. SPECIFICATIONS

Technical specifications for the Redroad CM17 Cordless Electric Spin Mop.

Model:	Redroad CM17
Host Voltage Rating:	14.8V
Power:	50W
Charger Input:	100-240V, 50/60HZ
Charger Output:	18V-420mA
Cell/Battery Capacity:	2200mAh/4 cells
Water Tank Capacity:	150ml
Wet Mopping Time:	Up to 30 minutes
Dry Mopping Time:	Up to 50 minutes

Net Weight:	2.90kg
Form Factor:	Handheld
Included Components:	Mop Head, Telescopic Handle, Wring Bucket
Special Features:	Double Motor, LED Headlight, Water Sprayer, Automatic Cleaning Bucket
Surface Recommendation:	Hard Floors, Tile, Wood, Laminate, Marble

Basic parameters



Product Specifications

Model	Redroad CM17
Host voltage rating	14.8V
Power	50W
Charger input	100-240V, 50/60HZ
Charger output	18V-420mA
Cell/battery capacity	2200mAh/4 cells
Water tank capacity	150ml
Wet mopping time	30min
Dry mopping time	50min
Net weight	2.90kg

Image: A visual representation of the Redroad CM17’s dimensions and key product specifications.

9. WARRANTY AND SUPPORT

Redroad products are manufactured to the highest quality standards. This product comes with a standard manufacturer's warranty. For detailed warranty information, please refer to the warranty card included with your purchase or visit the official Redroad website.

If you encounter any issues or have questions regarding your Redroad CM17 Cordless Electric Spin Mop, please contact Redroad Customer Support through their official website or the contact information provided in your product packaging. Please have your model number (CM17) and purchase details ready when contacting support.

You can visit the Redroad Store on Amazon for more information: [Redroad Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question