

[manuals.plus](#) /

› [Smeg](#) /

› [Smeg CJF11 Citrus Juicer Instruction Manual \(Pastel Blue\)](#)

Smeg CJF11PBUS

Smeg CJF11 Citrus Juicer Instruction Manual

MODEL: CJF11PBUS (PASTEL BLUE)

1. Introduction

This manual provides detailed instructions for the safe and efficient use, setup, operation, and maintenance of your Smeg CJF11 Citrus Juicer. Designed for extracting juice from citrus fruits such as oranges, lemons, and limes, this appliance combines functionality with a distinctive aesthetic. Please read all instructions carefully before first use and retain this manual for future reference.



Figure 1: Smeg CJF11 Citrus Juicer (Pastel Blue)

2. Safety Information

To ensure safe operation, always follow these basic safety precautions:

- Read all instructions before using the appliance.
- Do not immerse the motor base in water or other liquids.
- Keep hands and utensils away from moving parts during operation.
- Unplug the juicer from the outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- This appliance is for household use only.

3. Components

Familiarize yourself with the parts of your Smeg Citrus Juicer:

1. Dust Cover (transparent lid)

2. Stainless Steel Reamer
3. Stainless Steel Strainer
4. Juice Collector (BPA-free Tritan™)
5. Anti-drip Spout
6. Motor Base (die-cast aluminum)
7. Power Cord with integrated storage



Figure 2: Top view of the juicer showing the reamer and strainer.



Figure 3: Side view of the juicer highlighting the anti-drip spout.

4. Setup

Before first use, ensure all packaging materials are removed. Wash all removable parts (dust cover, reamer, strainer, juice collector) in warm soapy water, rinse thoroughly, and dry completely. Wipe the motor base with a soft, damp cloth.

To assemble:

1. Place the juice collector onto the motor base.
2. Insert the stainless steel strainer into the juice collector.
3. Place the stainless steel reamer onto the central shaft of the motor base, ensuring it is securely seated.

4. The dust cover can be placed on top when the juicer is not in use.

5. Operating Instructions

The Smeg CJF11 Citrus Juicer features an automatic start/stop system and an anti-drip spout for convenient juicing.

1. Ensure the juicer is properly assembled and plugged into a 120V power outlet.
2. Cut your citrus fruit (lemons, limes, oranges, grapefruits) in half.
3. Place a glass or container under the anti-drip spout. Ensure the spout is in the downward position to allow juice to flow.
4. Place a fruit half onto the reamer and apply gentle downward pressure. The reamer will automatically begin to rotate, extracting juice.
5. Continue rotating the fruit on the reamer until all juice is extracted.
6. To stop the juice flow, simply lift the fruit from the reamer. The motor will stop automatically. To temporarily stop juice flow from the spout, push the spout upwards. Push it down again to resume flow.
7. Repeat the process for additional fruit halves.

Your browser does not support the video tag.

Video 1: This video demonstrates the assembly, juicing process, and the functionality of the anti-drip spout and universal reamer of the Smeg Citrus Juicer.

6. Cleaning and Maintenance

Proper cleaning and maintenance will extend the life of your juicer.

- **Motor Base:** Wipe the motor base clean with a soft, damp cloth. Do not immerse the motor base in water.
- **Removable Parts:** The reamer, dust cover, strainer, and juice collector are dishwasher safe. For manual cleaning, wash in warm soapy water, rinse thoroughly, and dry completely.
- **Storage:** Thoroughly dry all components before storing. Use the dust cover to keep the juicer clean when not in use. The power cord can be coiled and stored neatly underneath the motor base.

Your browser does not support the video tag.

Video 2: This video illustrates the cleaning process for the removable parts and demonstrates the integrated cord storage feature on the base of the juicer.

7. Troubleshooting

If your juicer is not operating as expected, consider the following:

- **Juicer not turning on:** Ensure the power cord is securely plugged into a working outlet. Check that the reamer and strainer are correctly seated on the motor base. The juicer activates upon downward pressure on the reamer.
- **Juice not flowing:** Verify that the anti-drip spout is in the downward position. Ensure there is no pulp blockage in the strainer or spout.
- **Excessive pulp:** The strainer is designed to separate pulp. If you prefer less pulp, you may need to clean the strainer more frequently during extended juicing sessions.

8. Specifications

Feature	Detail
Brand	Smeg
Model Name	Smeg Citrus Juicer
Item Model Number	CJF11PBUS
Color	Pastel Blue
Product Dimensions	8"D x 7"W x 11"H
Item Weight	6 pounds
Material	Plastic, Stainless Steel (Die-cast aluminum base, Tritan™ lid and juicing bowl)
Maximum Power	80 Watts
Power Source	Corded Electric
Voltage	120 Volts
Number of Speeds	1
Special Features	Cord Storage, Easy to Clean, Manual (assisted), Pulp Control

9. Warranty and Support

Smeg appliances typically come with a standard manufacturer's warranty. Please refer to the warranty card included with your product for specific terms and conditions, including coverage duration and how to register your product. For technical support, spare parts, or warranty claims, please contact Smeg customer service through their official website or the contact information provided in your product packaging.