

[manuals.plus](#) /

› [RAYMOND WEIL](#) /

› [RAYMOND WEIL Tango Classic Women's Watch, Quartz, Lavender Dial, Indexes, Stainless Steel Bracelet, 30mm \(Model: 5960-ST-46001\) User Manual](#)

RAYMOND WEIL 5960-ST-46001

RAYMOND WEIL Tango Classic Women's Watch User Manual

Model: 5960-ST-46001

Brand: RAYMOND WEIL

1. INTRODUCTION

Thank you for choosing the RAYMOND WEIL Tango Classic Women's Watch, Model 5960-ST-46001. This timepiece is a testament to Swiss horological excellence, combining elegant design with precise quartz movement. This manual provides essential information for the proper setup, operation, maintenance, and care of your watch to ensure its longevity and optimal performance.





Figure 1.1: Front view of the RAYMOND WEIL Tango Classic Women's Watch. This image displays the watch's lavender dial, stainless steel case, and ergonomic 5-row stainless steel bracelet.

2. PRODUCT FEATURES

- **Case:** 30mm stainless steel case with a bezel enlivened with six screws and crown protectors.
- **Bracelet:** Ergonomic 5-row stainless steel bracelet for comfort and style.
- **Crystal:** Scratch-resistant sapphire crystal protecting the dial.
- **Dial:** Lavender dial with a sunray finish, featuring slim baton indexes and a date window at 3 o'clock.
- **Hands:** Hour and minute hands treated with Super-LumiNova® for enhanced readability in low-light conditions. Includes a central seconds hand.
- **Crown:** Screwed-down crown featuring the RW monogram.
- **Water Resistance:** Water resistant up to 100 meters (330 feet), suitable for swimming and showering.
- **Movement:** Reliable Quartz movement.



Figure 2.1: Detailed front view of the watch, showcasing the lavender dial with sunray finish, luminous hands, and date window.

3. SETUP AND INITIAL OPERATION

3.1 Setting the Time

1. Gently pull the crown (located on the right side of the watch case) out to position 2. You may feel a slight click.
2. Rotate the crown clockwise or counter-clockwise to set the hour and minute hands to the desired time.
3. Once the time is set, push the crown back into position 0 (original position) to engage the movement and start the watch. Ensure the crown is fully screwed down to maintain water resistance.

3.2 Setting the Date

1. Gently pull the crown out to position 1. This is typically a half-pull from the fully pushed-in position.
2. Rotate the crown clockwise to advance the date. Do not attempt to set the date between 9 PM and 3 AM, as this can damage the movement. If the current time falls within this period, first adjust the time outside this window, then set

the date, and finally reset the time.

3. Once the date is set, push the crown back into position 0. Ensure the crown is fully screwed down.





Figure 3.1: Side view of the watch, illustrating the crown and its position for adjustments.

4. OPERATING YOUR WATCH

4.1 Daily Wear

Your RAYMOND WEIL Tango Classic watch is designed for daily wear. The stainless steel bracelet is durable and comfortable. Ensure the clasp is securely fastened to prevent accidental loss.

4.2 Water Resistance

This watch is water resistant up to 100 meters (10 ATM / 330 feet). This rating means it is suitable for swimming, showering, and general water activities. However, it is not designed for scuba diving. Always ensure the crown is fully screwed down before exposing the watch to water. Do not operate the crown or pushers (if any) while the watch is wet or submerged.

5. MAINTENANCE AND CARE

5.1 Cleaning

To maintain the appearance of your watch, clean the case and bracelet regularly with a soft, damp cloth. For stainless steel, a mild soap solution can be used, followed by thorough rinsing with clean water and drying with a soft, lint-free cloth. Avoid using harsh chemicals or abrasive materials.

5.2 Battery Replacement

As a quartz watch, your timepiece is powered by a battery. The battery life typically ranges from 2 to 5 years, depending on usage. When the battery needs replacement, it is highly recommended to have it done by an authorized RAYMOND WEIL service center or a qualified watchmaker. This ensures proper sealing for water resistance and prevents damage to the delicate internal components.

5.3 Storage

When not wearing your watch, store it in a cool, dry place, away from direct sunlight, extreme temperatures, and strong magnetic fields. The original watch box is ideal for storage.



Figure 5.1: Illustration of a watch movement, emphasizing the precision and care required for internal maintenance.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch stops or runs intermittently.	Low or dead battery.	Replace the battery at an authorized service center.
Date does not change at midnight.	AM/PM setting is incorrect.	Advance the time by 12 hours.
Condensation under the crystal.	Loss of water resistance due to impact or aging seals.	Immediately take the watch to an authorized service center for inspection and repair. Do not expose to water.
Bracelet feels too tight or too loose.	Incorrect sizing.	Visit a jeweler or authorized service center to adjust the bracelet links.

7. SPECIFICATIONS

Feature	Detail
Model Number	5960-ST-46001
Case Diameter	30 mm
Case Material	Stainless Steel
Movement Type	Quartz

Feature	Detail
Dial Color	Lavender
Crystal	Sapphire
Water Resistance	100 meters (10 ATM / 330 feet)
Bracelet Material	Stainless Steel
Luminescence	Super-LumiNova® on hands





Figure 7.1: Rear view of the watch, displaying the engraved case back with model information and water resistance rating.

8. WARRANTY AND SUPPORT

Your RAYMOND WEIL Tango Classic watch is covered by a manufacturer's warranty against defects in materials and workmanship. Please refer to the warranty card included with your purchase for specific terms and conditions, including the warranty period and coverage details.

For warranty service, repairs, or any technical assistance, please contact an authorized RAYMOND WEIL service center. You can find a list of authorized service centers on the official RAYMOND WEIL website or by contacting their customer service.

RAYMOND WEIL Official Website: www.raymond-weil.com

It is recommended to keep your proof of purchase and warranty card in a safe place.

© 2024 RAYMOND WEIL. All rights reserved.

This manual is for informational purposes only and may be subject to change without notice.

Related Documents - 5960-ST-46001

	<p><u>RAYMOND WEIL Self-Winding Mechanical Watch with Date: Instructions for Use and Warranty Information</u></p> <p>Comprehensive guide for RAYMOND WEIL self-winding mechanical watches with date, covering operation, care, and warranty details. Learn how to set the time and date, maintain your watch, and understand its guarantee.</p>
	<p><u>Raymond Weil Self-Winding Mechanical Watch with Moon Phase and Date: Instructions for Use</u></p> <p>Official instructions for use for the Raymond Weil self-winding mechanical watch featuring moon phase and date complications. Includes details on operation, settings, care, and warranty.</p>

	<p>Raymond Weil Manual Winding Mechanical Watch: Instructions for Use, Care, and Warranty</p> <p>Comprehensive guide for Raymond Weil manual winding mechanical watches, covering setup, operation, maintenance, and warranty details. Learn how to wind, set time, care for your timepiece, and understand its guarantee.</p>
	<p>Raymond Weil Millésime Collection Review: Timeless Design and Value</p> <p>An in-depth review of the Raymond Weil Millésime watch collection, exploring its design, craftsmanship, value, and appeal to watch enthusiasts. Features detailed specifications and analysis.</p>