

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [sixthreezero](#) /

› [sixthreezero EVRYjourney Women's Beach Cruiser Bike User Manual](#)

sixthreezero EVRYjourney Women's Beach Cruiser Bike, Step-Through Touring Hybrid Bicycle

sixthreezero EVRYjourney Women's Beach Cruiser Bike User Manual

Your guide to assembly, operation, maintenance, and care for your sixthreezero EVRYjourney bike.

PRODUCT OVERVIEW

The sixthreezero EVRYjourney Women's Beach Cruiser Bike is designed for maximum comfort and versatile riding. Its low center of gravity and foot-forward design promote an upright posture while ensuring proper leg extension for efficient pedaling. This hybrid cruiser is suitable for various terrains, from beach cruising to trail riding.

Brand: sixthreezero

Model: EVRYjourney Women's Beach Cruiser Bike, Step-Through Touring Hybrid Bicycle



Image: The sixthreezero EVRYjourney Women's Beach Cruiser Bike, showcasing its cream frame, brown seat, and brown grips.

SETUP AND ASSEMBLY

The sixthreezero EVRYjourney bike comes approximately 80% assembled. While many components are pre-assembled, some final assembly and adjustments are required to ensure safe and optimal operation. It is recommended to carefully follow the included instructions for each step.

Key Assembly Steps:

- **Handlebar Installation:** Securely attach the handlebars to the stem, ensuring they are aligned and tightened to the specified torque.
- **Front Wheel Attachment:** Install the front wheel, making sure the quick-release skewer (if applicable) is correctly positioned and tightened. Verify that all bearings are present and properly seated for smooth wheel rotation.
- **Pedal Installation:** Attach the pedals, noting that pedals are typically left and right specific (often marked L and R). Thread them carefully to avoid cross-threading.
- **Seat Post and Saddle Adjustment:** Insert the seat post into the frame and adjust the saddle height for

comfortable and proper leg extension. The foot-forward design allows riders to place their feet flat on the ground while seated.

- **Fender and Rack Attachment:** Install the front and rear fenders, and the rear cargo rack. Ensure all mounting points are secure.
- **Brake and Gear Adjustment:** Fine-tune the front and rear handbrakes for responsive stopping power. Adjust the Shimano 7-speed external derailleur to ensure smooth and precise gear changes across all speeds.

For detailed visual guidance, please refer to the official assembly videos provided by [sixthreezero](#). If you encounter any difficulties, it is advisable to consult a professional bike mechanic.



Image: A rider enjoying the bike, highlighting the comfortable upright riding position.

OPERATING YOUR EVRYJOURNEY BIKE

The EVRYjourney is designed for ease of use and comfort, making it ideal for leisure rides, commuting, and touring. Its 7-speed external derailleur system provides versatility for various terrains and inclines.

Riding Position:

The bike's foot-forward seat and pedal positioning allow for an upright, heads-up riding posture. This design enables riders of varying heights to comfortably place their feet flat on the ground when stopped, without dismounting from the saddle. This enhances stability and confidence, especially in urban environments or during frequent stops.

Gear Shifting:

The Shimano 7-speed external derailleur system offers a wide range of gears for different riding conditions. Use the trigger shifter on the handlebars to smoothly transition between gears. Lower gears (1-3) are suitable for climbing hills or riding against strong headwinds, while higher gears (5-7) are for faster speeds on flat terrain. Practice shifting to find the most efficient gear for your current speed and incline.

Braking:

The bike is equipped with front and rear handbrakes. Apply both brakes simultaneously and smoothly to slow down or stop. Avoid sudden, forceful braking, especially with only the front brake, as this can lead to instability. Ensure brake levers are easily accessible and provide firm, consistent stopping power.

Tire Pressure:

Maintain proper tire pressure for optimal performance and comfort. The 2-inch wide whitewall semi-slick tires provide a cushioned ride. Refer to the tire sidewall for the recommended PSI (Pounds per Square Inch) range. Regularly check tire pressure before rides.



Image: A woman walking her sixthreezero EVRYjourney bike, highlighting its stylish design.

Official Product Videos:

sixthreezero EVRYjourney Women's Step-Through Hybrid Alloy Beach Cruiser Bicycle Overview

Your browser does not support the video tag.

Video: This video provides a comprehensive overview of the sixthreezero EVRYjourney Women's Step-Through Hybrid Alloy Beach Cruiser Bicycle, highlighting its features and design for both 24-inch and 26-inch models.

sixthreezero EVRYjourney Women's 7-Speed Step-Through Hybrid Cruiser Bicycle Features

Your browser does not support the video tag.

Video: This video details the specific features of the sixthreezero EVRYjourney Women's 7-Speed Step-Through Hybrid Cruiser Bicycle, focusing on its 26-inch wheels and 17.5-inch frame.

MAINTENANCE AND CARE

Regular maintenance ensures the longevity and safe operation of your sixthreezero EVRYjourney bike. Perform these checks periodically:

- **Tire Pressure:** Check tire pressure before each ride and inflate to the recommended PSI found on the tire sidewall.
- **Brakes:** Test brakes before each ride. Ensure they engage smoothly and stop the bike effectively. Adjust brake cables if levers feel too loose or too tight.
- **Chain Lubrication:** Lubricate the chain regularly, especially after riding in wet conditions or every few weeks with regular use. This prevents rust and ensures smooth pedaling.
- **Cleaning:** Clean your bike regularly with mild soap and water. Avoid high-pressure washers, which can damage bearings. Dry thoroughly to prevent rust.
- **Nut and Bolt Check:** Periodically check all nuts and bolts for tightness, especially on the wheels, handlebars, seat post, and crank arms. Loose components can affect safety and performance.
- **Bearing Inspection:** Listen for any unusual noises from the wheels or pedals, which could indicate worn or improperly lubricated bearings. Address these promptly to prevent further damage.



Image: The bike positioned on a scenic overlook, emphasizing its suitability for various adventures.

TROUBLESHOOTING COMMON ISSUES

This section addresses common issues you might encounter with your EVRYjourney bike. For complex problems, professional assistance is recommended.

Loose or Noisy Bearings:

If you hear grinding or clicking noises from the wheels, or if the wheels feel wobbly, it may indicate loose or missing ball bearings in the wheel hubs. This can sometimes occur if the bike was previously assembled incorrectly or if parts were missing upon arrival. Inspect the wheel hubs for any missing ball bearings or overly tightened components. Proper adjustment and lubrication of bearings are crucial for smooth operation and safety. If a ball bearing is missing, it must be replaced before riding.

Brake Issues:

- **Brakes not engaging:** Check brake cable tension. Adjust the barrel adjuster on the brake lever or caliper to increase tension. Ensure brake pads are making full contact with the rim.
- **Squealing brakes:** Clean rims and brake pads. Ensure pads are aligned correctly and not rubbing on the tire.

Gear Shifting Problems:

- **Gears not shifting smoothly:** Check derailleur alignment and cable tension. The chain might also need lubrication or cleaning.
- **Chain slipping:** This could be due to a worn chain, worn cogs, or incorrect derailleur adjustment.

Reflector Damage:

If a reflector is broken or missing, it should be replaced immediately for safety, especially when riding in low light conditions. Reflectors are essential for visibility to others.



Image: Rear view of the bike, highlighting the rear rack and fenders.

PRODUCT SPECIFICATIONS

Feature	Detail
Bike Type	Cruiser Bike
Age Range	Adult
Brand	sixthreezero
Number of Speeds	7
Color	Cream w/Brown Seat/Grips

Feature	Detail
Wheel Size	26 Inches
Frame Material	Aluminum
Suspension Type	Rigid
Special Features	Rear Rack, Aluminum Frame
Included Components	Cargo Rack
Brake Style	Hand brakes
Item Weight	18 Kilograms
Model Name	EVRYjourney Women's Beach Cruiser Bike, Step-Through Touring Hybrid Bicycle
UPC	610395713135

WARRANTY AND SUPPORT

Manufacturer's Warranty:

The sixthreezero EVRYjourney bike comes with a 365 Day Manufacturer Warranty. Please note that this warranty does not include returns; returns are subject to Amazon's 30 Day return policy.

Customer Support:

For product support, assembly assistance, or warranty claims, please visit the official sixthreezero store or contact their customer service directly. Many common assembly questions can be answered by referring to the detailed instructions or online resources provided by the manufacturer.

Visit the [sixthreezero Store on Amazon](#).

© 2024 sixthreezero. All rights reserved.

Related Documents - EVRYjourney Women's Beach Cruiser Bike, Step-Through Touring Hybrid Bicycle

	<p>Sixthreezero Easy Boarding E-Bike Assembly Guide</p> <p>Comprehensive assembly guide for the Sixthreezero Easy Boarding E-Bike, covering all steps from unboxing to final checks. Includes helpful tips and contact information for support.</p>
---	---

	<p><u>Cateye Kosmos CC-ST300 Cyclocomputer Operating Instructions</u></p> <p>Comprehensive operating manual for the Cateye Kosmos CC-ST300 bicycle computer, detailing setup, button functions, mounting, troubleshooting, maintenance, specifications, and warranty information.</p>
	<p><u>MOONCOOL Electric Tricycle Assembly Manual - Step-by-Step Guide</u></p> <p>Detailed assembly manual for MOONCOOL electric tricycles. Learn how to assemble, connect circuits, operate, and maintain your electric tricycle with this comprehensive guide.</p>
	<p><u>SPEEDFUN FURIOUS EVO for TQ HPR50 Installation and User Manual</u></p> <p>Comprehensive guide for installing and using the SPEEDFUN FURIOUS EVO module with TQ HPR50 e-bike motors. Learn how to bypass speed limits and activate/deactivate features.</p>
	<p><u>SpeedFun Furious EVO for Bafang M200/M410: Installation and User Manual</u></p> <p>This manual provides installation and usage instructions for the SpeedFun Furious EVO speed unlocking device, compatible with Bafang M200 and M410 e-bike motors. Learn how to activate, deactivate, and use different versions of the device, along with important safety and legal information.</p>
	<p><u>NAKTO ELECTRIC BICYCLE LCD-M5 Display Control Panel Instruction Manual</u></p> <p>Comprehensive guide to the NAKTO ELECTRIC BICYCLE LCD-M5 display control panel, covering features, wiring, settings, and button operations for e-bike users.</p>