

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [VGR](#) /

> [VGR V-340 Professional Foil Shaver User Manual](#)

VGR V-340

VGR V-340 Professional Foil Shaver User Manual

Model: V-340

INTRODUCTION

This manual provides comprehensive instructions for the safe and effective use of your VGR V-340 Professional Men's Rechargeable Electric Foil Shaver. Please read this document thoroughly before initial use and retain it for future reference.

IMPORTANT SAFETY INFORMATION

- Do not immerse the charging cable or power adapter in water.
- This appliance is IPX7 waterproof and can be used in the shower. However, ensure the charging port is completely dry before connecting the charger to prevent electrical hazards.
- Keep the shaver out of reach of children.
- Do not attempt to disassemble or repair the shaver yourself. Contact authorized customer support for any servicing needs.
- Use only the charging cable provided with the shaver.
- Avoid using the shaver on irritated, damaged, or broken skin. Consult a dermatologist if you experience persistent skin irritation.
- Do not expose the shaver to extreme temperatures or direct sunlight for prolonged periods.

PACKAGE CONTENTS

Verify that all the following items are included in your package:

- 1x VGR V-340 Men's Shaver
- 1x Magnetic Protection Cap
- 1x Type-C Charging Cable
- 1x User Manual
- 1x Travel Pouch



The image displays all items included in the package: the VGR V-340 shaver in blue, a Type-C charging cable, a small cleaning brush, and a soft grey travel pouch for convenient storage and transport.

PRODUCT FEATURES

- **Triple Floating Blades:** Engineered to provide a smooth, close shave with minimal passes.
- **600mAh Lithium Battery:** Offers up to 60 minutes of continuous cordless operation on a single charge.
- **Fast Type-C Charging:** Achieves a full charge in approximately 1.5 hours for quick readiness.
- **IPX7 Waterproof:** Designed for both wet and dry shaving, and fully washable for easy cleaning.
- **Ergonomic Design:** Provides a comfortable and secure grip for precise control during shaving.
- **Travel Lock Feature:** Prevents accidental activation of the shaver when stored or during travel.
- **Compact & Lightweight:** Weighs only 150 grams, making it ideal for travel and daily use.
- **Metal Shaver Head:** Constructed for durability and efficient, long-lasting performance.
- **Powerful Motor:** Ensures consistent cutting power for an effective and smooth grooming experience.



 **PRECISION BLADES**

Precision cutting system shavers even the shortest stubble

 **IPX7 WATERPROOF**

Fully body washable, convenient clean

 **LONGER WORK TIME**

Rechargeable Li-ion battery 5V 600mAh, longer service time than similar products.

 **ON/OFF BUTTON**

Easy to operate, convenient and practical

An infographic detailing the VGR V-340's main features: precision cutting blades for short stubble, IPX7 full body washability, a 600mAh rechargeable Li-ion battery for extended use, and a simple on/off button for convenient operation.

SETUP AND FIRST USE

Charging the Shaver

1. Ensure the shaver is turned off before charging.
2. Connect the provided Type-C charging cable to the shaver's charging port.
3. Connect the other end of the cable to a compatible USB power adapter (not included) or a computer USB port.
4. The charging indicator light will illuminate, indicating that charging is in progress. A full charge typically takes approximately 1.5 hours.
5. Once fully charged, disconnect the charging cable from both the shaver and the power source.



Palm size



Storage bag



ON/OFF button




A close-up view of the VGR V-340 shaver's Type-C charging port with the cable connected. Text overlays indicate a 1.5-hour charge time for 60 minutes of operation.

OPERATING INSTRUCTIONS

Shaving

1. **Preparation:** For optimal results, ensure your skin is clean. For wet shaving, apply a thin layer of shaving foam or gel to the area.
2. **Power On:** Press the power button located on the shaver to turn it on.
3. **Shaving Technique:** Hold the shaver at a right angle (90 degrees) to your skin. Move the shaver in short, gentle circular motions or straight strokes against the direction of hair growth. Use your free hand to stretch the skin, allowing the blades to capture hairs more effectively for a closer shave.
4. **Wet or Dry Use:** The IPX7 waterproof rating allows for comfortable and convenient wet or dry shaving, depending on your preference.
5. **Power Off:** After completing your shave, press the power button again to turn off the shaver.



This image provides a detailed view of the shaver head, highlighting the triple floating blades and the protective foil designed for a close and comfortable shave.

MAINTENANCE AND CLEANING

Daily Cleaning

1. Ensure the shaver is turned off before cleaning.
2. Remove the magnetic protection cap from the shaver head.
3. Rinse the shaver head thoroughly under running water to remove all hair clippings and residue. The shaver's IPX7 rating allows for full washability.
4. For a more comprehensive clean, use the provided cleaning brush to dislodge any stubborn hairs from the blades and foil.
5. Allow the shaver head to air dry completely before reattaching the magnetic cap.

Blade Care

To maintain optimal shaving performance and hygiene, it is recommended to replace the shaver foil and blades every 12

months, or sooner if you observe a noticeable decrease in shaving efficiency or experience discomfort during use.



The image shows two VGR V-340 shavers, one blue and one black, partially submerged in water, illustrating the product's IPX7 waterproof rating, making it suitable for wet use and easy cleaning.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted.	Charge the shaver for approximately 1.5 hours.
Shaver does not turn on.	Travel lock is activated.	Press and hold the power button for 3 seconds to deactivate the travel lock.
Poor shaving performance (e.g., not cutting effectively).	Blades or foil are dull or dirty with hair clippings.	Clean the shaver head thoroughly. If performance does not improve, consider replacing the shaver foil and blades.
Shaver pulls hair or causes discomfort.	Battery is low, reducing motor speed.	Charge the shaver fully.
Shaver pulls hair or causes discomfort.	Blades or foil are damaged or worn.	Inspect the shaver head for any visible damage. Replace the shaver foil and blades if necessary.

SPECIFICATIONS

- **Model:** V-340
- **Battery Type:** 600mAh Lithium-ion
- **Charging Time:** Approximately 1.5 hours
- **Operating Runtime:** Up to 60 minutes on a full charge
- **Waterproof Rating:** IPX7 (fully washable)
- **Power Source:** Battery Powered
- **Item Weight:** 150 grams
- **Product Dimensions (LxWxH):** 8 x 6 x 3 Centimeters
- **Blade Material:** Stainless Steel
- **Included Components:** Shaver, Magnetic Cap, Type-C Charging cable, User manual, Travel pouch

WARRANTY AND SUPPORT

The VGR V-340 Professional Foil Shaver is covered by a **1-Year Warranty** from the original date of purchase. This warranty covers manufacturing defects under normal use.

For warranty claims, technical assistance, or any product-related inquiries, please contact VGR customer service using the details below:

- **Email:** customercare@vgrofficial.in
- **Phone:** 18002578939
- **Website:** www.vgrofficial.in
- **Operating Hours:** 10:00 AM to 6:00 PM, Monday to Saturday

Please have your proof of purchase and product model number (V-340) ready when contacting support.