

## Gelbee Storm Burst Glow

# Gelbee Storm Burst Glow Water Bead Blaster Instruction Manual

## IMPORTANT SAFETY INFORMATION

---

**WARNING: NOT A TOY. ADULT SUPERVISION REQUIRED. MISUSE OR CARELESS USE MAY CAUSE SERIOUS INJURY, ESPECIALLY TO THE EYE. EYE PROTECTION MUST BE USED BY THE USER AND ANY PERSON WITHIN RANGE. BE CAREFUL, SHOOT SAFELY.**

This product is intended for users aged 14 years and up. Always wear the provided safety glasses during operation. Ensure all individuals in the vicinity are also wearing eye protection. Do not aim at people or animals. Read and understand all instructions before use.

## PACKAGE CONTENTS

---

Verify that all items listed below are present in your package:

- Gelbee Storm Burst Glow Water Bead Blaster
- Rechargeable Battery
- USB Charging Cable
- Safety Glasses
- Starter Pack of Glow-in-the-Dark Water Beads
- Modular Attachments (Rear Stock, Front Barrel, etc.)



Image: Front view of the Gelbee Storm Burst Glow Water Bead Blaster retail packaging, showing the blaster and key features.

## SETUP

---

### 1. Prepare Water Beads

1. Open the starter pack of glow-in-the-dark water beads.
2. Place the beads in a container with a generous amount of water.
3. Allow the beads to soak for at least 4 hours, or until they have expanded approximately 20 times their original size. They should be soft and squishy.
4. Drain any excess water before loading the beads into the blaster.

### 2. Charge the Battery

1. Locate the rechargeable battery and the USB charging cable.
2. Connect the battery to the USB charging cable.
3. Plug the USB cable into a compatible USB power source (e.g., wall adapter, computer USB port).
4. Allow the battery to charge fully. The indicator light on the charger will change color (e.g., red to green) when charging is complete.
5. Once charged, disconnect the battery from the charger.

### 3. Assemble the Blaster

The Gelbee Storm Burst Glow Blaster features a modular design, allowing for various configurations. Refer to the diagram below for assembly guidance.



Image: Rear view of the Gelbee Storm Burst Glow Water Bead Blaster retail packaging, illustrating the modular components and their assembly points.

- Attach the desired rear stock by sliding it onto the back of the main unit until it clicks into place.
- Attach the desired front barrel by sliding it onto the front of the main unit until it is securely fastened.
- Insert the charged battery into the designated battery compartment, ensuring correct polarity.

## OPERATING INSTRUCTIONS

### 1. Load Water Beads

1. Ensure the blaster is powered off.
2. Open the water bead reservoir (hopper) on top of the blaster.
3. Carefully pour the prepared, expanded water beads into the reservoir. Do not overfill.
4. Close the reservoir securely.

### 2. Power On and Select Mode

1. Put on your safety glasses. Ensure anyone nearby also wears eye protection.
2. Locate the power switch and turn the blaster ON.
3. The blaster operates in full-auto mode, capable of firing up to 11 beads per second.

### 3. Firing

1. Aim the blaster at a safe target. Never aim at people or animals.
2. Press and hold the trigger to fire water beads.
3. Release the trigger to stop firing.

### 4. Glow-in-the-Dark Feature

The Gelbee Storm Burst Glow Blaster and its water beads are designed to glow in low-light conditions. For optimal glow, expose the blaster and beads to light before use in the dark.



Image: The Gelbee Storm Burst Glow Water Bead Blaster illuminated in a dark environment, showcasing its glow-in-the-dark capabilities.

## MAINTENANCE

---

- **Cleaning:** After each use, ensure the blaster is powered off and the battery is removed. Empty any remaining water beads from the reservoir. Wipe down the exterior of the blaster with a damp cloth. Do not submerge the blaster in water.
- **Storage:** Store the blaster in a cool, dry place away from direct sunlight. Remove the battery if storing for extended periods. Ensure all water beads are removed from the blaster before storage.
- **Battery Care:** Recharge the battery regularly, even if not in use, to maintain its lifespan. Do not overcharge or leave unattended while charging.

## TROUBLESHOOTING

---

- **Blaster Not Firing:**
  - Check if the battery is fully charged and correctly inserted.
  - Ensure the power switch is in the ON position.
  - Verify that water beads are properly loaded and not jammed.
- **Beads Not Feeding:**
  - Ensure water beads are fully expanded and not too small or too large.
  - Check for any obstructions in the feeding mechanism.
  - Shake the blaster gently to help beads settle into the feed port.
- **Weak Firing Power:**
  - Recharge the battery. A low battery can reduce performance.
  - Ensure beads are properly hydrated; under-hydrated beads can affect velocity.

## SPECIFICATIONS

---

<b>Model:</b>	Storm Burst Glow
<b>Brand:</b>	Gelbee

<b>ASIN:</b>	B0D383ZTCG
<b>Product Dimensions:</b>	2.6 x 10.8 x 29.75 inches
<b>Recommended Age:</b>	14 years and up
<b>Max Velocity:</b>	Up to 240 feet per second (FPS)
<b>Rate of Fire:</b>	Up to 11 beads per second (full-auto)
<b>Special Features:</b>	Glow-in-the-dark, Modular Design

## **WARRANTY AND SUPPORT**

---

For warranty information or technical support, please refer to the manufacturer's official website or contact Gelbee customer service directly. Keep your purchase receipt as proof of purchase.

Manufacturer: Gelbee