

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [JUQITECH](#) /

› [JUQITECH Samsung Galaxy Tab S8 S7 Keyboard Case and Screen Protector User Manual](#)

JUQITECH Samsung Galaxy Tab S8 11" (SM-X700/SM-X706), Samsung Galaxy Tab S7 11" (SM-T870/SM-T875/SM-T876)

JUQITECH Samsung Galaxy Tab S8 S7 Keyboard Case and Screen Protector User Manual

Model: Galaxy Tab S8 11" (SM-X700/SM-X706), Galaxy Tab S7 11" (SM-T870/SM-T875/SM-T876)

Brand: JUQITECH

INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your JUQITECH Trackpad Backlit Keyboard Case and 2 Pack Screen Protector. This product is designed for use with Samsung Galaxy Tab S8 11-inch (2022 models SM-X700 / SM-X706) and Samsung Galaxy Tab S7 11-inch (2020 models SM-T870 / SM-T875 / SM-T876). Please ensure your tablet model is compatible before proceeding.

PRODUCT OVERVIEW

Components Included

- JUQITECH Trackpad Backlit Keyboard Case
- Detachable Wireless Keyboard
- 2 Pack Screen Protectors
- USB Cable (for charging the keyboard)

Key Features

- Integrated Trackpad: Multi-touch trackpad for cursor control.
- Backlit Keyboard: 7 colors with 3 brightness levels, including breathing backlit mode.
- Adjustable Kickstand: Allows for viewing angles from 30° to 160°.
- Detachable Design: Keyboard can be separated from the case.
- S Pen Holder: Built-in slot for S Pen storage.
- Screen Protector: 0.3mm ultra-thin, high transparency, S Pen compatible, anti-oil, dust-free, fingerprint-free.
- Durable Materials: Soft TPU case with PU leather exterior.
- Protection: Oil resistance, dustproof, impact resistance, anti-fingerprints, scratch proof, camera protection.

Product Visuals



Figure 1: Overview of the JUQITECH keyboard case with backlit keys and the included screen protectors. The case is shown with a tablet inserted, demonstrating its design and the separate screen protectors.

Focus On Every Details



Oil Resistance



Dustproof



Impact Resistance




Anti-Fingerprints



Scratch Proof



Honeycomb Heat Dissipation



Keyboard Case: 1.11lbs

Keyboard: 0.52lbs

Case: 0.59lbs



Soft TPU



PU Leather Exterior

Figure 2: Detailed view highlighting various features of the case, including oil resistance, dustproof properties, impact resistance, anti-fingerprint coating, scratch proofing, camera protection, built-in S Pen slot, and honeycomb heat dissipation design. Product weights for the keyboard case, keyboard, and case are also indicated.

Detachable Wireless Backlit Keyboard




Figure 3: Illustration of the detachable wireless backlit keyboard, showing full shortcuts, the large click-anywhere trackpad with dimensions, and indicators for turning on/off the touchpad and Bluetooth. The image also depicts the backlit keys, Broadcom 5.2 Bluetooth chip, and the trackpad mechanism.



Figure 4: Image showing the packaging and two screen protectors included with the product, emphasizing their 9H hardness and explosion-proof properties.

SETUP INSTRUCTIONS

1. Installing the Tablet into the Case

1. Gently align your Samsung Galaxy Tab S8 or S7 11-inch tablet with the soft TPU case.
2. Press the tablet firmly into the case, ensuring all corners are securely seated. The case is designed to protect the tablet and provide a stable base for the keyboard.
3. Ensure the camera cutout and S Pen slot are correctly aligned with your tablet's features.

2. Connecting the Wireless Keyboard via Bluetooth

1. **Charge the Keyboard:** Before first use, connect the keyboard to a power source using the provided USB cable. The charging indicator light will show charging status.
2. **Turn On Keyboard:** Locate the power switch on the keyboard and slide it to the "ON" position.
3. **Activate Bluetooth Pairing Mode:** Press the **Fn + C** keys simultaneously on the keyboard. The Bluetooth indicator light will begin to flash, indicating it is in pairing mode.

4. **Enable Bluetooth on Tablet:** On your Samsung Galaxy Tab, go to *Settings > Connected devices > Bluetooth* and turn Bluetooth ON.
5. **Pair Device:** In the list of available Bluetooth devices on your tablet, select "Bluetooth Keyboard" or a similar name.
6. **Confirm Connection:** Once connected, the Bluetooth indicator light on the keyboard will stop flashing and remain solid or turn off, depending on the model. Your tablet will also confirm the connection.

3. Applying the Screen Protector

For optimal results, apply the screen protector in a clean, dust-free environment.

1. **Clean the Screen:** Use the provided cleaning wipes (if included) or a microfiber cloth to thoroughly clean your tablet's screen. Ensure there are no dust particles, smudges, or fingerprints.
2. **Remove Protective Film (Side 1):** Carefully peel off the protective film labeled "1" or "Back" from the screen protector. Avoid touching the adhesive side.
3. **Align and Apply:** Align the screen protector with the edges of your tablet screen, paying attention to cutouts for the camera and sensors. Once aligned, gently lower the protector onto the screen.
4. **Smooth Out Bubbles:** Use a squeegee card (if included) or a soft cloth to gently push out any air bubbles from the center towards the edges.
5. **Remove Protective Film (Side 2):** Once the protector is fully adhered and bubbles are removed, peel off the top protective film labeled "2" or "Front".

High Definition

High definition and light transparency retain original pixels of picture and video



Figure 5: Demonstrates the high definition clarity and light transparency of the screen protector, designed to retain original pixel quality for pictures and videos.

Sensitive Touch

0.33mm ultra-thin thickness to maintain original highly response, ensure sensitive touching



Apple Pencil Compatibility



High Respons



Ultra Sensitive



Figure 6: Illustrates the sensitive touch capability of the 0.33mm ultra-thin screen protector, ensuring original highly responsive touch, Apple Pencil compatibility, and high responsiveness.

S Pen Compatible



Figure 7: Shows the screen protector's compatibility with the S Pen, allowing for smooth and accurate input.

OPERATING INSTRUCTIONS

Using the Keyboard

- **Typing:** Use the keyboard as a standard QWERTY keyboard for typing.
- **Backlight Control:** Press the **Light bulb icon key** (often near the spacebar or function row) to cycle through 7 different backlight colors. Press the **Fn + Light bulb icon key** to adjust the brightness levels (3 levels) or activate the breathing backlit mode.
- **Function Keys:** The top row of keys includes various function shortcuts (e.g., volume control, media playback, screen lock). These are typically accessed by pressing the **Fn** key simultaneously with the desired function key.

Using the Trackpad

- **Cursor Control:** Move your finger across the trackpad surface to control the cursor on your tablet screen.
- **Clicking:** Press down on the trackpad for a left-click action.
- **Right-Click:** Use two fingers to tap the trackpad for a right-click action.

- **Scrolling:** Use two fingers to swipe up or down on the trackpad to scroll through content.
- **Zooming:** Pinch in or out with two fingers to zoom in or out on content.
- **Disable/Enable Trackpad:** Press **Fn + Spacebar** (or a dedicated trackpad icon key) to toggle the trackpad on or off.

Adjusting the Kickstand and Case Usage



Figure 8: Demonstrates the adjustable kickstand, allowing the tablet to be positioned in both landscape and portrait modes to meet various usage needs.

- **Adjusting Angle:** The integrated kickstand allows you to recline the tablet smoothly from 30° to 160°. Adjust the kickstand to your desired viewing or typing angle.
- **Detachable Keyboard:** The keyboard is magnetically attached to the case. You can easily detach it to use the tablet independently or for different viewing modes.
- **Case Modes:** The soft case can be used in various configurations:
 - **Keyboard Mode:** Tablet in case, keyboard attached, kickstand deployed.
 - **Viewing Mode:** Keyboard detached, tablet in case with kickstand deployed for media consumption.
 - **Tablet Mode:** Keyboard detached, case folded back or removed for handheld use.

Detachable Soft Case

Remove keyboard use case adapt to your ever-changing whims and desires



Read

Sketch

Figure 9: Shows the versatility of the detachable soft case, allowing users to remove the keyboard and adapt the case for activities like reading or sketching.

MAINTENANCE

- **Cleaning the Case:** Wipe the exterior of the case with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Cleaning the Keyboard:** Use a soft, dry cloth to wipe the keyboard keys and trackpad. For dust between keys, use compressed air.
- **Cleaning the Screen Protector:** Use a microfiber cloth specifically designed for electronics screens. For stubborn smudges, a small amount of screen cleaner can be applied to the cloth (not directly to the screen).
- **Storage:** When not in use for extended periods, ensure the keyboard is turned off to conserve battery. Store the product in a cool, dry place.

TROUBLESHOOTING

Keyboard Not Connecting via Bluetooth

- **Check Power:** Ensure the keyboard is turned on and fully charged.
- **Re-pair:** Delete the "Bluetooth Keyboard" from your tablet's Bluetooth device list and attempt to re-pair by pressing **Fn + C** on the keyboard.
- **Tablet Bluetooth:** Verify that Bluetooth is enabled on your Samsung Galaxy Tab.
- **Distance:** Ensure the keyboard is within the effective Bluetooth range (typically 10 meters or 33 feet) of your tablet.
- **Interference:** Move away from other devices that might cause wireless interference.

Trackpad Not Responding

- **Check Enable/Disable:** Ensure the trackpad is not disabled. Press **Fn + Spacebar** (or the dedicated trackpad icon key) to toggle its status.
- **Reboot:** Turn the keyboard off and then on again.
- **Clean Trackpad:** Ensure the trackpad surface is clean and free of debris.

Keyboard Backlight Not Working

- **Check Battery:** Low battery can affect backlight functionality. Charge the keyboard.
- **Cycle Backlight:** Press the **Light bulb icon key** to ensure it's not simply turned off or set to a very dim level.

SPECIFICATIONS

Brand	JUQITECH
Compatible Devices	Samsung Galaxy Tab S8 11" (SM-X700/SM-X706), Samsung Galaxy Tab S7 11" (SM-T870/SM-T875/SM-T876)
Connectivity Technology	Bluetooth (Broadcom 5.2)
Keyboard Description	Ergonomic, Backlit, Trackpad
Special Features	Backlit, Trackpad, Adjustable Kickstand, Detachable Keyboard, S Pen Holder
Material	Acrylonitrile Butadiene Styrene (ABS), Soft TPU, PU Leather
Power Source	USB Power (Rechargeable Battery)
Switch Type	Scissor-switch
Screen Protector Thickness	0.3mm
Keyboard Case Weight	1.11 lbs (approx.)
Keyboard Weight	0.52 lbs (approx.)
Case Weight	0.59 lbs (approx.)

WARRANTY AND SUPPORT

For warranty information or technical support, please contact JUQITECH customer service through the retailer where the product was purchased or visit the official JUQITECH website. Keep your purchase receipt as proof of purchase.

Return Policy: This product typically includes a 30-day refund/replacement return policy from the date of purchase. Please refer to the specific return policy of your retailer for details.

© 2024 JUQITECH. All rights reserved.

Samsung Galaxy Tab and S Pen are trademarks of Samsung Electronics Co., Ltd.