

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Tupperware](#) /

› [Tupperware Lunch-It Portion & Go Compact Lunch Box Set \(Model 178376\) Instruction Manual](#)

Tupperware 178376

Tupperware Lunch-It Portion & Go Compact Lunch Box Set

MODEL: 178376

Brand: Tupperware

1. PRODUCT OVERVIEW

The Tupperware Lunch-It Portion & Go Compact Lunch Box Set provides a practical solution for transporting meals. This set includes two lidded containers, each designed with divided compartments to keep different food items separate. The containers feature liquid-tight seals and flexible tabs for easy opening and secure closure. Constructed from durable, dishwasher-safe, and BPA-free materials, these lunch boxes are built for repeated use and easy cleaning.

Key Features:

- Set of two lidded containers with divided compartments.
- Liquid-tight seals to maintain freshness and prevent leaks.
- Flexible seals and large tabs for effortless opening and closing.
- Constructed from sturdy, dishwasher-safe, and BPA-free materials.
- Stackable design for convenient storage.

2. SETUP

Initial Cleaning:

1. Before first use, wash both the containers and lids thoroughly with warm, soapy water.
2. Rinse all components completely to remove any soap residue.
3. Allow to air dry or dry with a clean cloth.

3. OPERATING INSTRUCTIONS

Filling the Container:

1. Open the container by gently lifting the large tab on the lid.
2. Place different food items into the three divided compartments. This helps keep foods separate and organized.

Lunch-It Portion & Go Compact 2 Lunch Box Set

These durable, versatile lunch boxes are smart alternatives to single-use plastic bags.



This image shows the Tupperware Lunch-It Portion & Go Compact Lunch Box filled with various food items, demonstrating its three divided compartments for organized meal packing.

Sealing the Container:

1. Align the lid with the container.
2. Press down firmly on the center of the lid, then work your way around the edges to ensure a complete, liquid-tight seal.
3. Verify the seal by checking that the lid is flush with the container's rim.

**Lock in freshness and flavor with
Tupperware's iconic quality and style.**



Tupperware®

This image demonstrates the process of sealing the lid onto the Tupperware Lunch-It Portion & Go Compact Lunch Box, ensuring freshness and preventing leaks.

Opening the Container:

1. Locate the large tab on the edge of the lid.
2. Gently lift the tab to break the seal and remove the lid.



A top-down view showing two Tupperware Lunch-It Portion & Go Compact Lunch Boxes, each prepared with a distinct meal, showcasing their versatility for various food combinations.

Product Demonstration Video:

Your browser does not support the video tag.

This official video from Tupperware US demonstrates the features and usage of the Lunch-It Portion & Go Compact Lunch Box, including its airtight seal and divided compartments.

4. MAINTENANCE

Cleaning Instructions:

- The Tupperware Lunch-It Portion & Go Compact Lunch Box and its lid are dishwasher safe. Place on the top rack for best results.
- Alternatively, hand wash with warm, soapy water and a soft sponge or cloth.
- Rinse thoroughly and dry completely before storing to prevent odors.
- Avoid using abrasive cleaners or scouring pads, as these can scratch the surface.

5. TROUBLESHOOTING

Lid not sealing properly:

- Ensure the rim of the container and the edge of the lid are clean and free from food particles.
- Press down firmly on the center of the lid, then systematically around the entire perimeter to create a tight seal.
- Check for any warping or damage to the lid or container. If damaged, replacement may be necessary.

Food odors or stains:

- Wash immediately after use to prevent food from drying onto the surface.
- For stubborn odors, try soaking the container in a solution of warm water and baking soda for several hours, then wash as usual.
- For stains, exposure to sunlight can sometimes help reduce discoloration.

6. SPECIFICATIONS



This image illustrates the dimensions of the lunch box: 6.6 inches (16.8 cm) in length, 6.1 inches (15.6 cm) in width, and 1.9 inches (4.8 cm) in height, with a capacity of 550 ml / 2 1/3 cups.

Feature	Detail
Model Number	178376
Material	Polyethylene, Polypropylene (BPA-Free)
Color	Orange/Blue (as per variant)
Capacity	2.3 Cups / 550 ml

Product Dimensions	6.6"L x 6.1"W x 1.9"H (16.8 cm L x 15.6 cm W x 4.8 cm H)
Item Weight	0.26 Kilograms / 9.1 ounces
Number of Compartments	3
Included Components	2 Lids, 2 Containers
Care Instructions	Dishwasher Safe

7. WARRANTY AND SUPPORT

Specific warranty information for this product is not provided in the available data. For details regarding warranty coverage or product support, please refer to the official Tupperware website or contact Tupperware customer service directly.
