

[Manuals.plus](#) /

› [LESIA](#) /

› LESIA F1 Mobile Phone User Manual

LESIA F1 Klapphandy 4G

LESIA F1 Mobile Phone User Manual

Model: F1 Klapphandy 4G

INTRODUCTION

Welcome to the user manual for your new LESIA F1 mobile phone. This phone is specifically designed with ease of use in mind, featuring large buttons, a clear display, and essential functions for seniors. Please read this manual carefully to understand how to operate your device safely and efficiently. Keep this manual for future reference.

PACKAGE CONTENTS

Before you begin, please check the package contents to ensure all items are present:

- LESIA F1 Mobile Phone
- Charging Station (Cradle)
- USB Type-C Charging Cable
- Power Adapter
- User Manual (this document)
- Screen Protector



Figure 1: LESIA F1 Package Contents. This image displays the LESIA F1 flip phone, a screen protector, a charger, a USB Type-C cable, the user manual, and the package box, illustrating all items included in the product package.

PRODUCT OVERVIEW

Familiarize yourself with the various parts of your LESIA F1 phone.





Figure 2: LESIA F1 Phone Closed View. This image shows the LESIA F1 flip phone in its closed position, highlighting its compact design and the external camera lens.



Big Font & Number
Easy to read for senior peoples

Figure 3: LESIA F1 Phone Open View with Large Font. This image displays the LESIA F1 flip phone in its open position, showcasing the large, easy-to-read buttons and the clear display with large font, designed for senior users.

Volume +/-
Convenient & Fast



Torchlight Button
Easy to find and use

Figure 4: LESIA F1 Side Buttons. This image highlights the side-mounted volume control buttons and the dedicated torchlight button on the LESIA F1 phone, indicating their convenient placement.

SOS Emergency Call Button

Your Safe Guard



Support 5 Emergency Contacts

Figure 5: LESIA F1 SOS Button. This image shows the prominent red SOS emergency call button located on the back of the LESIA F1 phone, emphasizing its accessibility for quick assistance.

SETUP

1. Inserting SIM Card and Battery

Your LESIA F1 phone supports dual SIM cards and requires a standard SIM card. Follow these steps to insert the SIM card and battery:

1. Carefully remove the back cover of the phone.
2. If a battery is already installed, remove it.
3. Locate the SIM card slot(s). Insert your SIM card(s) into the designated slot(s) with the gold contacts facing down, ensuring it clicks into place.
4. Insert the provided lithium-ion battery, aligning the contacts correctly.
5. Replace the back cover until it snaps securely.

2. Initial Charging

Before first use, fully charge your phone. The LESIA F1 comes with a convenient charging station.

1. Connect the USB Type-C cable to the power adapter, then plug the adapter into a wall outlet.
2. Connect the other end of the USB Type-C cable to the charging station.
3. Place the LESIA F1 phone into the charging station, ensuring it sits firmly and the charging indicator appears on the screen.
4. Allow the phone to charge until the battery icon indicates a full charge. This typically takes 2-3 hours.



Figure 6: LESIA F1 Phone in Charging Cradle. This image shows the LESIA F1 phone placed in its dedicated charging cradle, illustrating the ease of charging and highlighting various icons representing phone features like flashlight, calculator, speed dial, alarm clock, and SOS settings.

OPERATING INSTRUCTIONS

1. Power On/Off

- **To Power On:** Open the flip cover. Press and hold the red power/end call button (usually marked with a power symbol) until the screen lights up.
- **To Power Off:** Press and hold the red power/end call button until a power-off option appears on the screen. Select "Power Off" using the navigation keys and confirm.

2. Making and Receiving Calls

- **To Make a Call:**

- a. Open the flip cover.
- b. Dial the phone number using the large keypad.
- c. Press the green call button to initiate the call.

- **To Receive a Call:**

- a. When the phone rings, open the flip cover or press the green call button to answer.
- b. To end a call, press the red end call button.

3. Sending and Receiving Messages

Access the messaging menu to compose and read SMS messages.

- Navigate to the "Messages" icon on the main menu.
- Select "Write Message" to compose a new SMS.
- Enter the recipient's number and your message.
- Select "Send" to dispatch the message.

4. Special Features

- **SOS Emergency Call Button:**

The LESIA F1 features a dedicated SOS button on the back of the phone. In an emergency, press and hold this button. The phone will automatically dial up to 5 pre-set emergency contacts and send an emergency text message. Ensure your emergency contacts are properly configured in the phone settings.

SOS Emergency Call Button

Your Safe Guard



Support 5 Emergency Contacts

Figure 7: LESIA F1 SOS Button in Use. This image illustrates the SOS emergency call button on the back of the phone and indicates its ability to support up to 5 emergency contacts, providing a crucial safety feature.

- **Flashlight:**

A convenient flashlight button is located on the side of the phone. Press this button to quickly turn the flashlight on or off, providing illumination in dark environments.



Figure 8: LESIA F1 Torchlight Feature. This image demonstrates the side-button controlled torchlight feature of the LESIA F1 phone, showing a beam of light emanating from the phone's top, useful for dark conditions.

- **Speed Dial (M1/M2 Buttons):**

The M1 and M2 buttons on the keypad can be programmed for quick dialing of frequently used numbers. Refer to the phone's settings menu to assign contacts to these buttons.

- **Volume Control:**

Adjust the call volume and ringtone volume using the dedicated volume +/- buttons located on the side of the phone.

MAINTENANCE

1. Cleaning Your Phone

To keep your LESIA F1 phone in optimal condition:

- Use a soft, lint-free cloth to wipe the screen and body of the phone.
- Avoid using harsh chemicals, cleaning sprays, or abrasive materials.
- Do not expose the phone to excessive moisture.

2. Battery Care

Proper battery care extends the life of your phone's battery:

- Avoid extreme temperatures (very hot or very cold) as they can degrade battery performance.
- Charge the phone regularly, preferably before the battery is completely depleted.
- Use only the original LESIA charger and charging station provided with your phone.

TROUBLESHOOTING

If you encounter issues with your LESIA F1 phone, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Phone does not power on.	Battery is depleted or not inserted correctly.	Charge the phone for at least 30 minutes. Ensure the battery is correctly seated.
Cannot make or receive calls.	No SIM card, SIM card not inserted correctly, or no network signal.	Check SIM card insertion. Move to an area with better network coverage. Contact your service provider.
Poor call quality.	Weak network signal or interference.	Move to an area with stronger signal. Ensure nothing is blocking the speaker/microphone.
SOS button not working.	Emergency contacts not set up or incorrect.	Go to SOS settings and verify that emergency numbers are correctly programmed.
Phone freezes or is unresponsive.	Temporary software glitch.	Remove and reinsert the battery to perform a hard reset.

SPECIFICATIONS

Detailed technical specifications for the LESIA F1 mobile phone:

Feature	Detail
Model Name	F1 Klapphandy 4G
Brand	LESIA
Display	2.4-inch Color Screen
Network Technology	2G GSM (850/900/1800/1900 MHz), 3G WCDMA (850/900/2100), 4G LTE
SIM Card Slots	Dual SIM
Battery Capacity	1000 mAh Lithium-ion
Talk Time	Up to 4-5 hours
Standby Time	Up to 200 hours

Feature	Detail
Memory Storage Capacity	32 GB
Connectivity	3.5 mm Jack, USB Type C
Special Features	SOS Emergency Button, Large Buttons, Large Font, Flashlight, Charging Cradle, Speed Dial (M1/M2), Voice Function for numbers
Supported Languages	English, German, Italian, French, Spanish

WARRANTY AND SUPPORT

LESIA products are designed for reliability and performance. For information regarding warranty coverage, technical support, or service, please refer to the warranty card included in your product packaging or visit the official LESIA website. Please retain your proof of purchase for any warranty claims.

For further assistance, you may contact LESIA customer support through the contact information provided on their official website or the product packaging.

© 2024 LESIA. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How can I restore the dialing keypad language to Spanish on the LESIA F1 4G mobile phone?

To restore the language to Spanish on your LESIA F1 4G mobile phone, you will need to navigate through the settings menu. While the specific menu path isn't detailed in the manual, senior phones...

[Read full answer](#)