

[Manuals.plus](#) /

> [FRESMOL](#) /

> FRESMOL Compressed Air Duster Model VC019 Instruction Manual

FRESMOL VC019

FRESMOL Compressed Air Duster Instruction Manual

Model: VC019

INTRODUCTION

Thank you for choosing the FRESMOL Compressed Air Duster. This device is designed to provide a powerful and efficient solution for cleaning dust and debris from various electronic devices, keyboards, and other hard-to-reach areas. It serves as an eco-friendly and cost-effective alternative to traditional compressed air cans. Please read this manual thoroughly before use to ensure safe and optimal performance.

Key Features:

- **Powerful Airflow:** Equipped with a 100,000 RPM motor and 3 adjustable airflow settings (Low, Medium, High) for versatile cleaning.
- **Integrated LED Light:** Built-in LED work lights illuminate dark areas, making it easier to spot and clean hidden dust.
- **Rechargeable Battery:** Features a 7500mAh lithium battery, providing 20-40 minutes of continuous runtime on a single charge.
- **Type-C Fast Charging:** Supports 4-hour quick charging via the included Type-C cable.
- **Comprehensive Accessory Kit:** Includes 5 nozzles and 3 brushes for various cleaning applications.
- **Eco-Friendly Design:** Reusable and chemical-free, offering an environmentally conscious cleaning solution.
- **Portable and Lightweight:** Ergonomic design for comfortable grip and easy portability.

WHAT'S IN THE BOX

Verify that all items listed below are included in your package:

- FRESMOL Electric Air Duster Unit
- Brush (1)
- Brush (2)
- Brush (3)
- Nozzle (1)
- Nozzle (2)

- Nozzle (3)
- Nozzle (4)
- Nozzle (5)
- Type-C Charging Cable
- User Manual (this document)



Image: Contents of the FRESMOL Compressed Air Duster package, including the main unit, multiple nozzles, brushes, and a Type-C charging cable.

SETUP

1. **Initial Charge:** Before first use, fully charge the air duster. Connect the included Type-C charging cable to the device and a compatible USB power source (e.g., wall adapter, computer, power bank). The charging indicator light will turn green when fully charged. A full charge typically takes 4 hours.



Image: The FRESMOL Air Duster connected to a Type-C charging cable, illustrating the charging process.

- 2. Attach Nozzle/Brush:** Select the appropriate nozzle or brush for your cleaning task. Align the chosen accessory with the air outlet of the duster and push it firmly until it clicks into place.

POWERFUL DEEP CLEANING

Strong blowing power increased by 200%



Image: The FRESMOL Air Duster with a nozzle attached, demonstrating how accessories are connected.

OPERATING INSTRUCTIONS

- Power On/Off:** Long press the power button for 3 seconds to turn the device on or off.
- Adjust Airflow Speed:** Once powered on, short press the power button to cycle through the 3 adjustable airflow settings: Low, Medium, and High.
 - Gear 1 (Low):** Approximately 50,000 RPM, suitable for delicate surfaces.
 - Gear 2 (Medium):** Approximately 75,000 RPM, for general cleaning.
 - Gear 3 (High):** Approximately 100,000 RPM, for stubborn dust and debris.



Image: Illustration of the air duster's three speed settings and their respective performance levels.

3. **Using the LED Light:** The built-in LED work light automatically activates when the duster is powered on, providing illumination for cleaning in dimly lit areas.



LED LIGHTING DESIGN

Night lighting, clean without touching the dark

Image: The FRESMOL Air Duster in use, demonstrating the effectiveness of its integrated LED light for cleaning.

4. Cleaning Applications:

- **Keyboards & Electronics:** Use a fine nozzle and a brush to dislodge and blow away dust from keyboard keys, computer vents, and other electronic components.

Your browser does not support the video tag.

Video: Demonstrates cleaning a keyboard with the FRESMOL Air Duster, showing how to effectively remove dust and debris.

- **Car Interiors:** Utilize various nozzles to clean dust from car vents, dashboards, and crevices.

Your browser does not support the video tag.

Video: Shows the FRESMOL Air Duster being used to clean car interior vents and surfaces.

- **Other Uses:** The duster can also be used for cleaning camera equipment, air conditioners, inflating small items, and assisting with barbecue fires.

Comprehensive Cleaning Kit

Allows you to tackle various cleaning tasks with ease.



Car




Sofa



Fire



Camera



Inflatable function



Air conditioner



Keyboard

Image: A visual guide to the diverse applications of the FRESMOL Air Duster with its various attachments.

MAINTENANCE

- **Cleaning the Device:** Wipe the exterior of the air duster with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- **Cleaning Nozzles/Brushes:** After use, remove any attached nozzles or brushes and clean them as needed. They can be rinsed with water and air-dried if necessary. Ensure they are completely dry before reattaching or storing.
- **Storage:** Store the air duster and its accessories in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use for extended periods. Do not charge the device immediately after heavy use; allow it to cool down for at least 10 minutes.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device fully using the provided Type-C cable.
Weak airflow.	Low battery or incorrect speed setting.	Ensure the device is fully charged. Increase the airflow speed by short pressing the power button.
Device stops working during use.	Battery protection activated due to overheating or low charge.	Allow the device to cool down if it feels warm. Recharge the battery if it's low.
Nozzles do not fit securely.	Incorrect nozzle or not fully inserted.	Ensure you are using the correct nozzle for the air outlet and push it firmly until it clicks.

SPECIFICATIONS

Feature	Detail
Brand	FRESMOL
Model Number	VC019
Motor Speed	Up to 100,000 RPM
Airflow Settings	3 (Low, Medium, High)
Battery Capacity	7500mAh Lithium Battery
Continuous Runtime	20-40 minutes (depending on speed setting)
Charging Time	Approximately 4 hours
Charging Port	Type-C
Item Weight	13.28 ounces
Product Dimensions	2.36"W x 5.5"H
Included Components	Air duster, 5 nozzles, 3 brushes, Type-C charging cable

WARRANTY AND SUPPORT

The FRESMOL Compressed Air Duster comes with a **2-Year Manufacturer Warranty**. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, technical support, or any questions regarding your product, please contact FRESMOL customer service. Refer to the contact information provided on the product packaging or the official FRESMOL website.




Image: Visual representation of available customer support, including replacement services and 24/7 online assistance.

