

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Roconia](#) /

› [Roconia Q5 Projector User Manual](#)

Roconia Q5

Roconia Q5 Projector User Manual

Model: Q5 | Brand: Roconia

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Roconia Q5 5G WiFi Bluetooth Native 1080P Projector. Please read this manual thoroughly before using the projector to ensure optimal performance and safety.

WHAT'S IN THE BOX

- Roconia Q5 Projector
- Remote Control
- Power Cable
- HDMI Cable
- AV Cable
- User Manual (this document)

PRODUCT OVERVIEW

Familiarize yourself with the components and ports of your Roconia Q5 Projector.



Figure 1: Roconia Q5 Projector and accessories.

Front and Top View



Figure 2: Front and top view of the projector.

1. **Lens:** Projects the image onto the screen.
2. **Focus Ring:** Adjusts image clarity.
3. **Keystone Correction Ring:** Corrects trapezoidal distortion of the image.

Rear and Side Ports



Figure 3: Multiple input ports for versatile connectivity.

- **HDMI Ports (HDMI1, HDMI2):** Connect to devices like laptops, game consoles (PS5, Xbox), TV sticks, and DVD players.
- **USB Ports (USB1, USB2):** Connect USB drives for media playback.
- **AV Port:** Connect to older devices using an AV cable.
- **VGA Port:** Connect to computers with VGA output.
- **3.5mm Audio Jack:** Connect external speakers or headphones.

1. Placement

Place the projector on a stable, flat surface or mount it to the ceiling/wall. Ensure there is adequate ventilation around the projector.

2. Power Connection

Connect the power cable to the projector and then to a power outlet. The power indicator light will illuminate.

3. Screen Adjustment

Position the projector to achieve the desired screen size. The projector supports up to a 300-inch display.



Figure 4: The projector can create a large display up to 300 inches.

4. Focus and Keystone Correction

Turn on the projector. Rotate the **Focus Ring** (1) on the top of the projector until the image is clear. If the image appears trapezoidal, adjust the **Keystone Correction Ring** (2) until the image is rectangular.

CONNECTIVITY

1. Wired Connections (HDMI, USB, AV, VGA)

Connect your external devices (e.g., TV stick, laptop, game console) to the corresponding ports on the projector using the appropriate cables. Select the correct input source using the projector's menu or remote control.



Figure 5: Multiple connection options for various media devices.

Note: Due to HDCP copyright issues, streaming services like Netflix, Disney+, and Hulu prohibit direct playback from the projector via screen mirroring. Please use a TV Stick (not included) to connect to the projector for watching content from these services.

2. Wireless Connections (5G WiFi & Airplay/Screen Mirroring)

The projector supports 2.4G and 5G dual-band WiFi for stable and fast wireless connections with smartphones and other devices.



Figure 6: Seamless 5G WiFi connection for screen mirroring.

- **For iOS Devices (Airplay):**

1. Ensure your iOS device and the projector are connected to the same WiFi network.
2. On the projector, select the "Airplay" or "iOS Cast" input source.
3. On your iOS device, open Control Center and tap "Screen Mirroring" or "Airplay".
4. Select the projector from the list of available devices.

- **For Android Devices (Screen Mirroring):**

1. Ensure your Android device and the projector are connected to the same WiFi network.
2. On the projector, select the "Android Cast" or "Screen Mirroring" input source.
3. On your Android device, enable "Wireless Display", "Screen Cast", "Smart View", or similar function (names vary by device).
4. Select the projector from the list of available devices.

3. Bluetooth Connection (Audio Output)

The projector features Bluetooth 5.0, allowing you to connect external Bluetooth speakers or headphones for

enhanced audio.



Figure 7: Connect to external Bluetooth speakers for a better sound experience.

1. Go to the projector's Bluetooth settings.
2. Enable Bluetooth and scan for devices.
3. Select your Bluetooth speaker or headphones from the list to pair.

OPERATING INSTRUCTIONS

Power On/Off

- **Power On:** Press the power button on the projector or the remote control.
- **Power Off:** Press the power button again. Confirm shutdown if prompted.

Navigation and Menu

Use the directional buttons and OK/Enter button on the projector's control panel or the remote control to navigate through the on-screen menu. Access settings for picture, sound, network, and more.

Source Selection

Press the "Source" or "Input" button on the remote control or projector to select the desired input source (e.g., HDMI1, USB, AV, Screen Mirroring).

MAINTENANCE

- **Lens Cleaning:** Use a soft, lint-free cloth specifically designed for optical lenses to gently wipe the projector lens. Do not use abrasive cleaners.
- **Dust Removal:** Regularly clean the ventilation vents to prevent dust buildup, which can affect performance and lifespan. Use a soft brush or compressed air.
- **Storage:** When not in use for extended periods, store the projector in a cool, dry place, ideally in its original packaging or a protective case.
- **Lamp Life:** The LED bulb has an ultra-long life of up to 100,000 hours, ensuring years of entertainment.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No image or "No Signal"	Incorrect input source selected; Loose cable connection; Device not powered on.	Select the correct input source. Check all cable connections. Ensure connected device is powered on.
Blurry image	Focus not adjusted; Keystone not adjusted; Projector too close/far from screen.	Adjust the Focus Ring. Adjust the Keystone Correction Ring. Adjust projection distance.
No sound	Volume too low; Muted; External audio device not connected/paired.	Increase volume. Unmute. Ensure Bluetooth speaker is paired or wired speaker is connected correctly.
Cannot connect to WiFi	Incorrect password; Out of range; Network issue.	Verify WiFi password. Move projector closer to router. Restart router and projector.
Screen mirroring issues	Not on same WiFi network; Device compatibility; Copyright restrictions.	Ensure both devices are on the same WiFi. Check device compatibility. Use a TV stick for copyrighted content.

SPECIFICATIONS

Feature	Detail
Brand	Roconia
Model Number	Q5
Native Resolution	1920 x 1080 (Full HD)
Brightness	12000 Lumens
Contrast Ratio	10000:1
Display Size	Up to 300 inches

Feature	Detail
Connectivity	5G/2.4G WiFi, Bluetooth 5.0, HDMI, USB, AV, VGA, 3.5mm Audio Jack
Speaker	Built-in 5W HiFi Stereo Speakers with SRS sound system
Lamp Life	100,000 hours (LED)
Item Weight	3.08 pounds
Product Dimensions	12.23 x 8.62 x 5.24 inches
Color	White

WARRANTY AND SUPPORT

Roconia is committed to providing high-quality products and excellent customer service.

- **After-Sales Service:** Roconia offers 3-year after-sales service.
- **Customer Support:** A professional after-sales customer team is available 24/7 to provide support and solutions.
- For assistance, please refer to the contact information provided with your purchase or visit the official Roconia website.