

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [VASAGLE](#) /

› [VASAGLE Laundry Sorter URLS100B01 Instruction Manual](#)

VASAGLE URLS100B01

VASAGLE Laundry Sorter Instruction Manual

Model: URLS100B01

1. PRODUCT OVERVIEW

The VASAGLE Laundry Sorter is designed to streamline your laundry routine with its efficient sorting and portable features. This unit includes four removable liners, a sturdy top shelf, and smooth-rolling casters for easy mobility.

VASAGLE

by SONGMICS HOME



Image: The VASAGLE Laundry Sorter in use, demonstrating its functional design.

2. KEY FEATURES

- **Spacious and Efficient Design:** This laundry cart features two 13.2-gallon and two 6.6-gallon liners, providing a total capacity of 39.6 gallons (150 L). The integrated top shelf with guard rails offers a secure area for laundry essentials.

Roomy Storage, Orderly Space

- Top shelf offers convenient counter space
- Lower liners organize laundry



Image: Detailed view of the laundry sorter highlighting its storage capacity and shelf dimensions.

- **Personalized Sorting with Labels:** Equipped with 6 interchangeable labels (DARK, LIGHT, COLOR, TOWELS, SMALLS, OTHERS), this 4-bag sorter allows for customized organization. Labels attach easily with hook-and-loop fasteners.




Image: Close-up of the labels and the top shelf with guard rails.

- **Portable Design with Removable Liners:** The laundry sorter includes 4 casters, two of which are equipped with brakes, ensuring easy movement and secure placement. The liners feature hook-and-loop fasteners and convenient handles for simple removal and transport.

2 Ways to Carry the Liner



Image: Illustration of how to carry the liners using either the steel frame or flexible handles.

- **Sturdy and Durable Construction:** Constructed with a robust 0.6-inch diameter steel frame and thick Oxford fabric liners, this 4-section laundry hamper offers a strong and stable structure, capable of holding up to 85 lb.




Image: Diagram showing the weight capacity and overall dimensions of the sorter.

3. SETUP AND ASSEMBLY

Assembly of the VASAGLE Laundry Sorter is designed to be straightforward. All necessary parts are numbered, and detailed illustrated instructions are included to guide you through each step.

1. Unpack all components and verify against the parts list in the instruction manual.
2. Follow the step-by-step illustrations to connect the steel frame components.
3. Attach the top particleboard shelf securely.
4. Insert the Oxford fabric liners into their designated slots. Ensure the hook-and-loop fasteners are properly secured.
5. Attach the casters to the base of the frame. Two casters include brakes for stability. Alternatively, use the adjustable leveling feet if you prefer a stationary unit.

6. Apply the desired labels to the front of each liner.

For visual guidance, refer to the included instruction booklet.

4. OPERATING INSTRUCTIONS

4.1 Sorting Laundry

- Utilize the provided labels (DARK, LIGHT, COLOR, TOWELS, SMALLS, OTHERS) to categorize your laundry. These labels can be easily swapped to suit your specific sorting needs.
- Place items into the appropriate liners. The two smaller liners are ideal for delicates or small items, while the two larger liners accommodate bulkier clothes or towels.

4.2 Moving the Cart

- To move the laundry sorter, ensure the brakes on the casters are disengaged.
- Gently push or pull the cart to your desired location.
- To secure the cart in place, engage the brakes on the two locking casters.

4.3 Removing and Carrying Liners

- The fabric liners can be easily removed from the frame by detaching the hook-and-loop fasteners.
- Use the integrated handles on the liners to carry your sorted laundry to the washing machine.

5. MAINTENANCE

5.1 Cleaning the Frame and Shelf

- Wipe the steel frame and particleboard shelf with a soft, damp cloth.
- Avoid using abrasive cleaners or harsh chemicals, as these may damage the finish.
- Dry thoroughly after cleaning.

5.2 Cleaning the Liners

- The Oxford fabric liners can be spot cleaned with a mild detergent and water.
- Allow liners to air dry completely before reinserting them into the frame.
- Do not machine wash or tumble dry the liners, as this may cause damage or shrinkage.

6. TROUBLESHOOTING

6.1 Cart Does Not Roll Smoothly

- Check if the caster brakes are engaged. Disengage them if necessary.
- Ensure no debris is caught in the wheels. Clean the casters if obstructed.

6.2 Liners Do Not Stay Upright

- Verify that the hook-and-loop fasteners on the liners are securely attached to the frame.
- Ensure the internal support rods (if applicable) are correctly positioned within the liners.

6.3 Instability

- Confirm all screws and connections in the frame are tightened.
- If using adjustable feet, ensure they are properly leveled on an even surface.
- Avoid overloading the shelves or liners beyond the stated weight capacity.

7. SPECIFICATIONS

Brand	VASAGLE
Model Number	URLS100B01
Product Dimensions	28.5"L x 13"W x 43"H
Color	Ink Black + Chestnut Brown
Material	Steel, Oxford Fabric, Particleboard
Capacity	39.6 Gallons (150 L)
Item Weight	17.8 Pounds
Max Load Capacity	85 lb
Number of Liners	4 (Two 13.2-gallon, Two 6.6-gallon)
Special Feature	Removable Bags, Wheels with Brakes, Top Shelf with Guard Rails
Assembly Required	Yes

8. SAFETY INFORMATION

- Do not allow children to climb on or play with the laundry sorter.
- Ensure the cart is placed on a level surface to prevent tipping.
- Engage the wheel brakes when the cart is stationary to prevent accidental movement.
- Do not exceed the maximum load capacity of 85 lb.
- Keep small parts and assembly tools away from children.

9. WARRANTY AND SUPPORT

For warranty information, product support, or to inquire about replacement parts, please contact VASAGLE customer service through the retailer where the product was purchased or visit the official VASAGLE website. Please have your model number (URLS100B01) and purchase date available when contacting support.