

Sekey FW128

Sekey Heavy Duty Double Decker Folding Wagon

Model: FW128 | Brand: Sekey

1. INTRODUCTION AND OVERVIEW

Thank you for choosing the Sekey Heavy Duty Double Decker Folding Wagon. This versatile utility wagon is engineered for durability and convenience, designed to transport a wide range of items for various outdoor activities. With a robust alloy steel frame, it supports up to 500 lbs and offers a massive 400L capacity, making it ideal for sports events, camping trips, gardening, and shopping.

Its unique double-decker design and all-terrain wheels provide superior functionality and maneuverability, ensuring your gear is transported safely and efficiently. The innovative folding structure allows for quick setup and compact storage.



Figure 1: The Sekey Heavy Duty Double Decker Folding Wagon, showcasing its robust design and spacious upper compartment.

2. SETUP INSTRUCTIONS

The Sekey Double Decker Folding Wagon arrives fully assembled and is designed for effortless setup. Follow these steps to prepare your wagon for use:

1. **Unfolding the Wagon:** Place the folded wagon on a flat, stable surface. Gently pull the sides outwards until the frame fully expands.
2. **Securing the Base:** Once the frame is expanded, push down firmly on the center of the wagon's base until it locks into place. This ensures stability.
3. **Inserting the Bottom Pad:** Locate the removable bottom pad (stored in a side pocket when folded). Place this pad firmly into the main compartment to create a flat, stable floor.
4. **Activating the Extended Lower Shelf:** For the double-decker feature, unclip the lower shelf extension at the rear of the wagon and pull it outwards. Ensure it locks securely into its extended position.
5. **Adjusting the Handle:** The handle is spring-loaded. Pull it up to your desired height. To retract, press the red button on the handle shaft and push down.

Your browser does not support the video tag.

Video 1: This video demonstrates the quick and easy unfolding process of the Sekey Double Decker Collapsible Wagon, showing how to prepare it for use in under a minute.



Figure 2: The wagon in its compact, folded configuration, highlighting its portability and ease of storage.

3. OPERATING INSTRUCTIONS

The Sekey Double Decker Folding Wagon is designed for versatile use. Here's how to maximize its functionality:

3.1 Loading and Capacity

- **Upper Compartment:** Use the main upper compartment for general items such as bags, groceries, or smaller coolers. The reinforced Oxford fabric ensures durability.
- **Extended Lower Shelf:** The drop-down tailgate extends the lower deck to 56 inches, perfect for long items like 10x10 pop-up canopies, baseball bats, fishing rods, or folding chairs. This open-ended platform prevents items from tilting or falling.
- **Dual-Tier Organization:** Utilize the two tiers to separate items. For example, keep muddy sports

equipment on the lower shelf and use the top as a clean surface for snacks or electronics.

PRODUCT SIZE



Extended Bed
Fits Gear Longer than 48" Flat"

Figure 3: The extended lower bed of the wagon, illustrating its capability to accommodate long items such as a 10x10 pop-up canopy.

DUAL-TIER ORGANIZATION



Order



Chaos

Figure 4: A visual representation of the dual-tier organization, separating items for cleanliness and accessibility.

3.2 Maneuverability and Braking

- **All-Terrain Wheels:** The wagon is equipped with 360° rotating all-terrain big wheels, designed to navigate various surfaces including grass fields, gravel paths, and packed sand with ease.
- **Dual Braking System:** Two built-in brakes on the front wheels allow you to lock the wagon in place, preventing unwanted movement on slopes or uneven ground during loading and unloading. To engage, press down on the red levers on the wheels.

Your browser does not support the video tag.

Video 2: This video highlights the large wheels and the effective braking system of the wagon, demonstrating its stability on various terrains.

EXCEPTIONAL QUALITY WAGON BEYOND COMPARE



600D Oxford Fabric




Figure 5: Close-up of the all-terrain wheels, designed for smooth movement across diverse landscapes.

3.3 Additional Features

- **Side Pockets:** The wagon includes convenient side pockets for smaller items like sunscreen, books, or personal belongings.
- **Cup Holders:** Two integrated cup holders are available near the handle for easy access to beverages.

Your browser does not support the video tag.

Video 3: This video demonstrates the versatility of the 2-level wagon, including its use as a mobile station with a tabletop, ideal for sports and camping.

4. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your Sekey wagon:

- **Cleaning:** The Oxford fabric can be wiped clean with a damp cloth and mild soap. Avoid harsh chemicals. Ensure the fabric is completely dry before folding and storing to prevent mildew.
- **Storage:** When not in use, fold the wagon compactly and store it in a cool, dry place. Use the provided

cover to protect it from dust and damage.

- **Wheel Inspection:** Periodically check the wheels for any debris or damage. Ensure the brakes engage and disengage smoothly.
- **Frame Inspection:** Regularly inspect the alloy steel frame for any signs of wear, damage, or loose fasteners. Tighten any loose screws as needed.

5. TROUBLESHOOTING

If you encounter any issues with your wagon, refer to the following common problems and solutions:

- **Difficulty Unfolding/Folding:** Ensure all locking clasps are disengaged. Check for any obstructions in the folding mechanism. Apply gentle, even pressure when expanding or collapsing the frame.
- **Wheels Not Rolling Smoothly:** Inspect wheels for trapped debris (e.g., sand, small stones). Clean the wheels and axles. Ensure the brakes are fully disengaged.
- **Brakes Not Engaging/Disengaging:** Check the red brake levers for obstructions or damage. Ensure they can move freely to lock and unlock the wheels.
- **Wagon Instability:** Verify that the central base is fully pushed down and locked into place. Ensure all frame joints are securely fastened. Avoid exceeding the maximum weight capacity.

6. SPECIFICATIONS

Feature	Detail
Product Dimensions (D x W x H)	48"D x 22.83"W x 38.19"H
Material	Oxford Fabric, Polyvinyl Chloride (PVC)
Weight Capacity Maximum	500 Pounds
Number of Shelves	2 (Double Decker)
Tire Type	Solid, All-Terrain Big Wheels with Brakes
Number of Wheels	4
Frame Material	Carbon Steel
Handle Material	Alloy Steel
Special Features	Big Wheels with Brakes, Effortless Folding, Extended Lower Shelf, Extra Storage, Large Capacity

7. WARRANTY & SUPPORT

The Sekey Heavy Duty Double Decker Folding Wagon comes with a 1-year warranty. For warranty claims, product support, or any inquiries, please contact Sekey customer service through your purchase platform or visit the official Sekey website. Please retain your proof of purchase for warranty validation.

For additional information or assistance, please refer to the contact details provided with your product

packaging or on the Sekey brand store page.