



[Manuals.plus](#) /

> [APEXCHASER](#) /

> APEXCHASER Clothes Drying Rack Instruction Manual

APEXCHASER 128301

APEXCHASER Clothes Drying Rack Instruction Manual

MODEL: 128301

INTRODUCTION

Thank you for choosing the APEXCHASER Clothes Drying Rack. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new drying rack. Please read it thoroughly before use and retain it for future reference.

PRODUCT FEATURES

- **Premium Material:** Crafted from 100% metal, this clothes drying rack by APEXCHASER is durable, sturdy, and rust-free, ensuring long-lasting use and reliable performance.
- **Lightweight & Space Saving:** With its foldable design, this laundry drying rack is lightweight and easy to store. Perfect for use in laundry rooms, gardens, or patios, it can be effortlessly moved and stored in a corner, helping you save valuable space.
- **High Practicality:** Equipped with non-slip feet at the bottom, this 3-tier clothes rack provides stability and won't scratch your floors. It offers a gentle way to dry various clothing items such as shirts, jeans, dress slacks, sweaters, and more, helping save energy and extend the life of your garments.
- **Large Capacity:** Featuring 11 drying rods, this compact air drying clothing rack offers ample space for towels, scarves, dresses, and other items. It's also suitable for drying linens and baby clothes, accommodating all your drying needs with ease.
- **Easy Installation:** The APEXCHASER clothes ailer is designed for hassle-free installation. No tools are required, and you can easily connect the drying rods. Once installed, there's no need to disassemble it as it can be conveniently folded for storage whenever needed.

PACKAGE CONTENTS

- Main Frame Components (pre-assembled foldable sections)
- Drying Rods (11 pieces)
- Non-slip Feet (pre-attached)
- Instruction Manual (this document)

SETUP INSTRUCTIONS

Step 1: Unfold the Main Frame

Carefully remove the drying rack from its packaging. Place the folded frame on a flat, stable surface. Gently pull the top section upwards to begin unfolding the rack.





Image: The clothes drying rack shown in both its compact, folded state and partially unfolded, illustrating the initial setup step.

Step 2: Extend the Tiers

Continue pulling the frame upwards until all three tiers are fully extended and locked into place. Ensure all joints are securely engaged.


Development Step

1




Upright the drying rack

2



Pull the drying rack upward

3



Lock the buckle

4



Ready to use

Image: A visual guide demonstrating the upward extension of the drying rack's tiers during assembly.

Step 3: Secure the Buckles

Locate the secure buckle locks on each side of the rack. Push them firmly into place to ensure the rack remains stable during use.




Image: A detailed view of the buckle lock, highlighting how to secure the rack's frame for stability.

Step 4: Ready for Use

Once fully assembled and secured, the drying rack is ready to hold your laundry.



Image: The completed drying rack, ready for use, with clothes such as towels, shirts, and socks placed on its tiers.

OPERATING INSTRUCTIONS

Placing Laundry

Distribute laundry evenly across the 11 drying rods to maintain balance and stability. Heavier items should be placed on lower tiers if possible.

Utilize the top tier for flat drying items like sweaters or delicate garments. The middle and bottom tiers are ideal for hanging clothes, towels, and smaller items.



Image: The drying rack in use, demonstrating how different types of laundry can be placed on its multiple levels.

Indoor and Outdoor Use

The rust-free metal construction allows for both indoor and outdoor use. For outdoor use, ensure the rack is placed on a stable, level surface and consider bringing it indoors during strong winds or adverse weather conditions.



Image: The drying rack positioned on an outdoor patio, highlighting its suitability for outdoor use.

Folding for Storage

To fold the rack for compact storage, release the secure buckle locks and gently collapse the tiers downwards. The rack folds flat for easy storage in a corner or closet.



Image: The drying rack in its folded state, demonstrating its compact storage capability next to a laundry appliance.

MAINTENANCE

To clean the drying rack, wipe down the metal rods and frame with a damp cloth and mild detergent. Avoid abrasive cleaners or harsh chemicals that could damage the coating.

Ensure the rack is completely dry before folding and storing to prevent any potential moisture buildup.

TROUBLESHOOTING

Rack is unstable:

Ensure all tiers are fully extended and the secure buckle locks are engaged. Check that the non-slip feet are properly positioned on a flat surface.

Rods detach:

The rods are designed for easy connection. If a rod detaches, simply re-insert it firmly into its designated slot.

Rusting:

The rack features a corrosion-resistant coating. If any signs of rust appear, clean the area immediately and ensure the rack is stored in a dry environment.

SPECIFICATIONS

Feature	Detail
Brand	APEXCHASER
Model Number	128301
Material	Metal
Color	White
Product Dimensions	14.56"D x 35.03"W x 45.27"H
Item Weight	5.32 pounds
Mounting Type	Floor Mount
Special Feature	Collapsible

WARRANTY & SUPPORT

APEXCHASER offers a 60-day free return policy and 12 months problem-solving support. For any issues or inquiries, please contact our customer service team through the retailer's platform or visit the official [APEXCHASER store](#).

WHY CHOOSE US



Provide 60 day free return policy & 12 months problem solve issue.



Establish a scientific quality control plan and carefully monitor the quality of each product



With a professional R&D team of about 200 people, over 100 independent innovation patents.

Image: Information regarding APEXCHASER's customer support and warranty policies.