

[Manuals.plus](#) /

› [INFANS](#) /

› INFANS BE10027 3-in-1 Portable Pack and Play Instruction Manual

INFANS BE10027

INFANS BE10027 3-in-1 Portable Pack and Play Instruction Manual

Model: BE10027

INTRODUCTION

This manual provides essential instructions for the safe assembly, operation, and maintenance of your INFANS BE10027 3-in-1 Portable Pack and Play. This versatile product functions as a playpen, bassinet, and changing table, designed for children from 0 to 36 months, with a maximum weight capacity of 33 lbs. Please read all instructions carefully before use and retain this manual for future reference.



Image: The INFANS 3-in-1 Portable Pack and Play, fully assembled, showcasing its various components including the changing table, mobile with hanging toys, and a side storage bag. The compact carry bag is also shown, highlighting its portability.

SAFETY INFORMATION

WARNING: Failure to follow these warnings and the instructions could result in serious injury or death.

- Always ensure all locking mechanisms are securely engaged before placing a child in the playard.
- Do not use this product if any parts are missing, damaged, or broken. Contact INFANS for replacement parts and instructional literature if needed. Do not substitute parts.
- The maximum weight capacity for this product is 33 lbs (15 kg).
- The product is suitable for children aged 0-36 months.
- To prevent falls, do not use the changing table or bassinet feature once the child begins to push up on hands and knees, or has reached the maximum weight capacity, whichever comes first.

- Never leave a child unattended in the playard, bassinet, or changing table.
- Ensure the mattress pad fits snugly without gaps to prevent entrapment. Only use the mattress pad provided by the manufacturer.
- Keep the playard away from open flames, heaters, or other sources of strong heat.
- This product is certified by ASTM, TSCA, and CPSIA, ensuring it meets safety standards and is made from non-toxic, odorless materials.

PACKAGE CONTENTS

Verify that all components are present before assembly:

- 1 x INFANS Pack and Play Unit
- 1 x Instruction Manual (this document)
- 1 x Music Box with Toy Bar
- 1 x Carry Bag
- 1 x Detachable Changing Table
- 1 x Mattress Pad (37.5" L x 26.5" W)
- 1 x Side Storage Bag

SETUP INSTRUCTIONS


1. **Unpack the Unit:** Remove the Pack and Play from its carry bag. Place it on a flat, stable surface.
2. **Unfold the Frame:**
 - a. Separate the legs and pull the center of the base upwards.
 - b. Ensure all four top rails are locked into place. You should hear an audible "click" for each rail. If a rail does not lock, lift the center of the base slightly and try again.
 - c. Push the center of the base down until it lies flat.
3. **Install the Mattress Pad:** Place the mattress pad inside the playard, ensuring it lies flat and covers the entire bottom surface without gaps.
4. **Attach the Bassinet (for infants):**
 - a. If using the bassinet feature, secure the bassinet fabric to the upper rails of the playard according to the specific attachment points.
 - b. Place the mattress pad on the bassinet level.

3-In-1 Pack and Play

Multifunctional nursery center meets different needs



Detachable
Changing Table



Baby Play Yard



Infant Bassinet

Image: This illustration demonstrates the three primary functions of the INFANS Pack and Play: a spacious play yard for active toddlers, a convenient detachable changing table for newborns, and a cozy infant bassinet for sleeping.

5. Attach the Changing Table:

- Position the changing table over the top rails of the playard.
- Securely attach it using the designated clips or fasteners. Ensure it is stable before use.

6. Install the Music Box and Toy Bar:

Attach the music box and toy bar to the designated points on the playard frame. Ensure they are securely fastened and out of reach of a standing child.

7. Attach the Side Storage Bag:

Hook the side storage bag onto the exterior of the playard for convenient access to diapers and other essentials.

OPERATING INSTRUCTIONS

Using as a Playpen

The playpen provides a secure and spacious area for your child to play. Ensure the mattress pad is at the lowest level for

safety when used as a playpen. Always supervise your child while they are in the playpen.



Image: A parent watches over a baby comfortably situated in the INFANS Pack and Play, demonstrating its use as a secure play area.

Using as a Bassinet

The bassinet feature is designed for newborns and infants who cannot push up on their hands and knees. It provides an elevated sleeping surface. Always ensure the bassinet is securely attached to the upper rails. Discontinue use of the bassinet when your child reaches the weight limit or shows signs of pushing up.



Image: An infant rests in the bassinet configuration of the INFANS Pack and Play, highlighting its suitability for newborn sleep.

Using the Changing Table

The detachable changing table offers a convenient surface for diaper changes. Always secure the changing table firmly to the playard rails before use. Never leave your child unattended on the changing table. Discontinue use when your child can roll over or reaches the weight limit.

Using the Music Box and Toy Bar

The integrated music box and toy bar can provide entertainment and soothe your child. Activate the music box for gentle melodies. Ensure the toy bar is positioned safely and the hanging toys are securely attached.

Moving the Pack and Play

The Pack and Play is equipped with two universal wheels for easy movement. To move the unit, lift the end without wheels slightly and roll it to the desired location. Engage the wheel brakes once positioned to ensure stability.

Two Universal Wheels Help to Move



Image: A user demonstrates the ease of moving the INFANS Pack and Play, highlighting its two universal wheels and the integrated braking system for secure placement.

Folding for Storage or Travel

To fold the Pack and Play for storage or travel:

1. Remove the mattress pad, changing table, music box, and any other accessories.
2. Lift the center of the base slightly.
3. Disengage the locking mechanisms on all four top rails by pressing the buttons or levers.
4. Gently push the top rails inward to collapse the frame.
5. Push the center of the base upwards to fully fold the unit.
6. Secure the folded unit with the provided straps, if any, and place it into the carry bag.



Easy to Fold & Carry

Comes with a carrying bag



Image: A visual guide illustrating the step-by-step process of folding the INFANS Pack and Play into a compact form, ready for transport in its carry bag, shown stored in a car trunk.

MAINTENANCE

- **Cleaning:** Clean the fabric parts with a damp cloth and mild soap. Do not use harsh detergents or abrasive cleaners. Allow to air dry completely.
- **Frame:** Wipe the metal and plastic parts with a damp cloth.
- **Mattress Pad:** The mattress pad can be wiped clean with a damp cloth. Do not machine wash or tumble dry.
- **Inspection:** Regularly inspect the product for any signs of wear, damage, or loose parts. Ensure all fasteners and locking mechanisms are secure.
- **Storage:** When not in use, store the Pack and Play in its carry bag in a clean, dry place, away from extreme temperatures.

TROUBLESHOOTING

Problem: The top rails do not lock into place during setup.

Solution: Ensure the center of the playard base is not fully pushed down. Lift the center of the base slightly, then firmly push down on each top rail until it clicks into place. Once all rails are locked, push the center of the base down completely.

Problem: The playard is difficult to fold.

Solution: Make sure all accessories (mattress pad, changing table, etc.) are removed. Verify that all four top rail locking mechanisms are disengaged. The center of the base must be lifted slightly before attempting to collapse the rails.

Problem: Wheels are not rolling smoothly or locking.

Solution: Check for any debris or obstructions in the wheel mechanism. Ensure the brakes are fully disengaged for rolling and fully engaged for locking. Clean wheels if necessary.

SPECIFICATIONS

Model Number	BE10027
Overall Dimensions (L x W x H)	41" x 31" x 29"
Diaper Table Dimensions (L x W)	26" x 12.6"
Mattress Dimensions (L x W)	37.5" x 26.5"
Folded Carry Bag Dimensions (L x W x H)	31" x 8.5" x 9"
Wheel Diameter	4"
Main Materials	Oxford Cloth, Polyester, PP, Steel
Weight Capacity	33 lbs (15 kg)
Applicable Age	0-36 Months
Product Weight	24.4 lbs (11.09 kg)



Weight Capacity: 15 lbs



Suitable Age: 0-36 Months

Dimension of Mattress: 37.5" x 26.5" (L x W)




Image: A detailed diagram illustrating the key dimensions of the INFANS Pack and Play, such as overall size, changing table size, and mattress size, along with its weight capacity and recommended age range.

WARRANTY AND SUPPORT

Information regarding product warranty and customer support was not available in the provided product data. For warranty details or assistance, please refer to the product packaging or contact INFANS customer service directly through their official website or the retailer where the product was purchased.

© 2025 INFANS. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question