

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [AGLUCKY](#) /

> [AGLUCKY Ice Maker User Manual](#)

AGLUCKY B0CNVL19YJ

AGLUCKY Countertop Ice Maker User Manual

Model: B0CNVL19YJ

INTRODUCTION

Thank you for choosing the AGLUCKY Countertop Ice Maker. This portable and efficient appliance is designed to provide you with fresh bullet-shaped ice quickly and conveniently. With its rapid ice production, self-cleaning function, and user-friendly design, it is an ideal addition to any home kitchen, office, or for on-the-go use. This manual provides detailed instructions for safe operation, setup, maintenance, and troubleshooting to ensure optimal performance and longevity of your ice maker.



The AGLUCKY Countertop Ice Maker, showcasing its compact design and included ice basket and scoop, ready to produce bullet ice.

SAFETY INSTRUCTIONS

Please read all instructions carefully before using the appliance and retain them for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Ensure the power supply voltage matches the rating label on the appliance.
- Do not immerse the appliance, power cord, or plug in water or any other liquid.
- Unplug the ice maker from the outlet when not in use, before cleaning, or if a malfunction occurs.
- Do not operate the appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Keep the appliance away from heat sources, direct sunlight, and flammable materials.
- Ensure proper ventilation around the ice maker. Do not block any ventilation openings.
- Use only potable water in the water reservoir.

- Do not place fingers or other objects into the ice maker during operation.
- This appliance is for household use only. Do not use outdoors.
- Always place the ice maker on a stable, flat surface.

PRODUCT OVERVIEW

Familiarize yourself with the components of your AGLUCKY Ice Maker.



An overhead view of the ice maker, highlighting the control panel, transparent lid, and the ice basket with a scoop.

Components:

- **Control Panel:** Features indicator lights for "ADD WATER", "ICE FULL", "CLEAN", "POWER ON/OFF", and "SELECT" for ice size.
- **Transparent Lid:** Allows observation of the ice-making process.
- **Ice Basket:** Removable basket for collecting ice cubes.

- **Ice Scoop:** For convenient ice retrieval.
- **Water Reservoir:** Located beneath the ice basket, where water is stored for ice production.
- **Handle:** Integrated handle for easy portability.
- **Air Outlet:** Located on the side for heat dissipation.

SETUP

Follow these steps for the initial setup of your ice maker.

1. **Unpack:** Carefully remove the ice maker from its packaging. Remove all packing materials, including tape and foam.
2. **Clean:** Before first use, clean the interior of the ice maker. Refer to the "Maintenance" section for detailed cleaning instructions.
3. **Placement:** Place the ice maker on a stable, level surface, away from direct sunlight and heat sources. Ensure there is at least 4 inches of clearance around the unit for proper ventilation.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet. Ensure the outlet's voltage matches the appliance's requirements.
5. **First Use Recommendation:** It is recommended to run the self-cleaning cycle once before making ice for consumption to ensure the internal components are clean.

OPERATING INSTRUCTIONS

Learn how to operate your AGLUCKY Ice Maker to produce ice efficiently.

1. Adding Water:

- Open the lid and remove the ice basket.
- Fill the water reservoir with potable water up to the "MAX" fill line. Do not overfill.
- Replace the ice basket and close the lid.

2. Powering On and Selecting Ice Size:

- Press the "**POWER ON/OFF**" button to turn on the ice maker.
- The default ice size is usually small. To change the ice size, press the "**SELECT**" button. The indicator light will switch between "S" (Small) and "L" (Large).
- Small ice cubes are ideal for quick cooling, while large ice cubes melt slower, preserving drink flavor.

2 Sizes cubes

Small
28x21x21mm

Large
28*24*29mm



The ice maker produces two sizes of bullet-shaped ice cubes: Small (28x21x21mm) and Large (28x24x29mm).

3. Ice Production:

- The ice maker will begin producing ice within 6-8 minutes. Each cycle produces 9 bullet-shaped ice cubes.
- The machine can produce up to 26.5 pounds of ice in 24 hours.
- The "**ICE FULL**" indicator will illuminate when the ice basket is full, and the machine will automatically pause operation. Remove ice to resume production.
- The "**ADD WATER**" indicator will illuminate when the water level is low. Add more water to the reservoir to continue ice production.



A visual representation of the ice-making process, demonstrating the rapid production of 9 ice cubes in approximately 6 minutes.

4. Turning Off:

- Press the "**POWER ON/OFF**" button to turn off the ice maker.

MAINTENANCE

Regular maintenance ensures the longevity and hygiene of your ice maker.

Self-Cleaning Function:

The AGLUCKY Ice Maker features a convenient one-touch self-cleaning function.

1. Ensure the ice basket is empty.
2. Fill the water reservoir with clean water up to the "MAX" line. You may add a small amount of white vinegar or a mild cleaning solution suitable for ice makers (follow product instructions for cleaning solution).
3. Press and hold the "**CLEAN**" button for 1 second to activate the self-cleaning cycle. The "**CLEAN**" indicator will light up.
4. The machine will run a cleaning cycle, circulating water through its internal components.
5. Once the cycle is complete, drain the water from the reservoir by unplugging the drain plug (usually located at the bottom or side of the unit).
6. Rinse the reservoir thoroughly with clean water and drain again to remove any cleaning solution residue.



Simply press "Clean" to activate the machine's **self-cleaning** function

Detail of the control panel, emphasizing the "CLEAN" button for activating the self-cleaning function.

General Cleaning:

- **Exterior:** Wipe the exterior of the ice maker with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Ice Basket & Scoop:** Wash the ice basket and scoop with warm, soapy water. Rinse thoroughly and dry before returning to the unit.
- **Internal Components:** Periodically, after draining the water, wipe down the internal surfaces of the water reservoir and ice collection area with a clean cloth.
- **Air Outlet:** Keep the air outlet on the side of the unit clear of dust and obstructions to ensure efficient operation.

Storage:

If storing the ice maker for an extended period, ensure it is completely dry. Drain all water, run a self-cleaning cycle, and allow it to air dry before storing in a cool, dry place.

TROUBLESHOOTING

Refer to this section for solutions to common issues you might encounter.

Problem	Possible Cause	Solution
Ice maker not turning on.	No power; loose plug.	Ensure the unit is properly plugged into a working outlet. Check circuit breaker.
"ADD WATER" indicator is on.	Water reservoir is empty or low.	Add potable water to the reservoir up to the MAX fill line.
"ICE FULL" indicator is on.	Ice basket is full; ice is blocking sensor.	Remove ice from the basket. Ensure no ice cubes are obstructing the ice full sensor.
Ice cubes are too small or not forming.	Water temperature too high; ambient temperature too high; insufficient water.	Use colder water. Place the ice maker in a cooler environment. Ensure water level is sufficient.
Ice cubes stick together.	Ice melting and refreezing; high ambient temperature.	Transfer ice to a freezer immediately after production. Ensure proper ventilation.

Problem	Possible Cause	Solution
Unusual noise during operation.	Normal operation sounds (water pump, ice dropping); foreign object.	Some noise is normal. If excessive, unplug and check for obstructions. Contact customer support if noise persists.

SPECIFICATIONS

Feature	Detail
Model Name	Ice Maker
Brand	AGLUCKY
Product Dimensions	11.42"D x 8.74"W x 11.57"H
Weight	14.2 Pounds
Capacity	26.5 Pounds (ice production per 24 hours)
Wattage	100 watts
Ice Shape	Bullet
Ice Sizes	Small, Large
Ice Production Time	9 cubes in 6-8 minutes
Self-Cleaning Function	Yes

Compact Ice Machine



13.6 lbs



Compact



Handle



The compact design of the AGLUCKY Ice Maker, showing its dimensions (11.42"D x 8.74"W x 11.57"H) and weight (14 pounds), emphasizing its portability.

WHAT'S IN THE BOX

Upon opening your AGLUCKY Ice Maker package, you should find the following items:

- AGLUCKY Countertop Ice Maker Unit
- Ice Scoop
- Ice Basket
- User Manual (this document)

WARRANTY AND SUPPORT

AGLUCKY products are designed for reliability and performance. For warranty information and customer support, please refer to the contact details provided on the product packaging or visit the official AGLUCKY website. Keep your purchase

receipt as proof of purchase for warranty claims.

For further assistance or inquiries, you may also visit the AGLUCKY Store on Amazon:[AGLUCKY Store](#)

