

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Starfavor](#) /

› [Starfavor REVERIE Grand Digital Piano User Manual](#)

Starfavor REVERIE

Starfavor REVERIE Grand Digital Piano User Manual

Model: REVERIE

INTRODUCTION

Thank you for choosing the Starfavor REVERIE Grand Digital Piano. This instrument combines the elegant design of a grand piano with advanced digital features, offering an authentic playing experience. This manual provides essential information for the proper setup, operation, and maintenance of your digital piano. Please read it thoroughly before use to ensure optimal performance and longevity.

IMPORTANT SAFETY INFORMATION

- **Power Supply:** Use only the specified power adapter. Ensure the voltage matches your local power supply.
- **Placement:** Place the piano on a stable, level surface. Avoid direct sunlight, heat sources, and excessive humidity.
- **Ventilation:** Do not block ventilation openings. Ensure adequate airflow around the instrument.
- **Water and Moisture:** Keep the piano away from water or other liquids. Do not operate with wet hands.
- **Cleaning:** Use a soft, dry cloth for cleaning. Avoid abrasive cleaners or solvents.
- **Servicing:** Do not attempt to repair the instrument yourself. Refer all servicing to qualified personnel.

WHAT'S IN THE BOX

Upon unpacking, please verify that all the following items are included:

- Starfavor REVERIE Grand Digital Piano Unit
- Sustain Pedal Unit
- Power Cable
- User Manual (this document)



Image: The Starfavor REVERIE Grand Digital Piano, showcasing its elegant black finish, 88-key keyboard, and the included sustain pedal unit.

SETUP INSTRUCTIONS

The Starfavor REVERIE Grand Digital Piano is designed for straightforward assembly. Follow these steps to set up your instrument.

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future transport or storage.
2. **Leg Assembly:** Attach the four legs to the main piano body. Each leg is secured with 5 bolts, ensuring stability. Ensure all bolts are tightened securely.
3. **Pedal Unit Connection:** Connect the sustain pedal unit cable to the designated port on the underside of the piano.
4. **Power Connection:** Connect the power cable to the piano's power input and then to a suitable electrical outlet.
5. **Lid Mechanism:** The piano features a 1:1 replica of a grand piano's lid mechanism. Carefully open the lid to your desired position.

GRAND YET COMPACT

1:1 replica of the grand piano's lid mechanism and the streamlined arched soundboard.




Image: The Starfavor REVERIE Grand Digital Piano fully assembled in a home setting, demonstrating its compact size and elegant design.

The compact design occupies approximately 5 square feet, making it suitable for various home environments.

OPERATING INSTRUCTIONS

Basic Operation

- **Power On/Off:** Locate the power button, typically on the control panel, and press to turn the instrument on or off.
- **Volume Control:** Adjust the master volume using the dedicated control knob or buttons.
- **Key Action:** The 88 weighted hammer-action keys simulate an acoustic piano, providing a responsive touch.

WEIGHTED KEYBOARD PIANO

Accurately capturing the strength of your fingertips
and delivering a genuine grand piano touch.



Image: A close-up view of the 88 weighted keys, highlighting the realistic feel and response for an authentic playing experience.

Sound and Tones

- **Timbres:** The piano features 5 high-quality timbres. Refer to the control panel for selection buttons or menus.
- **Demo Songs:** Access 5 classic demo songs for listening or practice.
- **Transposition:** Adjust the pitch of the entire keyboard up or down to suit different keys or vocal ranges.
- **Metronome:** Utilize the built-in metronome for rhythm practice. Adjust tempo as needed.
- **Music Hall Reverb:** The opening and closing of the piano lid influences the sound's reverb, simulating acoustic grand piano environments. Experiment with lid positions to achieve desired effects. Note that preset sound effects may vary and reset upon restart.

MUSIC HALL REVERB

The opening and closing of the digital piano lid simulates the authentic acoustics of a grand piano.



Image: The digital piano with its lid open, illustrating how the design contributes to a simulated music hall reverb effect, enhancing the acoustic experience.

Connectivity

- **Bluetooth:**

The piano is equipped with Bluetooth for wireless connection to mobile devices. This allows for audio streaming or MIDI communication with compatible applications.

- a. Activate Bluetooth on your mobile device.
 - b. Select "REVERIE Piano" (or similar) from the list of available devices.
 - c. Once paired, you can stream audio to the piano's speakers or use MIDI apps.
- **USB-MIDI:** Connect the piano to a computer using a USB-MIDI cable for advanced music software editing or to transmit MIDI signals to learning applications.
 - **Headphone Jacks:** Two 6.35mm headphone jacks are provided for private practice or collaborative sessions. Connecting headphones will mute the internal speakers.
 - **MP3 Jack:** Use the 3.5mm MP3 jack to connect external audio sources and play along with your favorite music.

WIRELESS FREEDOM

Equipped with Bluetooth for wireless connection to mobile devices, allowing you to enjoy music or improvise.



Bluetooth




Image: A user interacting with the digital piano via Bluetooth, demonstrating the wireless connectivity feature for mobile devices.

Special Features

- **Amber Light Strip:** An integrated amber light strip provides ambient lighting, enhancing the playing atmosphere.
- **Dual Keyboard Setup:** The instrument supports a dual-keyboard setup, ideal for teaching or duets.
- **Recording Function:** The piano includes a recording option to capture your performances. Refer to the control panel for specific recording controls.

AMBER LIGHT BAR

Transforms REVERIE into the warmest light source in your home, dispelling the darkness of night.




Image: A close-up of the amber light bar integrated into the digital piano, providing warm ambient lighting during use.

MAINTENANCE AND CARE

- **Cleaning the Surface:** Use a soft, dry, lint-free cloth to wipe the piano's polished surface. For stubborn marks, slightly dampen the cloth with water and wipe gently, then dry immediately. Avoid chemical cleaners, waxes, or polishes.

- **Cleaning the Keys:** Wipe the keys with a soft, slightly damp cloth. Do not use alcohol or harsh cleaning agents, as they can damage the key surfaces.
- **Dust Protection:** When not in use, cover the piano with a dust cover to prevent dust accumulation on the keys and internal components.
- **Environmental Conditions:** Maintain a stable room temperature and humidity. Extreme fluctuations can affect the instrument's components.
- **Transportation:** If moving the piano, ensure it is properly disassembled and packed in its original or suitable protective packaging to prevent damage.

TROUBLESHOOTING GUIDE

If you encounter any issues with your Starfavor REVERIE Grand Digital Piano, please refer to the following common problems and solutions before contacting customer support.

Problem	Possible Cause	Solution
No sound from speakers	Power not connected or turned on. Volume too low. Headphones connected.	Ensure power cable is securely connected and piano is powered on. Increase the master volume. Disconnect headphones from the jacks.
Crackling or static sound	Loose cable connections. Interference from other electronic devices. Faulty speakers (rare).	Check all cable connections, especially the power and pedal cables. Move the piano away from other electronic devices. If the problem persists, contact customer support.
Bluetooth connection issues	Bluetooth not enabled on device. Piano not in pairing mode. Device too far from piano.	Ensure Bluetooth is active on your mobile device. Refer to the piano's manual for Bluetooth pairing instructions. Move your device closer to the piano.
Keys feel uneven or unresponsive	Dust or debris under keys. Environmental factors (humidity/temperature). Internal mechanism issue.	Gently clean around the keys. Ensure the piano is in a stable environment. If the issue persists, contact customer support.

SPECIFICATIONS

Feature	Detail
Model Name	REVERIE
Number of Keys	88
Key Action	Weighted Hammer Action
Dimensions (Product)	18.5"D x 50.94"W x 47.38"H (47cm D x 129.4cm W x 120.3cm H)

Feature	Detail
Item Weight	77 pounds (34.9 kg)
Finish Type	Polished
Connectivity Technology	Bluetooth, USB-MIDI
Connector Types	3.5mm Jack, 6.35mm Jack (x2 for headphones), MIDI USB, Mp3 jack
Power Source	Corded Electric
Speakers	Bi-amplified 25W system (2 full-range speakers, 2 tweeters)
Special Features	Hammer Action, Headphone Jack, Weighted Keys, Amber Light Strip, Music Hall Reverb Simulation
Supported Software	Standard MIDI-compatible software

WARRANTY AND CUSTOMER SUPPORT

For warranty information, please refer to the documentation provided with your purchase or visit the official Starfavor website.

If you require technical assistance, have questions about your product, or need to report a defect, please contact Starfavor customer support through their official channels.

- **Online Support:** Visit the [Starfavor Store on Amazon](#) for product information and support resources.
- **Contact Information:** Refer to your purchase receipt or the Starfavor website for direct customer service contact details.

PRODUCT VIDEOS

No official product videos from the seller with relevant metadata (e.g., creator_type: "Seller", m3u8 format) were found in the provided product data to embed in this manual.

