

[Manuals.plus](#) /

› [VINGLI](#) /

› VINGLI Heavy Duty Patio Porch Swing User Manual

VINGLI VL-ClassicalSwing

VINGLI Heavy Duty Patio Porch Swing User Manual

Model: VL-ClassicalSwing | Brand: VINGLI

1. INTRODUCTION

This manual provides essential information for the safe assembly, operation, and maintenance of your VINGLI Heavy Duty Patio Porch Swing. Please read all instructions carefully before use and retain this manual for future reference.



2. SAFETY INFORMATION

WARNING: Maximum weight capacity 880 lbs. Securely anchor the swing to stable supports. Do not use without chains properly loop-locked. Failure to follow these instructions may result in serious injury or property damage.

- Ensure all components are securely fastened before each use.
- Do not exceed the maximum weight capacity of 880 lbs.
- Keep children and pets away from the swing during assembly.
- Regularly inspect chains and connections for wear or damage.
- Install the swing on a level and stable surface.

3. PACKAGE CONTENTS

The exact package contents may vary slightly. Please refer to the packing list included with your product for a detailed inventory. Typically, the package includes:

- Wooden swing bench components (seat, backrest, armrests)
- Adjustable secure chains
- Hardware pack (screws, bolts, washers, carabiners)
- Assembly instructions

4. SETUP AND ASSEMBLY

Assembly of the VINGLI Patio Porch Swing is designed to be straightforward. It is recommended that two persons complete the assembly process.

1. Unpack all components and verify against the packing list.
2. Lay out all wooden parts and hardware on a clean, soft surface to prevent scratches.
3. Attach the armrests to the seat and backrest components using the provided hardware. Do not tighten screws completely at this stage.
4. Connect the adjustable chains to the designated attachment points on the swing bench. Ensure the chains are loop-locked for security.
5. Once all components are loosely assembled, place the swing in its intended location and ensure it is level.
6. Gradually tighten all screws and bolts until secure. Avoid over-tightening.
7. Before first use, perform a thorough check to ensure all connections are tight and the swing is stable.

For Your Porches



Image 4.1: Detailed dimensions of the 5 FT VINGLI porch swing, including length, width, and chain height, useful for planning installation.



Better Flexibility & Security



✓ Carabiner Design

VS



✗ S-Shaped Hooks



Easy to adjust the tilt angle to as your actual needs

Image 4.2: Illustration of the secure carabiner design for chain attachment, offering better flexibility and security.

5. OPERATING INSTRUCTIONS

The VINGLI Patio Porch Swing is designed for comfortable outdoor relaxation.

- **Adjusting the Swing Angle:** The upgraded chains allow you to adjust the angle of the patio swing. By modifying the chain length at the attachment points, you can customize the tilt to your preference for optimal comfort. Ensure both sides are adjusted evenly to maintain balance.
- **Ergonomic Comfort:** The wooden porch swing features curves in the knee area, providing an ergonomic design for a comfortable sitting experience.
- **Seating Capacity:** The swing is designed to accommodate up to three persons, with a maximum weight capacity of 880 lbs.



Image 5.1: Comparison highlighting VINGLI swing features: denser slats for comfort and flexible, adjustable chains for customized use.

Humanized Details



Well-Coated Surface

Painting work will provide better durability



Ergonomical Design

The seat curves in the middle and knee areas

Image 5.2: Close-up view of the swing's well-coated surface and ergonomically designed seat, emphasizing comfort and durability.

6. MAINTENANCE

Proper maintenance will extend the life and appearance of your VINGLI Patio Porch Swing.

- **Cleaning:** The swing features a well-coated surface, making it easy to clean. Wipe down the wooden surfaces with a damp cloth and mild soap as needed. Avoid harsh chemicals that may damage the finish.
- **Inspection:** Periodically inspect all bolts, screws, and chain connections to ensure they remain tight. Re-tighten if necessary.
- **Weather Protection:** While made from high-quality, all-weather resistant solid fir wood, prolonged exposure to extreme weather conditions may affect its longevity. Consider covering the swing during heavy rain, snow, or intense sun, or storing it indoors during off-seasons.



Image 6.1: The well-coated surface of the swing is easy to clean with a damp cloth, ensuring simple maintenance.



Image 6.2: The VINGLI porch swing is constructed from high-quality cedarwood, offering resistance to rain and sunlight for outdoor durability.

7. TROUBLESHOOTING

If you encounter any issues with your VINGLI Patio Porch Swing, please refer to the following common solutions:

- **Swing feels unstable:** Ensure all assembly hardware is fully tightened. Verify that the swing is installed on a level surface and that the hanging supports are secure.
- **Squeaking noises:** Check all metal-on-metal contact points, especially chain connections. Applying a small amount of lubricant to moving parts may resolve the issue.
- **Difficulty adjusting chains:** Ensure the carabiner mechanism is clean and free of debris. If chains are stiff, a lubricant can assist.

For issues not covered here, please contact VINGLI customer support.

8. SPECIFICATIONS

Feature	Specification
Product Dimensions	24.4 x 60.6 x 18.9 inches
Item Weight	38.5 pounds
Manufacturer	VINGLI
ASIN	B0D3F942TG
Item Model Number	VL-ClassicSwing
Color	Rustic
Brand	VINGLI
UPC	810158423435
Max Weight Capacity	880 lbs

9. WARRANTY AND SUPPORT

Specific warranty information is not provided in this manual. For details regarding warranty coverage, returns, or technical support, please refer to the product packaging or contact VINGLI customer service directly through their official website or the retailer where the product was purchased.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D3F942TG>

More documents and user manuals: <https://manuals.plus/>