

[Manuals.plus](#) /

> [iWALK](#) /

> iWALK 4,500mAh Portable Charger User Manual

iWALK LPB4500C

iWALK 4,500mAh Portable Charger User Manual

Model: LPB4500C

INTRODUCTION

Thank you for choosing the iWALK 4,500mAh Portable Charger. This compact and convenient power bank is designed to provide on-the-go charging for your USB-C compatible devices, including iPhone 15/16 series, Samsung Galaxy S22/23/24 series, and other Android smartphones. This manual provides essential information for safe and efficient use of your device.

SAFETY INFORMATION

Please read all safety warnings and instructions before using this product to avoid injury or damage.

- Do not expose the power bank to extreme temperatures (heat or cold), direct sunlight, or high humidity.
- Do not disassemble, modify, or attempt to repair the device yourself. Refer all servicing to qualified personnel.
- Keep the power bank away from water and other liquids.
- Do not drop, puncture, or apply excessive force to the device.
- Use only certified charging cables and adapters.
- Keep out of reach of children.
- Dispose of the power bank responsibly according to local regulations. Do not dispose of it in household waste.

PACKAGE CONTENTS

Verify that all items are present in your package:

- 1x iWALK 4,500mAh Portable Charger
- 1x USB-C to USB-C Cable
- 1x User Manual



Image: Contents of the iWALK 4,500mAh Portable Charger package.

PRODUCT OVERVIEW

The iWALK 4,500mAh Portable Charger features a compact design with a built-in USB-C connector for direct charging.



Image: The iWALK portable charger connected to a smartphone.

Its small size makes it highly portable, fitting easily into pockets or small bags.

The Market's Smallest 4500mAh



Image: Dimensions of the iWALK portable charger, highlighting its compact size.

The device is designed to maintain low heat during operation, ensuring stable and safe charging.

Low-Heat and Stable

Phone and Power Bank No More Overheating




Image: Illustration of the low-heat performance technology.

SETUP

Charging the Power Bank

Before first use, fully charge your iWALK Portable Charger.

1. Connect the provided USB-C to USB-C cable to the USB-C input port on the power bank.
2. Connect the other end of the cable to a compatible USB-C wall adapter (not included).
3. The LED indicator lights on the power bank will illuminate to show the charging status. Once all lights are solid, the power bank is fully charged.

OPERATING INSTRUCTIONS

Charging Your Device

The iWALK Portable Charger is designed for direct connection to your USB-C compatible smartphone.

1. Remove the protective cap from the built-in USB-C connector.
2. Plug the built-in USB-C connector directly into your smartphone's USB-C port.
3. Your device should begin charging automatically. The power bank's LED indicators will show its remaining battery level.

Special Designed for USB-C Port Phones



iPhone 15
Series



Samsung Galaxy
Series



Google Pixel
Series



Motorola
Series



Other Android
Cellphones



Image: Compatibility of the iWALK portable charger with various USB-C devices.

The 4,500mAh capacity provides significant power for your devices.

USB-C Plug in Portable Charger

Play While Charging

iPhone 15 Pro

1.1 times

iPhone 15

0.95 times



Image: Charging capacity examples for iPhone 15 and iPhone 15 Pro.

Pass-Through Charging

The iWALK Portable Charger supports pass-through charging, allowing you to charge both your phone and the power bank simultaneously.

1. Connect your smartphone to the iWALK Portable Charger via its built-in USB-C connector.
2. Connect the iWALK Portable Charger to a wall adapter using the USB-C to USB-C cable.
3. Your phone will charge first, followed by the power bank.

Pass Through Charging

Will Fully Charge Cellphone First,
Then Charge the Power Bank



Image: Illustration of pass-through charging functionality.

MAINTENANCE

Proper care will extend the life of your iWALK Portable Charger.

- Clean the device with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- Store the power bank in a cool, dry place when not in use.
- Avoid fully depleting the battery for extended periods. Recharge it periodically if not used regularly.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Power bank not charging	Cable or adapter issue; power bank fully discharged.	Ensure cable and adapter are working. Try a different cable/adapter. Allow a few minutes for the power bank to respond if deeply discharged.

Problem	Possible Cause	Solution
Device not charging from power bank	Power bank battery low; improper connection; device incompatibility.	Recharge the power bank. Ensure the USB-C connector is fully inserted into your device. Verify your device has a USB-C port and is compatible.
Slow charging	Cable quality; device input limit.	Use the provided USB-C cable or a high-quality alternative. Charging speed may vary depending on the device being charged.
Power bank gets warm during use	Normal operation.	It is normal for the power bank to become slightly warm during charging or discharging. If it becomes excessively hot, disconnect it immediately and contact support.

SPECIFICATIONS

Feature	Detail
Model Number	LPB4500C
Battery Capacity	4,500mAh
Connector Type	Built-in USB Type-C
Recharging Input	USB Type-C (15W support)
Product Dimensions	3.04 x 1.83 x 1.17 inches
Item Weight	2.65 ounces
Special Features	Built-in Cable, LED Indicator Lights, Lightweight, Pocket Size, Low Heat Performance, Pass-Through Charging
Manufacturer	U2O GLOBAL CO.,LTD.

WARRANTY AND SUPPORT

iWALK products come with a standard manufacturer’s warranty. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official iWALK website.

If you encounter any issues or have questions regarding your iWALK Portable Charger, please contact iWALK customer support:

- **Website:** [Visit the iWALK Store on Amazon](#) (for general product information and support links)
- Refer to the contact information provided in your product packaging for direct support channels.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D3FYG6ZS>

More documents and user manuals: <https://manuals.plus/>