SENGBIRCH TB370FU

SENGBIRCH Keyboard Case for Lenovo Tab P12 12.7" (TB370FU) Instruction Manual

1. INTRODUCTION AND OVERVIEW

Thank you for choosing the SENGBIRCH Keyboard Case for your Lenovo Tab P12 12.7" tablet. This product combines a protective case with a detachable Bluetooth keyboard, enhancing your tablet's functionality for typing, work, and entertainment. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal use of your new accessory.

Key Features:

- Detachable Bluetooth 5.0 keyboard for stable and fast connection.
- Durable protective case with precise cutouts.
- Adjustable viewing angles for comfortable use.
- Integrated stylus holder.
- Long-lasting rechargeable battery.

Compatibility: This keyboard case is specifically designed for the **Lenovo Tab P12 12.7" (2023) model TB370FU**. Please verify your tablet's model number before use to ensure proper fit and functionality.

Image 1.1: Compatibility guide for the keyboard case. Ensure your tablet is the Lenovo Tab P12 12.7" (TB370FU).

2. SETUP INSTRUCTIONS

2.1 Charging the Keyboard

Before first use, fully charge the keyboard. Connect the provided USB-C charging cable to the keyboard's charging port and a USB power adapter (not included). The charging indicator light will illuminate during charging and turn off when fully charged.

- Charging Time: Approximately 2-3 hours.
- Continuous Use: Up to 48 hours.
- Standby Time: Over 2 months.

Image 2.1: Keyboard charging port (Type-C) and battery indicators.

2.2 Inserting the Tablet into the Case

1. Gently align your Lenovo Tab P12 12.7" tablet with the case's frame.
2. Press the tablet firmly into the soft inner shell, ensuring all edges are securely seated and cutouts align with ports and buttons.

2.3 Pairing the Bluetooth Keyboard

1. Turn on the keyboard by sliding the 'ON/OFF' switch to the 'ON' position. The power indicator light will briefly illuminate.
2. Press the 'Connect' button on the keyboard. The Bluetooth indicator light will start blinking, indicating it is in pairing mode.
3. On your Lenovo Tab P12, go to **Settings > Bluetooth**.
4. Turn on Bluetooth and search for available devices.
5. Select "Bluetooth Keyboard" (or a similar name) from the list of devices.
6. Follow any on-screen prompts to complete the pairing process. The Bluetooth indicator light on the keyboard will stop blinking once successfully paired.

3. OPERATING INSTRUCTIONS

3.1 Attaching and Detaching the Keyboard

The keyboard is magnetically attached to the case. To attach, simply place the keyboard onto the designated area within the case. To detach, gently pull the keyboard away from the magnetic surface.

Image 3.1: The keyboard can be magnetically detached from the case.

3.2 Adjusting Viewing Angles

The case features an adjustable stand that supports three different viewing angles (130°, 125°, 120°). Simply fold the case cover to create a stable triangular stand and adjust it to your preferred angle for typing, viewing, or drawing.

Image 3.2: Adjustable stand angles for versatile use.

3.3 Keyboard Functions

- **Operating System Switching:** The keyboard supports different operating systems. Use **Fn + Q** for iOS, **Fn + W** for Android, and **Fn + E** for Windows.
- **Backlight Adjustment:** Press **Fn + Light Bulb icon** to cycle through 3 backlight brightness levels. Press **Fn + RGB icon** to change between 7 backlight colors.
- **Special Characters:** Use the **Fn** key in combination with other keys to access special characters, such as the Euro symbol (€) or accent marks (ñ).
- **Automatic Sleep Mode:** To conserve battery, the keyboard will automatically enter sleep mode after approximately 8 minutes of inactivity. Press any key to wake it up.

Tastiera Wireless Español

Image 3.3: Keyboard layout with function key combinations for various settings.

3.4 Stylus Holder

The case includes a dedicated slot for your stylus, ensuring it is securely stored and easily accessible.

Ranura precisa, protección completa

Imperturbable ante golpes y caídas
durante el uso diario

Image 3.4: Integrated stylus holder for convenience.

4. MAINTENANCE

4.1 Cleaning the Case and Keyboard

- Wipe the exterior of the case with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- For the keyboard, use a soft, dry cloth or a can of compressed air to remove dust and debris from between the keys.
- Ensure the keyboard is turned off before cleaning.

4.2 Battery Care

- Recharge the keyboard when the low battery indicator appears or when performance degrades.
- Avoid fully discharging the battery frequently to prolong its lifespan.
- If storing the keyboard for an extended period, charge it to about 50% and store in a cool, dry place.

5. TROUBLESHOOTING

If you encounter issues with your SENGBIRCH Keyboard Case, please refer to the following troubleshooting steps:

5.1 Keyboard Not Connecting/Frequent Disconnections

- **Check Battery:** Ensure the keyboard is sufficiently charged. Low battery can cause connection issues.
- **Re-pair Keyboard:** Delete the "Bluetooth Keyboard" from your tablet's Bluetooth device list and repeat the pairing steps (Section 2.3).
- **Restart Devices:** Turn off and on both your tablet and the keyboard.
- **Interference:** Move away from other wireless devices that might cause interference.

5.2 Keys Not Responding or Sticky Keys

- **Check Battery:** Ensure the keyboard has enough power.
- **Clean Keyboard:** Dust or debris under the keys can cause them to stick. Refer to Section 4.1 for cleaning instructions.
- **Restart Keyboard:** Turn the keyboard off and then on again.

5.3 Tablet Not Fitting Correctly

- **Verify Model:** Double-check that your tablet is indeed the Lenovo Tab P12 12.7" (2023) model TB370FU. This case is not compatible with other models.
- **Proper Insertion:** Ensure the tablet is aligned correctly and gently pressed into all corners of the soft inner shell.

6. SPECIFICATIONS

Brand	SENGBIRCH
Compatible Tablet Model	Lenovo Tab P12 12.7" (2023) TB370FU
Connectivity Technology	Bluetooth 5.0
Keyboard Layout	Spanish (QWERTY)
Battery Type	Rechargeable Lithium Polymer
Charging Time	2-3 hours
Continuous Use Time	Up to 48 hours
Standby Time	Over 2 months
Material	Plastic (keyboard), Faux Leather (case exterior)
Color	Black
Dimensions (Package)	31.2 x 25.1 x 4.1 cm
Weight (Product)	970 g

7. WARRANTY AND SUPPORT

SENGBIRCH products are designed for reliability and performance. For any questions, technical support, or warranty claims, please contact SENGBIRCH customer service through the retailer where you purchased the product or visit the official SENGBIRCH website for contact information.

Please retain your proof of purchase for warranty purposes.