

HUABAO A108

HUABAO Karaoke Machine A108 Instruction Manual

Model: A108

INTRODUCTION

Thank you for choosing the HUABAO Karaoke Machine A108. This portable multimedia speaker system is designed to provide a versatile audio experience with features including Bluetooth connectivity, dual wireless microphones, LED lighting, and multiple input options. Please read this manual carefully to ensure proper setup, operation, and maintenance of your device.

WHAT'S IN THE BOX

Upon unpacking, please ensure all the following items are present:

- 1 x Speaker
- 2 x Wireless Microphones
- 1 x Remote Control
- 1 x Shoulder Strap
- 1 x AUX Cable
- 1 x Type-C Charging Cable
- 1 x User Manual (this document)

LIGHTWEIGHT & PORTABLE

Come with a shoulder strap, portable designs for on-the-go enjoyment



Image: All items included in the HUABAO Karaoke Machine A108 package, including the speaker, two wireless microphones, remote control, shoulder strap, AUX cable, Type-C charging cable, and user manual.

SETUP

1. Charging the Speaker

Before first use, fully charge the speaker using the provided Type-C charging cable. The built-in 5400 mAh rechargeable battery provides 6-8 hours of playtime on a full charge, with a charging time of 4-5 hours.

EXTENDED PLAYTIME WITH HIGH-CAPACITY BATTERY



Built-in 5400mAh
rechargeable battery
keeps the party going
happy never stop



5400mAh

Image: The HUABAO Karaoke Machine highlighting its 5400 mAh high-capacity rechargeable battery for extended playtime.

2. Installing Batteries in Microphones

Each wireless microphone requires 2 AAA batteries (included). Twist the bottom part of the microphone to open the battery compartment, insert the batteries with correct polarity, and close the compartment securely.

3. Attaching the Shoulder Strap

For portability, attach the adjustable shoulder strap to the designated loops on the speaker. This allows for easy carrying during outdoor activities or travel.



Image: Two individuals carrying the lightweight and portable HUABAO Karaoke Machine using its adjustable shoulder strap.

OPERATING INSTRUCTIONS

1. Power On/Off

Locate the power button/volume knob on the control panel. Turn the knob clockwise to power on the speaker and adjust the main volume. Turn counter-clockwise to decrease volume and power off.

2. Mode Selection

Press the "Mode" button on the control panel or remote control to cycle through available input modes: Bluetooth, USB Drive, TF Card, AUX, and FM Radio.

3. Bluetooth Pairing

1. Switch the speaker to Bluetooth mode. The display will show "BLUE" and an audible prompt will confirm.
2. Enable Bluetooth on your smartphone, tablet, laptop, or other compatible device.
3. Search for "HUABAO A108" in the list of available devices and select it to pair.
4. Once paired, an audible confirmation will sound, and you can stream audio wirelessly.

WHAT'S IN THE BOX



Image: The HUABAO Karaoke Machine demonstrating stable wireless connectivity via Bluetooth 5.0 with various devices like phones, tablets, laptops, desktops, and smart TVs.

4. USB Drive / TF Card Playback

Insert a USB flash drive or TF card (containing MP3 files only) into the respective slot. The speaker will automatically switch to the corresponding mode and begin playback. Use the control panel buttons or remote for track navigation (Prev/Next) and Play/Pause.

5. AUX Connection

Connect an external audio device using the provided 3.5mm AUX cable. Switch the speaker to AUX mode. Audio from your external device will play through the speaker.

6. FM Radio

Switch to FM Radio mode. Use the control panel or remote to scan for stations. The speaker will automatically search and save available FM frequencies.

7. Microphone Usage

Turn on the wireless microphones. They will automatically connect to the speaker. Use the dedicated "Mic" volume knob on the speaker to adjust microphone volume. The "Echo" knob controls the echo effect for vocals.

8. LED Lights Control

The speaker features dynamic LED lights that sync to the music. Long press the "Mode/LED" button to change different lighting effects or turn them off.



Image: The HUABAO Karaoke Machine displaying its colorful LED lighting show, which can be adjusted by pressing the Mode/LED button.

9. Treble & Bass Adjustment

Use the dedicated Treble and Bass controls on the speaker's control panel to fine-tune the audio output to your preference.

BEAUTIFUL ATMOSPHERE LIGHTS

5 different light modes make a vibe atmosphere for your party




Image: Close-up of the HUABAO Karaoke Machine's control panel, highlighting the adjustable treble and bass knobs for personalized sound.

10. Using the Remote Control

The remote control allows for convenient operation from a distance, including power on/off, mode selection, volume adjustment, track control, and LED light settings.

Your browser does not support the video tag.

Video: An official HUABAO video demonstrating the features and operation of the A108 karaoke machine, including its two microphones and colorful lights.

Your browser does not support the video tag.

Video: An official seller video showcasing the HUABAO Karaoke Machine with its two wireless microphones, demonstrating its functionality and ease of use.

MAINTENANCE

- Keep the speaker and microphones dry and away from moisture.
- Clean the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Store the device in a cool, dry place when not in use.
- Avoid dropping the device or subjecting it to strong impacts.

TROUBLESHOOTING

Problem	Possible Solution
No power	Ensure the speaker is charged. Check the power knob is turned on.
Microphone not working	Check microphone batteries and ensure they are inserted correctly. Ensure microphone is powered on. Adjust microphone volume knob.
Bluetooth not connecting	Ensure speaker is in Bluetooth mode. Turn off and on Bluetooth on your device. Forget the device and re-pair.
No sound from USB/TF card	Ensure files are in MP3 format. Check if the speaker is in the correct mode. Ensure volume is up.

SPECIFICATIONS

- **Model:** A108
- **Power Source:** Battery Powered (Built-in 5400 mAh rechargeable battery)
- **Output Power:** 15W
- **Subwoofer Size:** 6.5-inch
- **Connectivity:** Bluetooth 5.0, AUX, USB, TF Card (MP3 files only)
- **Microphones:** 2 x Wireless Microphones (2 AAA batteries each)
- **Dimensions:** 9.1 x 5.8 x 13.35 inches
- **Item Weight:** 3.3 Pounds
- **Material:** Plastic
- **Impedance:** 3 Ohms
- **Manufacturer:** HUABAO



ALL-IN-ONE KARAOKE MACHINE

- Bluetooth 5.0
- TF Card
- USB
- FM
- AUX
- Treble & Bass
- Instrument
- Remote
- Colorful Lights

Image: The HUABAO Karaoke Machine showcasing its multiple connectivity options including Bluetooth 5.0, TF Card, USB, AUX, and adjustable Treble & Bass.

SUPERIOR HI-FI SOUND QUALITY

6.5 inch subwoofer
providing you an excellent
auditory experience



Image: The HUABAO Karaoke Machine emphasizing its superior Hi-Fi sound quality with a 6.5-inch subwoofer and 15W power output.

WARRANTY & SUPPORT

HUABAO offers a one-year warranty and lifetime technical support for all customers. If you have any questions or concerns regarding your HUABAO Karaoke Machine A108, please do not hesitate to reach out to our customer service team.

For support, please refer to the contact information provided on the product packaging or the official HUABAO website.