

## HEYNEMO 26 Quart Electric Roaster Oven

# HEYNEMO 26 Quart Electric Roaster Oven Instruction Manual

Model: 26 Quart Electric Roaster Oven



## INTRODUCTION

Thank you for choosing the HEYNEMO 26 Quart Electric Roaster Oven. This appliance is designed to provide efficient and versatile cooking for a variety of dishes, from large turkeys to everyday meals. Please read this manual thoroughly before initial use to ensure safe operation and optimal performance. Keep this manual for future reference.



Image: The HEYNEMO 26 Quart Electric Roaster Oven, showcasing its capacity with a fully roasted turkey and garnishes.

## IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

## COMPONENTS

---

The HEYNEMO Electric Roaster Oven includes the following components:

- Roaster Oven Base
- Removable Roasting Pan
- Removable Roasting Rack
- Self-Basting Lid



# Free Oven To

---

## Prepare Other Dishes

Image: The HEYNEMO Roaster Oven with its removable roasting rack, highlighting the convenient lid rest design.

### SETUP AND FIRST USE

- Unpack:** Carefully remove all components from the packaging. Retain packaging for storage or disposal.
- Initial Cleaning:** Before first use, wash the removable roasting pan, roasting rack, and self-basting lid in warm, soapy water. Rinse thoroughly and dry completely. Wipe the exterior of the roaster oven base with a damp cloth. Do not immerse the base in water.
- Placement:** Place the roaster oven on a stable, heat-resistant surface, away from walls and other appliances, ensuring adequate ventilation. Ensure the power cord is not obstructed or near hot surfaces.
- Pre-Seasoning (Optional):** For optimal performance and to eliminate any manufacturing odors, it is recommended to run the roaster empty for 30 minutes at 350°F (175°C) before first use. Ensure the area is well-ventilated during this process.

### OPERATING INSTRUCTIONS

## Temperature Control and Functions

The HEYNEMO Electric Roaster Oven features a single knob control for simplified operation. The knob allows you to select various temperature settings and specific functions.

# Defrost and Warm Function

**Caution: Hot Surface**



Thawing Turkey



Warm Turkey



Image: The control knob of the roaster oven, illustrating the Defrost, Keep Warm, and temperature settings, with visual examples of their use.

- **Defrost Mode (250°F / 120°C):** This low-temperature setting is designed to quickly thaw frozen ingredients while helping to preserve their original flavor and nutrients.
- **Heat Mode (Up to 450°F / 230°C):** Use this high-temperature setting for cooking and heating various foods. The powerful 1450W heating element ensures quick and even heat distribution.
- **Keep Warm Mode (150°F / 65°C):** This setting maintains food at an ideal serving temperature for extended periods, ensuring meals remain warm until ready to serve.

## General Cooking Process

1. **Prepare Food:** Place your food item, such as a turkey or roast, onto the removable roasting rack.
2. **Insert into Pan:** Carefully place the roasting rack with food into the removable roasting pan.

3. **Place in Base:** Insert the roasting pan into the roaster oven base.
4. **Cover:** Place the self-basting lid onto the roasting pan. The lid's design promotes water circulation, helping to keep food moist and tender.
5. **Set Temperature:** Plug the roaster into a standard 120V AC outlet. Turn the control knob to your desired temperature setting. The indicator light will illuminate when the roaster is heating.
6. **Monitor Cooking:** Cook according to your recipe. The roaster's efficient heating system ensures even cooking.
7. **Finish:** Once cooking is complete, turn the knob to "Off" and unplug the appliance. Use oven mitts to carefully remove the lid, then the roasting pan and rack.

## Temperature Lock Inside



Image: Internal heat circulation within the roaster oven, demonstrating its ability to maintain consistent temperatures for thorough cooking.

# Say NO to Dry Turkey



AIR CYCLE  
HEATING



VISUALIZATION  
TOP



150-450°F  
ADJUSTABLE TEMP



Image: Features of the roaster oven's lid, including air cycle heating and a visualization top, designed to prevent food from drying out.




Image: A visual guide illustrating the process from quick defrosting to enjoying a perfectly baked turkey.

# Keep Warm & Defrost Setting

Adjustable temperature from 150°F-450°F



Image: Detailed view of the adjustable temperature settings for defrosting, roasting, and keeping food warm.

## MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your HEYNEMO Electric Roaster Oven.

- Always Unplug:** Before cleaning, ensure the roaster is unplugged from the power outlet and has completely cooled down.
- Removable Parts:** The roasting pan, roasting rack, and lid are removable and can be washed by hand in warm, soapy water. They are also dishwasher safe. Ensure all food residue is removed.
- Roaster Base:** Wipe the exterior and interior of the roaster oven base with a damp cloth. For stubborn stains, use a mild non-abrasive cleaner. Do not immerse the base in water or any other liquid.
- Drying:** Ensure all parts are thoroughly dry before reassembling or storing the appliance.
- Storage:** Store the roaster oven in a cool, dry place.

## Removable Pan & Liftable Rack



Image: Demonstrates the ease of removing the roasting pan and liftable rack for serving and cleaning.

## TROUBLESHOOTING

If you encounter issues with your HEYNEMO Electric Roaster Oven, please refer to the following common

troubleshooting steps:

- **Appliance Not Turning On:**

- Ensure the power cord is securely plugged into a working electrical outlet.
- Check if the outlet is functional by plugging in another appliance.
- Verify the control knob is turned to a temperature setting and not "Off".

- **Food Not Cooking Evenly:**

- Ensure the lid is properly seated on the roasting pan to maintain consistent internal temperature.
- Avoid opening the lid frequently during cooking, as this can cause heat loss.
- Check that the roaster is not overcrowded, allowing for proper heat circulation around the food.

- **Food is Dry:**

- Ensure the self-basting lid is used correctly to promote moisture retention.
- Consider adding a small amount of liquid (broth, water) to the bottom of the roasting pan, especially for longer cooking times.
- Verify the cooking temperature and time are appropriate for the food item.

- **Smoke or Odor During First Use:**

- A slight smoke or odor during the first use is normal and typically dissipates quickly. This is due to protective coatings burning off. Ensure good ventilation.

If problems persist, please contact customer support.

## SPECIFICATIONS

<b>Brand</b>	HEYNEMO
<b>Model</b>	26 Quart Electric Roaster Oven
<b>Capacity</b>	26 Quarts
<b>Power Source</b>	Electric (1450W, 120V)
<b>Temperature Range</b>	150°F - 450°F (65°C - 230°C)
<b>Control Type</b>	Knob
<b>Product Dimensions</b>	23.35"D x 15.47"W x 14.65"H
<b>Item Weight</b>	17.16 pounds
<b>Color</b>	Black
<b>UPC</b>	789889887215

## WARRANTY AND SUPPORT

### Product Warranty

The HEYNEMO Electric Roaster Oven comes with a **ONE YEAR WARRANTY** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage resulting from misuse, accident, alteration, neglect, or unauthorized repair.

Please retain your proof of purchase for warranty claims.

## Customer Support

For technical assistance, warranty claims, or any questions regarding your HEYNEMO Electric Roaster Oven, please contact our customer support team.




### Contact Information:




- **Email:** [support@heynemo.com](mailto:support@heynemo.com)
- **Website:** [Visit the HEYNEMO Store on Amazon](https://www.amazon.com/heyne-mo)

When contacting support, please have your product model number (26 Quart Electric Roaster Oven) and proof of purchase readily available.



## Related Documents - 26 Quart Electric Roaster Oven

	<p><a href="#"><u>HEYNEMO ZIM005 Slush Machine User Manual</u></a> User manual for the HEYNEMO ZIM005 dual-tank slush machine (Model HJ-7802). This guide provides detailed instructions on operation, safety precautions, ingredient guidelines, cleaning, and troubleshooting for optimal performance.</p>
	<p><a href="#"><u>NESCO ITR-01 Upright Turkey Roaster User Manual   Oil-Free Vertical Roasting Guide</u></a> Comprehensive user manual for the NESCO ITR-01 Upright Turkey Roaster. Learn about setup, operation, cleaning, troubleshooting, and cooking settings for oil-free vertical roasting.</p>
	<p><a href="#"><u>Behmor 2020SR Plus Operations Manual: Gourmet Coffee Roaster</u></a> A comprehensive operations manual for the Behmor 2020SR Plus Gourmet Coffee Roaster, detailing setup, operation, safety precautions, roasting profiles, maintenance, troubleshooting, and warranty information. Learn to master home coffee roasting with this guide.</p>

	<p><b>Coffee Compadre Electric Micro Coffee Roaster: Quick Start &amp; Roasting Guide</b></p> <p>Comprehensive guide to using the Coffee Compadre electric micro coffee roaster. Learn quick start steps, automatic, assistant, and manual roasting modes, safety instructions, and coffee development phases for home and commercial use.</p>
	<p><b>Sunvivi 20QT Roaster Oven User Manual</b></p> <p>User manual for the Sunvivi 20QT Roaster Oven, detailing its features, specifications, operation, safety, cleaning, and cooking guidelines for efficient home cooking.</p>
	<p><b>Butterball Oil Free Turkey Roaster MB23010809: Operation and Safety Manual</b></p> <p>This manual provides essential operation and safety instructions for the Butterball Oil Free Turkey Roaster, model MB23010809. Learn how to safely assemble, operate, clean, and maintain your roaster for optimal outdoor cooking performance.</p>