

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [GOOJODOQ](#) /
- › [GOOJODOQ Portable Turbo Fan User Manual](#)

GOOJODOQ Portable Turbo Fan

# GOOJODOQ Portable Turbo Fan User Manual

Model: Portable Turbo Fan

## 1. INTRODUCTION

Thank you for choosing the GOOJODOQ Portable Turbo Fan. This compact and powerful fan is designed to provide efficient cooling wherever you go, whether for outdoor adventures, travel, or indoor use. Equipped with a high-capacity battery and USB-C fast charging, it offers convenience and long-lasting performance. Please read this manual carefully before using the product to ensure proper operation and maintenance.



Image: The GOOJODOQ Portable Turbo Fan in grey, showcasing its sleek design and the powerful airflow it generates from the front nozzle. A digital display on the fan shows 'AIR VOLUME', '100', and 'POWER'.

## 2. PRODUCT FEATURES

- **Large Capacity Battery:** Integrated 4000 mAh battery provides 2 to 12 hours of continuous operation, depending on the selected wind speed.
- **USB-C Fast Charging:** Type-C port enables quick charging, reaching full capacity in approximately 2.3 hours.
- **Five Adjustable Wind Speeds:** Equipped with advanced brushless motor technology, offering fine wind speed adjustment from 1 to 100, providing five distinct speed options.
- **High-Resolution Digital Display:** Features a digital screen that shows real-time remaining power and current wind speed, allowing for precise control and timely charging.
- **Compact and Portable Design:** Weighing only 225g, its lightweight and compact body, along with a thoughtful anti-loss cable design, makes it easy to carry in a backpack or bag.
- **Versatile Usage:** Ideal for hiking, camping, barbecues, sports, outdoor activities, indoor office use, and general travel.

# Brushless Motor

Low Losses And Long Service Life





Image: An internal view of the fan highlighting the brushless motor and its components, emphasizing low losses and long service life. The diagram also shows the airflow path.

# High Resolution Digital Display



Image: A detailed view of the high-resolution digital display on the fan, clearly indicating 'AIR VOLUME' (wind speed) as '100' and 'POWER' (battery level) with a battery icon.

# 4000mAh High Capacity Battery 2.3H USB-C Fast Charging



Image: An X-ray style view of the fan's handle, revealing the internal 4000mAh high-capacity battery and the USB-C charging port with a charging cable connected, illustrating 2.3 hours fast charging.

## Compact & Portable



Image: A hand demonstrating the compact and portable nature of the fan by easily placing its 225g body into a handbag, highlighting its convenience for travel.

## Anti-Drop Hand Strap



Image: A person outdoors using the GOOJODOQ Portable Turbo Fan, with the anti-drop hand strap securely attached to their wrist, demonstrating safe and convenient use.

### 3. SETUP

1. **Unboxing:** Carefully remove the fan and all accessories from the packaging. Ensure all components are present: the fan unit, USB-C charging cable, and anti-loss hand strap.
2. **Initial Charge:** Before first use, fully charge the fan. Connect the provided USB-C cable to the fan's charging port and the other end to a compatible USB power adapter (not included). The digital display will show charging progress. A full charge takes approximately 2.3 hours.
3. **Attach Hand Strap:** If desired, attach the anti-loss hand strap to the designated loop on the fan's handle for added security during use.

## 4. OPERATING INSTRUCTIONS

1. **Power On/Off:** Press and hold the power button (usually the lower button on the side) for a few seconds to turn the fan on or off. The digital display will illuminate upon activation.
2. **Adjusting Wind Speed:** The fan features five adjustable wind speeds. Use the control buttons (typically '+' and '-' or up/down arrows) on the side of the fan to increase or decrease the wind speed. A short press will adjust the speed by 20%, while a long press allows for continuous adjustment from 1 to 100. The current wind speed will be displayed on the digital screen.
3. **Monitoring Battery and Speed:** The high-resolution digital display provides real-time information. The 'POWER' indicator shows the remaining battery level, and the 'AIR VOLUME' indicator shows the current wind speed setting.
4. **Charging:** When the battery level is low, connect the USB-C charging cable to recharge the fan. The display will indicate charging status.



Image: A close-up view of the fan's button switch, showing the 'up' and 'down' arrows for adjusting wind speed. Instructions indicate a short press for 20% adjustment and a long press for continuous adjustment from 1-100.

## 5. MAINTENANCE

- **Cleaning:** To clean the fan, ensure it is turned off and unplugged. Use a soft, dry cloth to wipe the exterior. Do not use abrasive cleaners or immerse the fan in water. For the air inlet/outlet, use a soft brush or compressed air to remove dust.
- **Storage:** When not in use for extended periods, store the fan in a cool, dry place away from direct sunlight and extreme temperatures. It is recommended to charge the battery to about 50% before storing to prolong battery life.
- **Battery Care:** To maintain battery health, avoid completely draining the battery frequently. Recharge the fan when the battery indicator shows low power.

## 6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not turn on.	Battery is depleted.	Charge the fan using the USB-C cable.
	Power button not pressed correctly.	Press and hold the power button for a few seconds.
Fan is not charging.	USB-C cable or adapter is faulty.	Try a different USB-C cable or power adapter.
	Charging port is dirty.	Gently clean the charging port with a dry, soft brush.
Weak airflow.	Fan speed set too low.	Increase the wind speed using the control buttons.
	Air inlet/outlet blocked by dust.	Clean the air inlet and outlet as described in the Maintenance section.

## 7. SPECIFICATIONS

Feature	Specification
Brand	GOOJODOQ
Model	Portable Turbo Fan
Color	Grey

Feature	Specification
Power Source	USB Powered
Style	Modern
Product Dimensions (D x W x H)	5.9 x 6.1 x 16 cm
Special Feature	Portable
Recommended Uses	Hiking, Camping, BBQ, Sports, Outdoor Activities, Summer Heat, Indoor Office, Travel
Mounting Type	Portable
Controller Type	Button Control
Material	Plastic
Battery Capacity	4000 mAh
Charging Time	Approx. 2.3 hours (USB-C)
Operating Time	2-12 hours (depending on speed)
Weight	225g

## 8. WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the product packaging or contact your point of purchase. If you encounter any issues or have questions regarding your GOOJODOQ Portable Turbo Fan, please contact customer support through the retailer or the official GOOJODOQ website for assistance.

Please retain your proof of purchase for warranty claims.