

KICHLY Airtight Container

KICHLY Airtight Food Storage Containers User Manual

Model: Airtight Container (Pack of 24)

1. INTRODUCTION

Thank you for choosing KICHLY Airtight Food Storage Containers. This 24-pack set is designed to help you organize your kitchen pantry and keep your food fresh. Made from durable, safe plastic, these containers feature airtight, leakproof lids and come with reusable labels for easy identification. Please read this manual carefully to ensure proper use and care of your new storage solution.

2. PRODUCT OVERVIEW

The KICHLY Airtight Food Storage Container set includes 24 containers of various sizes, perfect for diverse storage needs:

- 6 x Tall Containers (2.8L)
- 6 x Large Containers (2.0L)
- 6 x Medium Containers (1.6L)
- 6 x Small Containers (0.8L)

Each container is equipped with a locking lid featuring a unique silicone ring to ensure an airtight and leakproof seal. The set also includes reusable chalkboard labels and a chalkboard marker for convenient content labeling.

Key Features:

- **Airtight & Leakproof:** Lids with silicone seals prevent leaks and keep food fresh.

- **Durable Plastic:** Made from high-quality, safe plastic.
- **Reusable Labels:** Includes chalkboard labels and a marker for easy content identification.
- **Space Efficient:** Stackable design optimizes pantry and kitchen space.



Figure 2.1: Full set of KICHLY airtight food storage containers with various contents and labels.

FEATURES



Figure 2.2: Detailed view of the container lid, showcasing its sealing and locking mechanisms.

AIRTIGHT FOOD CONTAINERS



Perfect for storing flour, sugar, spaghetti, rice, nuts, cereal, snacks, pasta, and more

Figure 2.3: Dimensions and capacities of the KICHLY food storage containers.

3. SETUP

Before first use, it is recommended to wash all containers and lids thoroughly. Follow the cleaning instructions in the 'Maintenance & Care' section.

Applying Labels:

1. Choose a suitable chalkboard label shape for your container.
2. Peel the label from its backing.
3. Apply the label to a clean, dry surface of the container.
4. Use the provided chalkboard marker to write the name of the food item or contents on the label.



Figure 3.1: Customizing containers with reusable chalkboard labels.

4. OPERATING INSTRUCTIONS

Filling and Sealing:

1. Open the four locking clips on the lid.
2. Remove the lid from the container.
3. Fill the container with your desired dry goods, such as cereal, pasta, rice, flour, or snacks.
4. Place the lid back onto the container, ensuring it is properly aligned.
5. Press down firmly on the lid and then snap all four locking clips into place until you hear a click. This ensures an airtight seal.

Storage and Organization:

- Utilize the various container sizes to store different quantities and types of food. Tall containers are ideal for spaghetti or long pasta.
- The clear design allows for easy visibility of contents, even without reading the labels.
- Containers are designed to be stackable, allowing you to maximize vertical space in your pantry,

cabinets, or countertops.



VARIOUS SIZES **MEET ALL YOUR NEEDS**

When not in use, they can inlay together to save more space

Figure 4.1: KICHLY containers accommodating various food items.



REUSABLE CHALKBOARD LABELS



Figure 4.2: Pantry organization before and after using KICHL Y containers.

5. MAINTENANCE & CARE

Proper care will extend the life and effectiveness of your KICHL Y containers.

Cleaning Instructions:

- **Hand Wash Recommended:** For best results and to preserve the integrity of the plastic and silicone seal, hand wash all containers and lids with warm, soapy water.
- **Do Not Dishwash:** These containers are not dishwasher safe. High heat from dishwashers can warp the plastic and compromise the airtight seal.
- **Drying:** Ensure all parts are completely dry before reassembling and storing food to prevent moisture buildup.

Cleaning Labels:

The chalkboard labels can be easily cleaned. Simply wipe them with a damp cloth to erase writing and reuse them for different contents.

6. TROUBLESHOOTING

- **Lid Not Sealing Properly:** Ensure the silicone ring is correctly seated within the lid groove and free from any food debris. Make sure all four locking clips are fully engaged.
- **Labels Not Sticking:** Ensure the container surface is clean and dry before applying labels. If labels lose their stickiness over time, they can be replaced.
- **Container Odor:** If a container retains an odor after washing, try soaking it in a solution of warm water and baking soda for a few hours, then wash and dry thoroughly.

7. SPECIFICATIONS

Feature	Detail
Brand	KICHLY
Model Number	Airtight Container
Material	Plastic (Reusable)
Color	Clear
Container Shape	Rectangular
Closure Type	Clip-On (4-sides locking lids)
Special Feature	Air Tight
Item Package Quantity	1 (Set of 24 containers)
Unit Count	24.0 Count
Capacities Included	2.8L, 2.0L, 1.6L, 0.8L
Recommended Uses	Pet Food, Cake, Spices, Candy, Cereal, Pasta, Coffee
Product Care Instructions	Hand Wash Possible (Not Dishwasher Safe)
Item Weight	9.66 pounds
Country of Origin	Pakistan
UPC	197703000335

8. WARRANTY & SUPPORT

For any questions, concerns, or support regarding your KICHLY Airtight Food Storage Containers, please contact the manufacturer directly through their official website or the retailer where the product was purchased. Specific warranty details may vary and are typically provided with your purchase documentation.