

[Manuals.plus](#) /

› [Shark](#) /

› Shark Rotator Pet Lift-Away ADV Upright Vacuum LA700 User Manual

Shark LA700

Shark Rotator Pet Lift-Away ADV Upright Vacuum LA700 User Manual

Model: LA700

INTRODUCTION

This manual provides essential instructions for the safe and effective operation, assembly, and maintenance of your Shark Rotator Pet Lift-Away ADV Upright Vacuum, model LA700. Please read all instructions carefully before use to ensure optimal performance and longevity of your appliance.

WHAT'S IN THE BOX

Carefully unpack all components and inspect for any damage. Ensure all parts listed below are present.

What's in the box:



Image: The Shark Rotator Pet Lift-Away ADV Upright Vacuum with its primary components and two accessories: an 8-inch Crevice Tool and an Upholstery Tool.

- Main Vacuum Pod with Dust Cup
- Motorized Floor Nozzle (DuoClean PowerFins HairPro)
- Wand
- Handle
- Hose
- 8" Crevice Tool
- Upholstery Tool
- Odor Neutralizer Technology Cartridge (pre-installed or separate)

ASSEMBLY

Follow these steps to assemble your vacuum cleaner:

1. Insert the Wand into the Motorized Floor Nozzle until it clicks securely into place.
2. Slide the Handle into the top of the Wand until it clicks.
3. Place the Vacuum Pod onto the Wand and slide it down towards the Motorized Floor Nozzle until it clicks.
4. Connect the Hose to the back of the Vacuum Pod by pushing it in until it clicks.
5. Store the 8" Crevice Tool and Upholstery Tool on the accessory posts located on the vacuum pod.

6. Ensure the power cord is securely wrapped around the cord hooks for storage.

OPERATING MODES

Your Shark Rotator vacuum offers versatile cleaning modes for different surfaces and tasks.

1. Upright Mode

This mode is for general floor cleaning. Plug in the vacuum, place your foot on the floor nozzle, and tilt the handle back to engage the brushrolls. Use the power switch on the handle to select the appropriate surface setting (Hard Floor or Carpet).

2. Lift-Away Mode

The Lift-Away feature allows you to detach the vacuum pod from the floor nozzle for portable cleaning of stairs, furniture, and other above-floor areas.



Easily detach the pod

Pod-release pedal for easy transitions from on-floor to above-floor cleaning.

Image: A user's foot pressing the pedal located at the base of the vacuum pod, indicating the action to detach the pod for Lift-Away mode.

1. To activate Lift-Away mode, press the red pedal located on the side of the floor nozzle with your foot.
2. Lift the vacuum pod away from the floor nozzle.
3. You can now use the wand with an attached accessory, or detach the wand from the handle to use the hose

directly with an accessory.



Lift away the pod to clean up high

Lift-Away[®] technology lets you detach the pod and clean above the floor.

Image: A woman cleaning a high ceiling corner using the vacuum in Lift-Away mode, holding the wand with an extension.



Lift away the pod to clean stairs

Lift away the pod, remove the wand and nozzle,
and tackle stairs with ease.

Image: A person cleaning carpeted stairs using the vacuum in Lift-Away mode, holding the hose and an attachment.

KEY FEATURES



Image: An annotated diagram highlighting the main features of the Shark Rotator vacuum, such as its Lift-Away capability, Odor Neutralizer, DuoClean PowerFins, HEPA filtration, swivel steering, LED headlights, and self-cleaning brushroll.

- **DuoClean PowerFins HairPro:** This dual-brushroll system is engineered to deeply clean carpets and directly engage hard floors, effectively picking up dirt, debris, and hair in a single pass.
- **No Hair Wrap:** The self-cleaning brushroll is designed to prevent hair from wrapping around it, ensuring consistent performance and reducing maintenance.
- **Odor Neutralizer Technology:** This feature actively guards against unpleasant odors within your vacuum, contributing to a fresher-smelling home environment. The intensity can be adjusted.



Odor Neutralizer Technology

Guards against bad odors inside your vacuum for a fresher-smelling home*.

*Compared to Shark LA700 without Odor Neutralizer Technology.

Image: A close-up view of the Odor Neutralizer Technology cartridge, showing it being handled for insertion or removal from the vacuum.

- **Anti-Allergen Complete Seal Technology with HEPA Filter:** This system traps 99.97% of dust and allergens (0.3 microns and larger) inside the vacuum, preventing them from re-entering the air you breathe.
- **LED Headlights:** Integrated lights on the floor nozzle illuminate hidden debris, making it easier to spot and clean dirt in dimly lit areas.
- **Advanced Swivel Steering:** Provides enhanced maneuverability, allowing you to easily navigate around furniture and into tight spaces.
- **Included Accessories:** The vacuum comes with an 8" Crevice Tool for reaching narrow spaces and an Upholstery Tool for cleaning fabrics and pet hair.



Powerful pet hair pickup

Attachments like the Upholstery Tool make cleaning pet hair a breeze in Lift-Away mode.

Image: A user demonstrating the effective pet hair pickup on a couch using the Upholstery Tool in Lift-Away mode, with a dog observing.



Image: A split image showing the 8-inch Crevice Tool cleaning a narrow gap and the Upholstery Tool cleaning a carpeted stair.

MAINTENANCE

Regular maintenance ensures your vacuum operates efficiently and extends its lifespan.

1. Emptying the Dust Cup

1. Press the dust cup release latch and lift the dust cup off the vacuum pod.
2. Hold the dust cup over a trash bin and press the bottom release latch to open the bottom flap.
3. Tap gently to remove any lodged debris. Close the flap securely.

2. Cleaning Filters

To maintain optimal suction, regularly clean the filters. Rinse filters with cold water only and allow them to air-dry completely for at least 24 hours before reinstalling.

- **Foam and Felt Filters:** Located above the dust cup. Rinse every 3 months.
- **HEPA Filter:** Located at the bottom of the vacuum pod. Rinse once a year.

3. Brushroll Maintenance

Periodically check the brushrolls for any debris, string, or hair that may be wrapped around them. Use scissors to

carefully cut away any obstructions. The self-cleaning brushroll feature minimizes this, but occasional checks are recommended.

4. Odor Neutralizer Cartridge

The Odor Neutralizer Technology cartridge should be replaced periodically to maintain its effectiveness. Refer to the product packaging for replacement frequency. To replace, locate the cartridge slot on the floor nozzle, twist to unlock, remove the old cartridge, and insert a new one, twisting to lock it in place.

TROUBLESHOOTING

If you encounter issues with your vacuum, consult the following common solutions:

- **Vacuum not picking up debris or no suction:**

- Check if the dust cup is full and empty it.
- Inspect filters for clogging and clean them as per maintenance instructions.
- Check for blockages in the hose, wand, or floor nozzle.
- Ensure all connections are securely clicked into place.

- **Brushrolls not spinning:**

- Ensure the vacuum is in the correct floor setting (Carpet mode for brushroll activation).
- Check the floor nozzle for any obstructions preventing the brushrolls from rotating.
- Verify that the vacuum pod is securely attached to the floor nozzle.

- **Vacuum turns off on its own:**

- The vacuum may have overheated. Turn off the vacuum, unplug it, and clear any blockages. Allow it to cool for at least 45 minutes before restarting.
- Ensure filters are clean and dry.

SPECIFICATIONS

Feature	Detail
Brand	Shark
Model Number	LA700
Special Feature	Bagless
Filter Type	Foam, HEPA
Cordless	No
Form Factor	Cannister (Lift-Away)
Controller Type	Push Button
Control Method	Touch
Portable	Yes (Lift-Away mode)
Number of Power Levels	1

Number of Wheels	4
Indoor/Outdoor Usage	Indoor
Product Dimensions	13 x 12 x 45 inches
Item Weight	16.76 pounds
Batteries Required	No

WARRANTY AND SUPPORT

For warranty information, please refer to the warranty card included with your product or visit the official Shark website. For technical support, replacement parts, or service inquiries, please contact Shark customer service directly. Contact details can typically be found on the manufacturer's website or in your product packaging.

