

[Manuals.plus](#) /

› [Apple](#) /

› Apple iPad Pro 13-Inch (M4) User Manual

Apple MVX53LL/A

Apple iPad Pro 13-Inch (M4) User Manual

Model: MVX53LL/A

Brand: Apple

1. INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Apple iPad Pro 13-Inch (M4). Designed for powerful performance and an exceptional visual experience, the iPad Pro features the M4 chip, an Ultra Retina XDR display, and advanced connectivity options.

The iPad Pro is built to enhance productivity and creativity, supporting accessories like the Apple Pencil Pro and Magic Keyboard. It integrates with Apple Intelligence for personalized assistance and offers robust privacy protections.

2. SETUP

2.1. Unboxing and Initial Inspection

Upon opening the packaging, ensure all components are present and undamaged. The box should contain:

- 13-inch iPad Pro
- USB-C Charge Cable (1 m)
- 20W USB-C Power Adapter

Carefully remove the iPad Pro from its packaging. Inspect the device for any physical damage before proceeding.



Figure 2.1: The Apple iPad Pro 13-inch (M4) in Silver, showcasing its sleek design from both front and rear perspectives.

2.2. Powering On and Charging

Before first use, it is recommended to fully charge your iPad Pro. Connect the USB-C charge cable to the iPad's USB-C port and the 20W USB-C Power Adapter. Plug the adapter into a power outlet. The battery icon on the screen will indicate charging status.

To power on the iPad Pro, press and hold the top button until the Apple logo appears.

2.3. Initial Setup Steps

Follow the on-screen instructions to complete the initial setup:

1. **Select Language and Region:** Choose your preferred language and country or region.
2. **Quick Start:** If you have another iOS device, you can use Quick Start to set up your new iPad automatically.
3. **Connect to Wi-Fi:** Select your Wi-Fi network and enter the password. The iPad Pro supports Wi-Fi 6E for fast

wireless connections.

4. **Data & Privacy:** Review Apple's Data & Privacy information.
5. **Face ID:** Set up Face ID for secure authentication and unlocking.
6. **Create a Passcode:** Establish a passcode for additional security.
7. **Transfer Apps & Data:** Choose to restore from iCloud Backup, Mac or PC, or set up as a new iPad.
8. **Apple ID:** Sign in with your Apple ID or create a new one.
9. **Siri & Other Services:** Configure Siri, Screen Time, and other Apple services as desired.

3. OPERATING THE IPAD PRO

3.1. Ultra Retina XDR Display

The 13-inch Ultra Retina XDR display offers extreme brightness, contrast, and exceptional color accuracy. It features ProMotion technology for adaptive refresh rates, P3 wide color, and True Tone for comfortable viewing in various lighting conditions.




Figure 3.1: The Ultra Retina XDR display showcasing its vibrant and detailed visual capabilities.

3.2. M4 Chip Performance

Equipped with the M4 chip, the iPad Pro delivers powerful performance for demanding tasks, from professional applications to high-end gaming. The 10-core CPU and 10-core GPU ensure smooth and responsive operation.




Figure 3.2: Key features of the iPad Pro, including its thin profile, advanced display, M4 chip, and compatible accessories.

3.3. iPadOS and Applications

iPadOS enhances the iPad's productivity and versatility. You can run multiple apps simultaneously, use Scribble with Apple Pencil in any text field, and manage tasks with Stage Manager, which allows for resizable, overlapping apps and external display support.

The App Store offers over a million applications, complementing pre-installed apps like Safari, Messages, and Keynote.

3.4. Cameras and LiDAR Scanner

The iPad Pro features a landscape 12MP Ultra Wide front camera with Center Stage for video conferencing and Portrait mode selfies. The 12MP Wide back camera with adaptive True Tone flash supports capturing photos and 4K video with ProRes. The integrated LiDAR Scanner enhances AR experiences by mapping the depth of any space.

3.5. Connectivity

Wi-Fi 6E provides fast and reliable wireless connections for quick transfers of photos, documents, and large video files. The USB-C connector supports Thunderbolt / USB 4, allowing connection to external displays, drives, and other peripherals.

3.6. Accessories (Sold Separately)

The iPad Pro is compatible with the Apple Pencil Pro and Magic Keyboard, which significantly expand its capabilities.

- **Apple Pencil Pro:** Transforms the iPad into a drawing canvas and note-taking device. It offers advanced features for precision and control.
- **Magic Keyboard for iPad Pro:** Features a thin and light design, a comfortable typing experience, and a built-in glass trackpad with haptic feedback. It also serves as a protective cover.



Figure 3.3: A user interacting with the iPad Pro using an Apple Pencil, demonstrating its creative potential.

3.7. Face ID

Face ID allows you to securely unlock your iPad Pro, authenticate purchases, and sign in to apps with a glance. To use Face ID, ensure your face is clearly visible to the front camera.

4. MAINTENANCE

4.1. Cleaning Your iPad Pro

To clean your iPad Pro, use a soft, lint-free cloth. Avoid abrasive materials, aerosols, solvents, or ammonia. For the screen, a slightly damp cloth is acceptable. Do not spray cleaners directly onto the screen.

4.2. Battery Care

The iPad Pro features an all-day battery life. To maximize battery longevity, avoid exposing the device to extreme temperatures. For long-term storage, charge the battery to about 50% and power off the device. Regular software updates can also optimize battery performance.

4.3. Software Updates

Keep your iPad Pro's software up to date to ensure optimal performance, security, and access to the latest features. Go to **Settings > General > Software Update** to check for and install available updates.

5. TROUBLESHOOTING

5.1. Common Issues and Solutions

- **Device Unresponsive:** If your iPad Pro is unresponsive, force restart it. Press and quickly release the volume up button, press and quickly release the volume down button, then press and hold the top button until the Apple logo appears.
- **Wi-Fi Connectivity Issues:** Ensure your Wi-Fi router is working correctly. Try forgetting the network (Settings > Wi-Fi > [Your Network] > Forget This Network) and rejoining. Restarting both your iPad and router can also resolve issues.
- **Apps Crashing:** Ensure all apps are updated to their latest versions. If an app continues to crash, try deleting and reinstalling it.
- **Battery Draining Quickly:** Check battery usage in Settings > Battery to identify apps consuming significant power. Adjust settings like screen brightness and background app refresh.

5.2. Restoring to Factory Settings

If persistent issues occur, you may consider restoring your iPad Pro to its factory settings. **Warning: This will erase all data on your device.** Back up your iPad Pro to iCloud or your computer before proceeding. Go to **Settings > General > Transfer or Reset iPad > Erase All Content and Settings**.

6. SPECIFICATIONS

Feature	Specification
Product Dimensions	11.09 x 8.48 x 0.2 inches
Item Weight	1.27 pounds
Manufacturer	Apple

Feature	Specification
ASIN	B0D3JB95VD
Country of Origin	China
Item Model Number	MVX53LL/A
Batteries	1 Lithium Ion batteries required (included)
Date First Available	May 7, 2024
Brand	Apple
Model Name	iPad Pro
Memory Storage Capacity	512 GB
Screen Size	13 Inches
Display Resolution Maximum	2752-by-2064-pixel resolution at 264 ppi

7. WARRANTY AND SUPPORT

Your Apple iPad Pro 13-Inch (M4) is covered by Apple's standard limited warranty. For detailed information regarding warranty coverage, terms, and conditions, please refer to the warranty documentation included with your purchase or visit the official Apple support website.

For technical assistance, software support, or service inquiries, please contact Apple Support. You can find contact information and additional resources on Apple's official support pages.

© 2025 Apple Inc. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.