



Manuals.plus /

› KIDISLE /

› Electric Milk Frother User Manual

## KIDISLE MF0802

# Electric Milk Frother User Manual

Model: MF0802 | Brand: KIDISLE

## 1. INTRODUCTION

---

Thank you for choosing the KIDISLE Electric Milk Frother. This versatile appliance is designed to enhance your coffee and beverage experience by providing various milk frothing and heating options. Please read this manual thoroughly before first use to ensure safe and optimal operation.



*Image: The KIDISLE Electric Milk Frother, showcasing its sleek black design, control panel, and included whisks, alongside a prepared cup of frothed coffee.*

## 2. WHAT'S INCLUDED

---

Your package should contain the following items:

- 1 x Electric Milk Frother Unit
- 1 x User Manual (this document)
- 1 x Frothing Whisk
- 1 x Heating Whisk

## 3. KEY FEATURES

---

- **4-in-1 Multi-Functionality:** Prepare Hot Thick Foam, Hot Thin Foam, Hot Milk, and Cold Thin Foam.
- **Customizable Temperature Settings:** Select from 130°F, 140°F, 150°F, and 160°F for personalized beverages.
- **30-Minute Auto-Warming:** Maintains the ideal temperature for an extended period.
- **Real-Time Temperature Display:** Provides precise control during frothing and heating.

- **Whisper-Quiet Operation:** Ensures a peaceful coffee preparation experience.
- **Non-Stick Interior:** Facilitates easy cleaning.



Image: Visual representation of the frother's four functions: Warm Thin Foam, Warm Thick Foam, Warm Milk/Chocolate, and Cold Thick Foam.

## 4. SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Before first use, clean the interior of the frother and the whisks with warm, soapy water. Rinse thoroughly and dry completely. Do not immerse the base unit in water.
3. **Place:** Position the frother on a stable, flat, and dry surface. Ensure it is away from heat sources and direct sunlight.

4. **Insert Whisk:** Select the appropriate whisk for your desired function (frothing or heating) and place it onto the drive shaft at the bottom of the frother's interior. Ensure it is securely seated.



*Image: A hand carefully placing the frothing whisk onto the central pin inside the frother's pitcher.*

5. **Connect Power:** Plug the power cord into a standard electrical outlet.



*Image: The base of the frother, illustrating the power connection point.*

## 5. OPERATING INSTRUCTIONS

---

The control panel features intuitive touch buttons for easy operation.



*Image: A close-up view of the frother's touch-sensitive control panel, highlighting the illuminated icons and temperature display.*

1. **Add Milk:** Pour milk into the frother. Observe the MIN and MAX fill lines inside the pitcher. Do not exceed the MAX line for frothing to prevent overflow, or the MAX line for heating.

# LARGE CAPACITY



Maximum level  
for heating milk



Maximum level  
for frothing milk



Minimum  
liquid level



*Image: The interior of the frother, clearly showing the maximum fill lines for heating and frothing, and the minimum liquid level.*

- Select Function:** Press the function button to cycle through the 4-in-1 options: Hot Thick Foam, Hot Thin Foam, Hot Milk, and Cold Thin Foam. The selected function icon will illuminate.
- Set Temperature:** Press the temperature button to cycle through the available temperature settings: 130°F, 140°F, 150°F, and 160°F. The chosen temperature will be displayed on the screen.

# 4 TEMPERATURE SETTINGS

Room Temp, 130, 140, 150, 160°F



*Image: An illustration demonstrating the four available temperature settings (Room Temp, 130°F, 140°F, 150°F, 160°F) for various beverage preferences.*

4. **Start Operation:** Press the power button to begin the selected function. The frother will operate quietly.
5. **Auto-Warming:** For hot functions, the frother will maintain the set temperature for up to 30 minutes after completion.
6. **Completion:** The frother will automatically stop when the cycle is complete.

## 6. MAINTENANCE

Proper maintenance ensures the longevity and performance of your milk frother.

- **Cleaning:** Always unplug the frother and allow it to cool completely before cleaning. The interior of the frother and the whisks should be cleaned by hand with warm, soapy water.
- **Do Not Immerse:** Do not immerse the main unit or power base in water or any other liquid.

- **Drying:** Ensure all parts are thoroughly dried before reassembly or storage.
- **Storage:** Store the frother in a clean, dry place when not in use.

## 7. TROUBLESHOOTING

If you encounter any issues, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Frother does not turn on.	Not plugged in; Power outage; Unit malfunction.	Ensure power cord is securely plugged in; Check power outlet; Contact customer service if issue persists.
Milk does not froth.	Incorrect whisk used; Too much or too little milk; Type of milk.	Ensure frothing whisk is installed; Adjust milk quantity between MIN/MAX frothing lines; Use fresh, cold milk (dairy or non-dairy alternatives may vary in frothing ability).
Milk is not hot enough.	Incorrect temperature setting; Heating whisk not installed.	Select a higher temperature setting; Ensure heating whisk is installed for heating functions.
Unit stops unexpectedly.	Overheating; Insufficient liquid.	Unplug and let cool for 10-15 minutes; Ensure milk is above MIN line.

If the problem persists after trying these solutions, please contact KIDISLE customer service for assistance.

## 8. SPECIFICATIONS

Attribute	Detail
Brand	KIDISLE
Model Name	MF0802
Special Feature	Variable Temperature Control
Color	Black
Material	Stainless Steel
Recommended Uses	Residential
Included Components	Milk Frother, User Manual, 1 Frothing Whisk, 1 Heating Whisk
Product Care Instructions	Hand Wash Only
Power Source	Corded Electric
Package Dimensions	10.16 x 7.87 x 6.22 inches
Item Weight	2.25 pounds
Date First Available	June 23, 2024

## 9. WARRANTY AND SUPPORT

This product comes with a 2-year warranty. For any product issues, questions, or support needs, please

contact KIDISLE customer service. Refer to the contact information provided in your product packaging or on the official KIDISLE website.