Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Boscznorp Boscznorp Smart Tracker

Boscznorp Smart Tracker User Manual

Model: Boscznorp Smart Tracker

1. Product Overview

The Boscznorp Smart Tracker is a compact, lightweight device designed to help you locate your important items using Apple's "Find My" network. It is compatible exclusively with iOS devices (iPhone, iPad, Apple Watch) and features a replaceable battery for extended use.



Image: The Boscznorp Smart Tracker, a small, black, square-shaped device with rounded corners, featuring the "Boscznorp" logo on its surface.

Key Features:

- **Apple "Find My" Network Integration:** Utilize the extensive Apple network for long-distance tracking.
- **Easy Pairing:** Quick and simple pairing with your iOS device.
- **Audible Alert:** Activate a sound (80dB) to locate items within approximately 15 meters (50 feet).
- **Anti-Loss Notifications:** Receive alerts if you leave an item behind (requires notification settings to be enabled).
- **Replaceable Battery:** Powered by a CR2032 battery with an average life of 1 year. Battery status can be checked via the "Find My" app.

- **Privacy Protection:** Location data and personal information are not stored on the tag or accessible by Apple or the manufacturer. Only you can access your item's location information.

2. Package Contents

- 1 x Boscznorp Smart Tracker
- 1 x Keychain
- 1 x User Manual

Your browser does not support the video tag.

Video: Unboxing the Boscznorp Smart Tracker and its contents, including the tracker, keychain, and user manual. The video also demonstrates pressing the button on the tracker.

3. Setup and Pairing

Follow these steps to pair your Boscznorp Smart Tracker with your iOS device:

1. **Activate the Smart Tracker:** Press and hold the button on the Boscznorp Smart Tracker for 3 seconds until you hear a beep sound. This turns the device on.
2. **Enable "Find My" and Bluetooth:** On your iPhone or iPad, ensure that the "Find My" app is installed and enabled, and Bluetooth is turned on.
3. **Add Item in "Find My" App:**
    - Open the "Find My" app.
    - Tap on the "**Items**" tab.
    - Tap "**Add Item**" or the "**+**" icon.
    - Select "**Other Supported Item**".
4. **Connect the Tracker:** The app will begin searching for nearby compatible devices. Once "Boscznorp" appears, tap "**Connect**".
5. **Customize Your Tracker:** After connecting, you will be prompted to enter a name for your item and select an emoji or icon. Tap "**Continue**" or "**Done**" to complete the pairing process.



Image: Visual guide showing the steps to pair the Boscznorp Smart Tracker with the "Find My" app, including opening the app, adding an item, and connecting the tracker.

Important Note: *This device is compatible with iOS only. Android devices are not supported. Ensure your iOS device's network settings (Wi-Fi and mobile network) are stable for optimal performance.*

4. Operating Your Smart Tracker

4.1 Locating Your Item

To find an item attached to your Boscznorp Smart Tracker:

- Open the "Find My" app on your iOS device.
- Navigate to the "**Items**" tab.
- Select your Boscznorp Smart Tracker from the list.

- Tap "**Play Sound**" to make the tracker emit an audible alert (80dB) if it's within Bluetooth range (approx. 15 meters). Tap "**Stop Sound**" once found.
- If the item is out of Bluetooth range, the "Find My" app will display its last known location on a map, utilizing the Apple "Find My" network for long-distance tracking. You can tap "**Directions**" to get navigation to the item's location.



Image: The Boscznorp Smart Tracker shown with sound waves emanating from it, alongside an iPhone screen displaying the "Find My" app with the "Play Sound" option highlighted.



Image: An iPhone screen showing a map with navigation directions, illustrating the remote tracking capability of the Boscznorp Smart Tracker.

4.2 Anti-Loss Notifications (Left Behind Alerts)

To receive alerts when you leave an item behind:

- In the "Find My" app, go to the "**Items**" tab and select your Boscznorp Smart Tracker.
- Under the "**Notifications**" section, enable "**Notify When Left Behind**".
- You will receive an alert on your iOS device if the tracker moves out of range from your device.



Image: A Boscznorp Smart Tracker attached to a backpack, with a "Time Sensitive: 'Emily's Bag' left behind" notification displayed on an iPhone screen.

4.3 Lost Mode

If your item is truly lost, you can enable Lost Mode:

- In the "Find My" app, select your Boscznorp Smart Tracker.
- Scroll down to "**Lost Mode**" and tap "**Enable**".
- Follow the on-screen instructions to enter a contact phone number or email address.
- If someone finds your item, they can use their iPhone to scan the tracker and see your contact information.
- When Lost Mode is enabled, "Notify When Found" is automatically activated.

5. Maintenance

5.1 Battery Replacement

The Boscznorp Smart Tracker uses a replaceable CR2032 coin cell battery. The battery typically lasts for over one year. You can check the battery status in the "Find My" app.

To replace the battery:

1. Locate the small groove on the side of the tracker.
2. Carefully open the tracker by inserting a small tool (like a coin or a flat-head screwdriver) into the groove and twisting gently.
3. Remove the old CR2032 battery.
4. Insert a new CR2032 battery with the positive (+) side facing up.
5. Align the two halves of the tracker and press firmly until it clicks securely into place.



Image: A diagram illustrating the dimensions of the Boscznorp Smart Tracker (35mm x 35mm x 5mm) and highlighting its replaceable battery feature and 80dB sound capability.

6. Troubleshooting

6.1 Pairing Issues

- **Tracker Not Found:** Ensure the tracker is turned on (press and hold the button for 3 seconds until it beeps). Make sure Bluetooth is enabled on your iOS device.
- **Pairing Failure:** If pairing fails, try resetting the Boscznorp Smart Tracker (see section 6.2).
- **Network Issues:** If you experience network problems, try switching between Wi-Fi and mobile data on your smartphone.

6.2 Resetting Your Boscznorp Smart Tracker

If you need to reset your tracker or pair it with a new Apple ID:

1. **Remove from "Find My" App:**
    - Open the "Find My" app.
    - Go to the "**Items**" tab.
    - Select the Boscznorp Smart Tracker you wish to remove.
    - Scroll down and tap "**Remove Item**" or "**Remove**". Confirm your choice.
2. **Hard Reset (if necessary):** If the above step doesn't work or for a complete reset, press the button on the tracker twice quickly. After the second beep, press and hold the button for approximately 5 seconds until you hear a new sound. This indicates the device has been reset and is ready for new pairing.

7. Specifications

Brand	Boscznorp
Model	Boscznorp Smart Tracker
Dimensions (L x W x T)	35 mm x 35 mm x 5 mm
Material	Plastic
Battery Type	1 x CR2032 (included, replaceable)
Average Battery Life	1 year
Sound Level	80 dB
Sound Range	Approx. 15 meters (50 feet)
Control Method	"Find My" App (iOS)
Compatible Devices	iPhone, iPad (iOS 14.5 or later)
Manufacturer	JiangXi Kingtron Technology Co.,Ltd
ASIN	B0D3KP7JHZ

UPC	774882313243

8. Warranty and Support

The Boscznorp Smart Tracker comes with a **1-year warranty** from the date of purchase.

If you encounter any issues or have questions regarding your product, please contact our customer support. We are committed to providing satisfactory solutions.

Contact information for support can typically be found on the product packaging or the retailer's website where you purchased the item.

9. Important Safety Information

- **KEEP BATTERIES OUT OF REACH OF CHILDREN:** Swallowing a button battery can cause serious injury or death in as little as 2 hours. Seek immediate medical attention if a battery is swallowed.
- Do not attempt to disassemble or modify the device beyond battery replacement.
- Avoid exposing the device to extreme temperatures, direct sunlight, or water (it is not waterproof).
- Dispose of batteries and the device according to local regulations.

© 2024 Boscznorp. All rights reserved.
Apple, Apple Watch, iPhone, iPad, iPadOS, Mac, macOS, and "Find My" are trademarks of Apple Inc., registered in the U.S. and other countries and regions.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D3KP7JHZ

More documents and user manuals: **https://manuals.plus/**