

YUMAZLA PT05

YUMAZLA 71-inch Extendable Phone Tripod (Model PT05) Instruction Manual

Your guide to setting up and using your YUMAZLA tripod.

[Setup](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

1. SETUP GUIDE

Follow these steps to correctly set up your YUMAZLA 71-inch Extendable Phone Tripod.


1.1 Unpacking and Initial Assembly

1. Carefully remove all components from the packaging. You should find the main tripod unit, a smartphone holder, and a Bluetooth remote control.
2. Locate the smartphone holder. It features a 1/4-inch screw thread at its base.
3. Attach the smartphone holder to the top of the tripod pole by screwing it clockwise until secure. Ensure it is firmly attached to prevent your device from falling.

71-inch Ultra-high Tripod



Ours



Others



Image: The YUMAZLA 71-inch Extendable Phone Tripod, showing the main unit, detachable phone holder, and Bluetooth remote control.



Image: Close-up of the multi-functional cell phone holder, highlighting its compatibility with 3.7"-7" smartphones, and 1/4 standard screws for accessories like GoPro, cameras, or ring lights.

1.2 Deploying the Tripod Base

1. Hold the tripod by the main pole. Gently pull the legs outwards from the base until they are fully extended and locked into position. The wide leg design ensures stability.
2. Ensure all three legs are evenly spread on a flat surface for maximum stability.

YUMAZLA



Image: Step 1 - Screw the phone holder to the right onto the tripod pole.

STEP 1

Screw to the right



Image: The tripod base with legs extended, illustrating the wider and longer design for enhanced stability.

1.3 Pairing the Bluetooth Remote

1. The Bluetooth remote control is conveniently stored within the tripod leg. Gently slide it out.
2. Turn on the remote control. An indicator light will begin to blink, signifying it is in pairing mode.
3. On your smartphone, go to Bluetooth settings and search for available devices. Select "YUMAZLA Remote" (or similar) to pair. The indicator light will stop blinking once successfully paired.

Embeddable Remote Control

Simple to find, convenient and practical



Image: The detachable Bluetooth remote control, shown stored within the tripod leg for easy access and storage.

2. OPERATING INSTRUCTIONS

Learn how to effectively use your tripod for various photography and videography needs.

2.1 Adjusting Height and Angle


1. To extend the tripod pole, simply pull the sections upwards to your desired height. The tripod can extend up to 71 inches (180 cm).
2. To adjust the angle of your smartphone, loosen the knob on the smartphone holder, position your device as desired (horizontal or vertical), and then tighten the knob to secure it.



STEP 2
Extend to a suitable height



Image: Step 2 - Extend the tripod pole to achieve the desired height for your shot.



3 STEP Rotate to desired angle




Image: Step 3 - Rotate the phone holder to achieve either horizontal or vertical shooting angles.

2.2 Using the Remote Control

Once paired, open your smartphone's camera app. Use the remote control to remotely trigger photos or start/stop video recording. This allows for hands-free operation, ideal for group shots or self-portraits.



Image: The tripod in use with the detachable wireless remote, enabling hands-free photography and videography.

2.3 Versatile Usage Modes

The YUMAZLA tripod supports multiple modes:

- **Tripod Mode:** For stable shots on any flat surface.

- **Selfie Mode:** Collapse the legs and extend the pole for a selfie stick.
- **Handheld Mode:** Use the collapsed unit as a stable grip for vlogging or action shots.

3

MODELS

Meet your different needs



Selfie Mode



Handheld Mode



Tripod Mode



Image: Illustration of the three primary usage modes: Selfie Mode (extended pole), Handheld Mode (compact), and Tripod Mode (legs extended).



Image: Example of using the tripod for a horizontal shot, ideal for landscapes or wide scenes.



Image: Example of using the tripod for a vertical shot, suitable for portraits or social media content.



Vertical shot



Image: Example of using the tripod for an overhead shot, useful for product photography or cooking videos.

Your browser does not support the video tag.

Video: A demonstration of the 71-inch Phone Tripod and Selfie Stick, including its detachable remote, showcasing its versatility for various uses.

3. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your tripod.

- **Cleaning:** Wipe the aluminum parts with a soft, dry cloth. Avoid abrasive cleaners or solvents.
- **Storage:** When not in use, collapse the tripod to its most compact size and store it in a dry place away from extreme temperatures.
- **Remote Battery:** The remote control uses 1 Lithium Metal battery. Replace as needed.

4. TROUBLESHOOTING

If you encounter any issues, refer to the following common solutions:

- **Remote Control Not Connecting:**
 - Ensure the remote control is charged or has a fresh battery.
 - Verify Bluetooth is enabled on your smartphone.
 - Unpair and re-pair the remote control in your phone's Bluetooth settings.
 - Ensure the remote is within range of your device.
- **Tripod Instability:**
 - Ensure all three legs are fully extended and locked into position on a flat, stable surface.
 - Avoid placing heavy devices beyond the specified weight limit.
- **Phone Holder Not Gripping Securely:**
 - Ensure your smartphone is within the compatible width range (max 9cm).
 - Tighten the screw on the phone holder firmly after positioning your device.

5. SPECIFICATIONS

Feature	Detail
Brand	YUMAZLA
Model Name	YMPT05
Item Model Number	PT05
Maximum Height	71 inches (180 Centimeters)
Material	Aluminum
Item Weight	1.45 pounds (0.66 Kilograms)
Weight Limit	1.1 Pounds
Compatible Devices	Smartphone (max width 9cm)
Tripod Head Type	Ball Heads
Special Feature	1.8m phone tripod, Multi-function Phone Holder, Portable
Batteries	1 Lithium Metal battery required (for remote)

6. WARRANTY & SUPPORT

For detailed warranty information, please refer to the "Warranty Card" included in your product packaging. This card contains specific terms and conditions regarding your product's warranty coverage.

If you require further assistance or have questions not covered in this manual, please contact YUMAZLA customer support through their official website or the contact information provided in your product documentation.