

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Monster](#) /

› [Monster Wireless Earbuds, Achieve 300 AirLinks Headphones User Manual](#)

Monster MH2005

Monster Achieve 300 AirLinks Wireless Earbuds User Manual

Model: MH2005

Brand: Monster

INTRODUCTION

This manual provides comprehensive instructions for the safe and efficient use of your Monster Achieve 300 AirLinks Wireless Earbuds. Please read this manual thoroughly before using the product and retain it for future reference.

The Monster Achieve 300 AirLinks are designed for an immersive audio experience with advanced features such as Bluetooth 5.3 connectivity, touch controls, and a long-lasting battery.

PACKAGE CONTENTS

Ensure all items are present in the package:

- Monster Achieve 300 AirLinks Wireless Earbuds (Left and Right)
- Charging Case
- USB-C Charging Cable
- Multiple Sizes of Ear Tips
- User Manual (This document)



Figure 1: Contents of the Monster Achieve 300 AirLinks package. This image displays the earbuds, their charging case, a USB-C charging cable, various sizes of silicone ear tips, and the included quick start guide/user manual.

PRODUCT OVERVIEW

Familiarize yourself with the components of your Monster Achieve 300 AirLinks Wireless Earbuds.



Figure 2: Overview of the Monster Achieve 300 AirLinks earbuds and their charging case. The image shows the compact black charging case with its lid open, revealing the charging slots for the left and right earbuds. One earbud is shown outside the case, highlighting its design and ear tip.

Earbud Components:

- **Touch Control Area:** For managing playback, calls, and voice assistant.
- **LED Indicator:** Displays pairing status and battery level.
- **Microphone:** For calls and voice commands.
- **Ear Tip:** Ensures a secure and comfortable fit, and optimal sound isolation.

Charging Case Components:

- **Charging Indicators:** Shows the case's battery level.
- **USB-C Charging Port:** For charging the case.

SETUP

1. Initial Charge

Before first use, fully charge the earbuds and the charging case.

1. Place both earbuds into the charging case.
2. Connect the USB-C charging cable to the port on the back of the charging case and the other end to a USB power source (e.g., wall adapter, computer USB port).
3. The LED indicators on the case will illuminate to show charging status. They will turn solid or off when fully charged.



Figure 3: The USB-C charging port on the Monster Achieve 300 AirLinks charging case, illustrating how to connect the charging cable for power input.



Figure 4: Battery life and fast charging capabilities. The earbuds offer 8 hours of playback on a single charge, with the charging case providing an additional 24 hours, for a total of 32 hours. A quick 10-minute charge via USB-C yields 2 hours of listening time.

2. Pairing with a Device

1. Open the charging case. The earbuds will automatically enter pairing mode, indicated by flashing LED lights on the earbuds.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for "Monster Achieve 300 AirLinks" in the list of available Bluetooth devices.
4. Select it to connect. Once connected, the earbud LEDs will stop flashing and remain solid or turn off, and you will hear an audible confirmation.

BLUETOOTH 5.3

Fast Connection

Easy- Stable



Figure 5: Bluetooth 5.3 connectivity for fast and stable connections. The image illustrates the seamless pairing process between the earbuds and a mobile device, showing the earbuds listed as "Monster Achieve 300 AirLinks" in the Bluetooth settings.

Note: The earbuds will automatically reconnect to the last paired device when taken out of the case, if Bluetooth is enabled on the device.

OPERATING INSTRUCTIONS

Wearing the Earbuds:

For optimal sound quality and comfort, ensure the earbuds are worn correctly.

1. Identify the Left (L) and Right (R) earbuds.
2. Gently insert the earbud into your ear canal and twist slightly to secure it.
3. Adjust the ear tip size if necessary to achieve a snug fit. A proper seal is crucial for bass response and noise isolation.

32 Hours of Play time

8 Hrs
Single charge

24 Hrs
Long time battery life



FAST CHARGING:
Type-C 10min charge = 120min playtime

Figure 6: Proper way to wear the Monster Achieve 300 AirLinks earbud. The image shows an earbud correctly seated in the ear, ensuring comfort and optimal audio performance.

CORRECT WAY TO WEAR BLUETOOTH EARBUDS



THE WRONG WAY TO WEAR BLUETOOTH EARBUDS



NOTE: Incorrect wearing method of BluetoothEarbuds results in no sound during calls.

Figure 7: Visual guide demonstrating the correct and incorrect methods for wearing Bluetooth earbuds. The correct method shows the earbud securely fitted, while the incorrect method shows it loosely placed, which can lead to poor sound quality during calls.

Touch Controls:

The Monster Achieve 300 AirLinks feature intuitive touch controls on each earbud.

SMART TOUCH CONTROL

Control music and calls with your finger tap



Figure 8: Smart Touch Control functions. This diagram shows the touch-sensitive area on the earbud and its corresponding actions: Volume Up/Down, Previous/Next Track, Play/Pause, Answer/Hang Up calls, and Voice Assistant activation.

Touch Control Functions

Action	Function
Single Tap (L/R)	Play/Pause Music, Answer/End Call
Double Tap (Right)	Next Track
Double Tap (Left)	Previous Track
Triple Tap (Right)	Volume Up
Triple Tap (Left)	Volume Down
Long Press (2s) (L/R)	Activate Voice Assistant, Reject Call

MAINTENANCE

Cleaning:

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove ear tips and clean them with mild soap and water, then dry thoroughly before reattaching.
- Do not use abrasive cleaners or solvents.

Storage:

When not in use, store the earbuds in their charging case to protect them and ensure they remain charged.

Water Resistance:

The earbuds are IPX6 water-resistant, meaning they can withstand high-pressure water jets. This makes them suitable for workouts and light rain. However, they are not designed for submersion in water.



Figure 9: IPX6 Water Resistance. The image depicts the earbuds being exposed to water splashes, highlighting their resistance to sweat, water, and rain, making them suitable for active use.

TROUBLESHOOTING

Common Issues and Solutions

Issue	Possible Cause	Solution
Earbuds not pairing	Not in pairing mode, out of range, or previously paired.	Ensure earbuds are in pairing mode (flashing LEDs). Place them closer to the device. Forget "Monster Achieve 300 AirLinks" in your device's Bluetooth settings and re-pair.
No sound or low volume	Low battery, incorrect fit, device volume too low.	Charge earbuds and case. Adjust earbud fit and try different ear tip sizes. Increase volume on both earbuds and your connected device.
Intermittent connection	Interference, distance from device, obstacles.	Move closer to your device. Avoid physical obstructions between earbuds and device. Restart both earbuds and the device.
Microphone not working	Earbud not properly connected, microphone blocked.	Ensure earbuds are fully connected. Check for debris blocking the microphone port.

If issues persist, please refer to the [Support and Warranty](#) section.

SPECIFICATIONS

Monster Achieve 300 AirLinks Specifications

Feature	Detail
Model Name	MH2005
Connectivity Technology	Wireless (Bluetooth 5.3)
Headphones Form Factor	In Ear
Special Feature	Touch Control
Included Components	User Manual
Control Type	Media Control
Water Resistance Level	IPX6 Water Resistant
Frequency Range	20 Hz - 20,000 Hz
Item Weight	0.13 Kilograms (approx. 4.6 ounces)
Battery Life (Earbuds)	Up to 8 hours (single charge)
Total Playtime (with case)	Up to 32 hours
Charging Port	USB-C
Manufacturer	Jonter

Feature	Detail
UPC	810079706280



Figure 10: Internal structure of the earbud. This detailed view highlights the 10mm titanium diaphragm dynamic driver, responsible for natural sound and deep bass, and the integrated Bluetooth 5.3 chip for stable connectivity.

SUPPORT AND WARRANTY

For technical support or warranty inquiries, please contact Monster customer service. Refer to the official Monster website or the contact information provided in your product packaging for the most up-to-date support details.

Warranty Information: This product typically comes with a manufacturer's warranty covering defects in materials and workmanship. Please retain your proof of purchase for warranty claims.

Protection Plans: Extended protection plans may be available for purchase. Check with your retailer for details on 2-Year or 3-Year protection plans.

IMPORTANT SAFETY INFORMATION

-
- Do not expose earbuds or case to extreme temperatures.
 - Avoid dropping or subjecting the product to strong impacts.
 - Do not disassemble or attempt to repair the product yourself. This will void the warranty.
 - Use only the provided charging cable or a certified USB-C cable.
 - Prolonged exposure to high volume levels may cause hearing damage.

OFFICIAL PRODUCT VIDEOS

Watch these official videos for additional guidance and demonstrations.

No official seller videos are available for this product at this time.

© 2024 Monster. All rights reserved.
For more information, visit the [Monster Store](#).