

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Jectse](#) /

› [Jectse Open Ear Bluetooth V5.3 EDR Air Conduction Sports Headset Instruction Manual](#)

Jectse Jectsewt52xo68vi-11

Jectse Open Ear Bluetooth V5.3 EDR Air Conduction Sports Headset User Manual

Model: Jectsewt52xo68vi-11

1. PRODUCT OVERVIEW

The Jectse Open Ear Bluetooth V5.3 EDR Air Conduction Sports Headset is designed for comfort and performance during physical activities. Its open-ear design allows for environmental awareness while providing clear audio. This manual provides essential information for the proper use and maintenance of your headset.



Figure 1: Front view of the Jectse Open Ear Bluetooth Headset.

2. PACKAGE CONTENTS

- 1 x Jectse Open Ear Bluetooth Headset
- 1 x Charging Cable



Figure 2: Headset and included charging cable.

3. SETUP

3.1 Initial Charging

1. Connect the provided charging cable to the charging port on the headset.
2. Plug the other end of the charging cable into a standard USB power adapter (not included) or a computer's USB port.
3. Allow approximately 1.5 hours for a full charge. The indicator light will change to show charging status (refer to product-specific light indicators if available).

3.2 Power On/Off

- **To Power On:** Press and hold the power button (location may vary, typically on one of the ear units) until the indicator light illuminates.
- **To Power Off:** Press and hold the power button until the indicator light turns off.

3.3 Bluetooth Pairing

1. Ensure the headset is fully charged and powered off.
2. Press and hold the power button for approximately 5-7 seconds until the indicator light flashes rapidly (typically blue and red, indicating pairing mode).
3. On your smartphone, tablet, or other Bluetooth-enabled device, navigate to the Bluetooth settings.
4. Search for available devices. The headset should appear as "Jectse Headset" or a similar name.
5. Select the headset from the list to connect. Once connected, the indicator light will typically flash slowly or turn solid blue.
6. If prompted for a password, enter "0000" (four zeros).

4. OPERATING INSTRUCTIONS

4.1 Wearing the Headset

The headset features an open-ear design with a flexible band that rests behind your neck, and the ear units sit comfortably over your ears without blocking the ear canal. This design ensures stability during movement and allows you to remain aware of your surroundings.



Figure 3: Back view of the headset, showing the neckband design.

4.2 Basic Functions

- **Play/Pause:** Press the multi-function button once.
- **Next Track:** Double-press the multi-function button.
- **Previous Track:** Triple-press the multi-function button.
- **Volume Up:** Press the Volume + button.
- **Volume Down:** Press the Volume - button.

- **Answer/End Call:** Press the multi-function button once during an incoming call or during an active call.
- **Reject Call:** Press and hold the multi-function button for 2 seconds during an incoming call.
- **Activate Voice Assistant:** Press and hold the multi-function button for 2 seconds (when not on a call).

4.3 Comfort and Stability

The ultra-light design and skin-friendly frame ensure comfort for extended wear, making it ideal for running and various workouts. The secure fit prevents the earphones from falling out even during intense physical activity, while the open-ear design enhances situational awareness.



Figure 4: The headset's lightweight design, suitable for active use.

5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe the headset. Avoid using abrasive cleaners or solvents.
- **Storage:** Store the headset in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Resistance:** The headset is waterproof. However, avoid prolonged submersion in water. Ensure the charging port is dry before charging.

- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the headset regularly, even if not in use for extended periods.

6. TROUBLESHOOTING

- **Headset won't turn on:** Ensure the battery is charged. Connect to the charging cable and try again after a few minutes.
- **Cannot pair with device:**
 - Ensure the headset is in pairing mode (indicator light flashing rapidly).
 - Turn off and on your device's Bluetooth.
 - Delete the headset from your device's Bluetooth list and attempt to re-pair.
 - Ensure the headset is within the operating range (up to 15 meters/49 feet).
- **No sound or low volume:**
 - Check the volume levels on both the headset and your connected device.
 - Ensure the headset is properly connected to your device.
 - Try playing audio from a different application or source.
- **Intermittent connection:**
 - Move closer to your connected device to reduce interference.
 - Avoid obstacles between the headset and your device.
 - Ensure no other strong wireless signals are causing interference.

7. SPECIFICATIONS

Feature	Specification
Model Number	Jectsewt52xo68vi-11
Material	Acrylonitrile Butadiene Styrene (ABS)
Bluetooth Version	V5.3 EDR
Supported Modes	HFP/HSP/A2DP/AVRCP
Operating Range	Over 15 meters (49 feet)
Battery Capacity	80 mAh Lithium Battery
Music Playback Time	≥8 hours (at 70% volume)
Standby Time	≥300 hours
Charging Time	1.5 hours
Water Resistance Level	Waterproof
Weight	44 Grams
Compatible Devices	Smartphones, iOS, Android, Tablets, Laptops, any device with Bluetooth 5.3 or higher

8. WARRANTY AND SUPPORT

Information regarding specific warranty terms and support contact details is not available in the provided product data. Please refer to the retailer or manufacturer's website for the most current warranty information and customer support options.

© 2025 Jectse. All rights reserved.