

Arzum OK0026-K

ARZUM OKKA RICH SPIN PRO TURKISH COFFEE MACHINE

Model: OK0026-K | Brand: Arzum

INTRODUCTION

Welcome to the user manual for your new ARZUM OKKA RICH SPIN PRO Turkish Coffee Machine. This appliance is designed to prepare authentic Turkish coffee, milk coffee, and hot chocolate with ease and precision. Please read this manual carefully before first use to ensure safe operation and optimal performance.



Image: The ARZUM OKKA RICH SPIN PRO Turkish Coffee Machine displayed with several prepared coffee and milk-based beverages, showcasing its versatility.

IMPORTANT SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and/or injury to persons.

- Read all instructions before use.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire,

electric shock, or injury to persons.

- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

PRODUCT OVERVIEW

Familiarize yourself with the components of your ARZUM OKKA RICH SPIN PRO Turkish Coffee Machine.





Image: Side view of the ARZUM OKKA RICH SPIN PRO Turkish Coffee Machine, highlighting its sleek chrome design and compact form factor.





Image: Front view of the ARZUM OKKA RICH SPIN PRO, showing the main body and the removable stainless steel pot.



Image: Top-down view of the control panel, featuring the central rotary knob and various function icons for different beverage types.





Image: Rear view of the ARZUM OKKA RICH SPIN PRO, showing the power cord connection and ventilation.

Key Components:

- **Main Unit:** Houses the heating element and control electronics.
- **Stainless Steel Pot:** Removable pot for brewing coffee and preparing milk-based drinks.
- **Control Panel:** Features a central rotary knob and touch-sensitive buttons for various functions.
- **Measuring Spoon:** For precise coffee dosage.

SETUP

Unboxing and Initial Cleaning:

1. Carefully remove all packaging materials and dispose of them responsibly.
2. Wipe the exterior of the main unit with a damp cloth.
3. Wash the stainless steel pot and measuring spoon with warm, soapy water. Rinse thoroughly and dry completely. Do not wash the main unit under running water or immerse it.

First Use:

1. Place the appliance on a stable, flat, heat-resistant surface.
2. Ensure the stainless steel pot is properly seated in the main unit.
3. Plug the power cord into a grounded electrical outlet.
4. Fill the pot with water up to the maximum level indicator (without coffee or milk).
5. Select a brewing program (e.g., Turkish coffee) and let the machine complete a cycle with just water. This cleans the internal components.
6. Discard the water and rinse the pot. Your machine is now ready for use.

OPERATING INSTRUCTIONS

The ARZUM OKKA RICH SPIN PRO offers multiple functions for various beverages.

Preparing Turkish Coffee:

1. Add water to the stainless steel pot according to the desired number of cups (max 5 cups).
2. Add one level measuring spoon of finely ground Turkish coffee per cup.
3. Optionally, add sugar to taste.
4. Place the pot into the main unit.
5. Turn the rotary knob to select the "Turkish Coffee" program.
6. Press the central button to start brewing. The machine will automatically stir and brew the coffee to perfection, signaling when ready.
7. Carefully pour the coffee into cups.

Preparing Milk Coffee / Hot Chocolate:

The machine also features functions for milk-based beverages, including frothing and heating milk.

1. Add milk to the stainless steel pot, observing the maximum fill line for milk.
2. For hot chocolate, add chocolate powder or pieces. For milk coffee, you may add instant coffee or espresso.
3. Place the pot into the main unit.
4. Turn the rotary knob to select the desired milk program (e.g., "Milk Coffee", "Hot Chocolate", "Milk Frothing").
5. Press the central button to start the program. The machine will heat and/or froth the milk as per the selected function.
6. Once complete, carefully pour the prepared beverage.

MAINTENANCE

Daily Cleaning:

- After each use, unplug the machine and allow it to cool down.
- Remove the stainless steel pot. Wash it with warm, soapy water and a soft sponge. Rinse thoroughly and dry.
- Wipe the exterior of the main unit with a damp cloth. Do not use abrasive cleaners or scouring pads.
- Ensure no liquid enters the electrical components.

Descaling:

Depending on water hardness, descaling may be required periodically to maintain performance. Use a descaling solution suitable for coffee machines or a mixture of white vinegar and water (1:2 ratio).

1. Fill the pot with the descaling solution up to the maximum level.
2. Place the pot in the machine and run a full brewing cycle (without coffee/milk).
3. Discard the solution and rinse the pot thoroughly.
4. Run 2-3 cycles with fresh water to remove any residual descaling solution.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Machine does not turn on.	Not plugged in; power outage; faulty outlet.	Check power cord connection; check circuit breaker; try a different outlet.
Coffee is not hot enough.	Insufficient water; machine needs descaling.	Ensure correct water level; perform descaling procedure.
Coffee overflows.	Too much coffee/water; pot not seated correctly.	Do not exceed max fill line; ensure pot is securely placed.
Milk does not froth properly.	Type of milk used; milk temperature; machine needs cleaning.	Use cold, fresh milk (full-fat works best); ensure pot is clean.

SPECIFICATIONS

Feature	Detail
Brand	Arzum
Model Number	OK0026-K
Color	Chrome
Dimensions (L x W x H)	19 x 25 x 34 cm
Weight	200 grams
Capacity	5 Tasses (Cups)
Power	700 Watts

Feature	Detail
Voltage	230 Volts
Material	Stainless Steel
Special Features	Foamy milk coffee, slow brake function, overflow protection, milk frother, temperature control, stainless steel jug.
Coffee Maker Type	Turkish Coffee Machine

WARRANTY AND SUPPORT



Your ARZUM OKKA RICH SPIN PRO Turkish Coffee Machine is covered by a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions. For technical support, troubleshooting assistance, or spare parts inquiries, please contact Arzum customer service. Contact details can typically be found on the manufacturer's official website or on the warranty documentation.

Keep your purchase receipt as proof of purchase for warranty claims.

© 2024 Arzum. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

Related Documents

	<p>Arzum OKKA Rich Spin Pro Kullanım Kılavuzu</p> <p>Arzum OKKA Rich Spin Pro Türk Kahvesi Makinesi kullanım kılavuzu. Bu kılavuz, cihazın güvenli kullanımı, özellikleri, bakımı ve çeşitli pişirme modları hakkında detaylı bilgi içerir.</p>
	<p>Arzum OKKA Minio Jet Turkish Coffee Machine User Manual and Guide</p> <p>Comprehensive user manual for the Arzum OKKA Minio Jet Turkish coffee machine, detailing operation, safety, maintenance, and brewing tips for authentic Turkish coffee.</p>

	<p>Arzum OKKA Rich Spin M Türk Kahvesi Makinesi Kullanım Kılavuzu</p> <p>Arzum OKKA Rich Spin M Türk Kahvesi Makinesi kullanım kılavuzu. Bu kılavuzda cihazın güvenli kullanımı, teknik özellikleri, temizliği ve bakımı hakkında detaylı bilgiler bulunmaktadır.</p>
	<p>Arzum Okka Minio Türk Kahvesi Makinesi Kullanım Kılavuzu</p> <p>Arzum Okka Minio Türk Kahvesi Makinesi için kapsamlı kullanım kılavuzu, güvenlik talimatları, teknik özellikler, kullanım önerileri, temizlik ve bakım bilgileri.</p>

Documents - Arzum – OK0026-K



[\[pdf\]](#) User Manual Instructions

RICH SPIN PRO arzum okka rich spin pro turk kahvesi makinesi ok0026 destek tr manuals |||

RICH SPIN PRO KULLANMA KILAVUZU INSTRUCTION MANUAL

GEBRAUCHSANWEISUNG MANUEL D INSTRUCTIONS D ... a Arzum yetkili

servisine bavurunuz. 2 ARZUM OKKA RICH SPIN PRO TR OKKA RICH SPIN PRO

OK0026 / **OK0026-K** NDEKLER 1. NEML GVENLK UYARILARI 4 2. MAKNENN

GENEL VE TEKNK ZELLKLER 8 3. MAKNENN KUL...

lang:id score:36 filesize: 1.79 M page_count: 128 document date: 2023-07-15