

Phomemo TP88

Phomemo TP88 Tattoo Transfer Stencil Printer User Manual

Model: TP88

1. PRODUCT OVERVIEW

The Phomemo TP88 Tattoo Transfer Stencil Printer is a compact, portable thermal printer designed for tattoo artists and enthusiasts. It utilizes HD thermal technology to produce clear tattoo stencils without the need for ink. The device supports both A4 and US Letter size transfer paper and offers wide compatibility with smartphones (iOS and Android) via Bluetooth and PCs (Windows, Mac OS, Chrome OS, Linux) via USB connection. Its built-in 1200 mAh battery ensures long-lasting operation, capable of printing up to 140 sheets on a full charge.

Key features include:

- **Wireless Connectivity:** Bluetooth for smartphones and USB for PCs.
- **Inkless Thermal Printing:** High-definition stencils without ink cartridges.
- **Portable Design:** Compact and lightweight for easy transport.
- **Wide Paper Compatibility:** Supports A4 and US Letter size tattoo transfer paper.
- **Anti-Wrinkle Function:** Designed to prevent paper rolling during printing.
- **Powerful Mobile App:** Features image editing, cropping, and tattoo preview functions.

2. WHAT'S IN THE BOX

Upon unboxing your Phomemo TP88 Tattoo Transfer Stencil Printer, you should find the following items:

- 1x Phomemo TP88 Tattoo Transfer Stencil Printer
- 10x Thermal Transfer Paper sheets
- 1x Type-C Charging Cable
- 1x Docking Station (USB-A to USB-C adapter)
- 1x Velvet Pouch for carrying
- 1x Quick Start Guide

Phomemo TP88 Tattoo Machine

NEW FASHION DESIGN




Image: The Phomemo TP88 printer shown with its accessories, including transfer paper, charging cable, adapter, and velvet pouch.

Your browser does not support the video tag.

Video: An unboxing demonstration of the Phomemo TP88 tattoo machine, showcasing all included components.

3. SETUP AND PAPER LOADING

Follow these steps to prepare your TP88 printer for use:

1. **Power On:** Press and hold the power button on the printer until the indicator light turns on.

2. **Open Printer:** Press the two side buttons simultaneously to open the printer cover.

3. **Prepare Transfer Paper:**

- Remove the yellow backing paper from the thermal transfer sheet.
- Carefully peel off the transparent protective paper.

4. **Load Paper:** Insert the white transfer paper (with the white side facing up) into the printer's paper slot until it is gently gripped by the rollers. Ensure the paper is aligned straight to prevent misprints.

High-Definition Resolution




Image: Visual instructions demonstrating how to prepare and load the thermal transfer paper into the TP88 printer.

Your browser does not support the video tag.

Video: A demonstration of preparing and loading Phomemo tattoo thermal paper into the printer.

4. OPERATING INSTRUCTIONS

4.1. Printing from a Smartphone (Bluetooth)

1. **Download App:** Download the "Phomemo" app from the App Store (iOS) or Google Play Store (Android).
2. **Connect via Bluetooth:** Open the Phomemo app and enable Bluetooth on your smartphone. Search for and select "TP88" from the list of available devices to connect.
3. **Select/Edit Design:** Within the app, you can choose from massive material templates, upload your own images, or use the free editing tools to adjust, crop, or splice designs. The app also allows you to convert pictures into transfer lines and preview tattoo patterns.
4. **Print:** Adjust print parameters as needed within the app, then initiate printing. The printer will feed the paper and create your stencil.




Image: A smartphone screen showing the Phomemo app interface with options for editing and printing, connected to the TP88 printer.

Printing from phone or tablet

Download App "Phomemo"

The image illustrates the Phomemo app's functionality for printing from a mobile device. A man is shown using his smartphone to interact with the app, which is displayed on a large screen overlay. The app interface includes options for 'Free Editing', 'Image cutting', and 'Tattoo preview'. A Bluetooth icon is shown near the man's phone, indicating the connection method. The printer, a TP88 model, is shown printing a purple skull design. The printer is surrounded by tattoo supplies, including ink bottles and a tattoo machine. In the top right corner, there are logos for Google Play and the App Store. In the bottom right corner, a 'Bluetooth Connection' box shows icons for Android and iOS.

Image: Detailed view of the Phomemo app's features, including tattoo library, image cutting, and tattoo preview.

4.2. Printing from a Computer (USB)

1. **Download Driver:** Visit the official Phomemo website (pages.phomemo.com/#/TP88) to download the appropriate driver for your operating system (Windows, Mac OS, Chrome OS, or Linux).
2. **Install Driver:** Follow the on-screen instructions to install the printer driver on your computer.
3. **Connect Printer:** Connect the TP88 printer to your computer using the provided Type-C charging cable. If your computer lacks a USB-A port, use the included docking station (USB-A to USB-C adapter).
4. **Print:** Open your desired image or design on your computer, select the TP88 printer from your print options,

and initiate printing.



Image: A laptop connected to the Phomemo TP88 printer, demonstrating the process of printing a tattoo stencil from a computer.

Your browser does not support the video tag.

Video: A step-by-step guide on how to use the Phomemo TP88 tattoo machine to print stencils via a computer connection.

5. MAINTENANCE

To ensure the longevity and optimal performance of your Phomemo TP88 printer, regular maintenance is recommended:

- **Cleaning:** Periodically clean the paper path and thermal print head with a soft, lint-free cloth. If necessary, use a small amount of isopropyl alcohol on the cloth for stubborn residue, ensuring the printer is powered off and disconnected from power.
- **Storage:** Store the printer in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** For extended storage, ensure the battery is charged to approximately 50-70% to maintain battery health. Avoid fully discharging the battery for long periods.
- **Paper Handling:** Always use high-quality thermal transfer paper designed for stencil printers. Store paper in its original packaging to protect it from light and moisture.

6. TROUBLESHOOTING

If you encounter issues with your Phomemo TP88 printer, consider the following common solutions:

- **Printer Not Powering On:** Ensure the printer is fully charged. Connect it to a power source using the provided Type-C cable and a standard 5V/2A (10W) charger.
- **Poor Print Quality:**
 - Check if the thermal transfer paper is loaded correctly (white side up).
 - Ensure the paper is not wrinkled or damaged.
 - Clean the thermal print head as described in the Maintenance section.
 - Verify the image resolution and settings in the app or computer driver.
- **Connection Issues (Bluetooth):**
 - Make sure Bluetooth is enabled on your smartphone and the printer is within range.
 - Restart both the printer and your smartphone.

- Ensure no other devices are interfering with the Bluetooth connection.
- Re-pair the device through the Phomemo app.
- **Connection Issues (USB):**
 - Verify that the USB cable is securely connected to both the printer and the computer.
 - Ensure the correct printer driver is installed and updated for your operating system.
 - Try a different USB port or cable.
- **Paper Jam:** Power off the printer, gently open the cover, and carefully remove any jammed paper. Ensure no small pieces of paper remain inside before closing the cover and powering on.

7. SPECIFICATIONS

Feature	Detail
Model Number	TP88
Product Dimensions	12.2 x 1.57 x 2.64 inches
Weight	2.47 Pounds
Battery	1 Lithium Polymer battery (1200 mAh), included
Printing Technology	Thermal (Inkless)
Paper Compatibility	A4, US Letter size thermal transfer paper
Connectivity	Bluetooth (iOS, Android), USB (Windows, Mac OS, Chrome OS, Linux)
Included Components	TP88 Tattoo Machine, 10x Thermal Transfer Paper, Type-C Charging Cable, Docking Station, Velvet Pouch
Color	Black
Water Resistance Level	Not Water Resistant

8. WARRANTY AND SUPPORT

For any product inquiries, technical support, or warranty claims, please contact Phomemo customer service:

- **Email:** bestservice2012@outlook.com
- **Tel:** +1 833 879 0321 (Toll Free)
- **WhatsApp:** +1 971 476 7804
- **Office Hours:** Monday - Friday, 9 AM - 5 PM (EST)

Please refer to your purchase documentation for specific warranty details.

