

Nobleza Professional Pet Blower 2000W

Nobleza Professional Pet Blower 2000W Instruction Manual

Model: Professional Pet Blower 2000W

INTRODUCTION

Thank you for choosing the Nobleza Professional Pet Blower 2000W. This powerful and efficient pet dryer is designed to significantly reduce drying time for your pets, providing professional grooming results at home or in a salon. Please read this manual carefully before use to ensure safe and optimal performance of your device.

SAFETY INFORMATION

To prevent injury or damage, always follow these basic safety precautions:

- Read all instructions before using the appliance.
- Do not operate the pet blower near water or in wet conditions.
- Always unplug the appliance when not in use and before cleaning.
- Keep the power cord away from heated surfaces.
- Do not allow children to operate this appliance.
- Ensure the air inlets and outlets are clear of obstructions during operation.
- Never point the airflow directly into the pet's eyes, ears, or sensitive areas for extended periods.
- Monitor the pet's skin temperature to prevent overheating.
- If the power cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.

PACKAGE CONTENTS

Verify that all items are present in the package:

- Nobleza Professional Pet Blower unit
- Flexible hose (2 meters extensible)
- 4 Interchangeable Nozzles:

- Flat nozzle (for sweeping away mixture/general drying)
 - Round nozzle (for maximizing drying area)
 - Narrow flat nozzle (for deep air blowing)
 - Comb nozzle (for quick drying and detangling)
- Instruction Manual (this document)



The Nobleza pet blower unit, flexible hose, and the four distinct nozzles included in the package.

PRODUCT OVERVIEW

The Nobleza Professional Pet Blower features a robust design for efficient and comfortable pet grooming.

- **High Power Motor:** 2000W for fast and effective drying.
- **Adjustable Airflow:** Stepless speed control from minimum to maximum.
- **Adjustable Temperature:** Three temperature settings (Cool 30°C, Warm 50°C, Hot 60°C) with a cycling mode.

- **Low Noise Operation:** Designed for quiet performance, operating at $\leq 75\text{dB}$, with claims of $< 55\text{dB}$.
- **Ergonomic Design:** Features an insulated handle on the hose for comfortable grip and a portable handle on the unit.
- **Durable Hose:** 2-meter extensible, heat-resistant hose.
- **Washable Filter:** Easy to remove and clean for consistent performance.
- **Anti-Slip Bottom:** Ensures stability during use.



The Nobleza Professional Pet Blower 2000W unit.



Key features of the Nobleza Pet Blower, highlighting its ergonomic and functional design elements.

Professional High-Speed Pet Dryer



Control panel with wind speed adjustment, cycling mode, and temperature indicator.

More Quiet

Insulated Handle

30db

<55db

80db

85db

The pet blower is designed for quiet operation, making grooming more comfortable for pets.

SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Attach Hose:** Connect the flexible hose securely to the air outlet on the main unit. Ensure it clicks into place or is firmly twisted on, depending on the connection type.
3. **Select Nozzle:** Choose the appropriate nozzle for your grooming needs and attach it to the end of the hose. The nozzles are designed for quick and easy interchangeability.
4. **Position Unit:** Place the pet blower on a stable, flat surface, ensuring the air inlets are not obstructed.
5. **Connect Power:** Plug the power cord into a suitable electrical outlet.

OPERATING INSTRUCTIONS

1. **Power On:** Turn the wind speed adjustment knob clockwise to power on the unit and begin airflow. Continue turning to increase the wind speed.
2. **Adjust Wind Speed:** Rotate the knob to select the desired airflow intensity. Start with a lower speed for sensitive pets or areas, gradually increasing as needed.
3. **Select Temperature:** Press the "Cycling Mode" button to cycle through the temperature settings:
 - **Cool (30°C):** For initial drying or sensitive areas.
 - **Warm (50°C):** Standard drying temperature.
 - **Hot (60°C):** For faster drying of thick coats, use with caution and monitor pet comfort.

The LED indicator will show the current temperature setting.

4. **Drying Technique:**

- Begin drying from the pet's back, moving towards the tail and legs.
- Keep the nozzle moving constantly to avoid concentrating heat in one spot.
- Use the appropriate nozzle for different tasks:
 - **Flat nozzle:** Ideal for general drying and removing excess water.
 - **Round nozzle:** Maximizes drying area for large sections of coat.
 - **Narrow flat nozzle:** For targeted, deep air blowing into dense undercoats.
 - **Comb nozzle:** Helps to detangle and quick-dry simultaneously.
- For optimal results and pet comfort, ensure the pet is towel-dried as much as possible before using the blower.

5. **Estimated Drying Times:**

How Long to Dry a Dog



Small Breed Dogs

Short hair **5-10mins**
long hair **10-15mins**



Medium Breed Dogs

Short hair **15-25mins**
long hair **25-35mins**



Large Breed Dogs

Short hair **35-45mins**
long hair **45-55mins**

Approximate drying times vary by breed size and hair length.

- **Small Breed Dogs:** Short hair 5-10 mins, Long hair 10-15 mins.
- **Medium Breed Dogs:** Short hair 15-25 mins, Long hair 25-35 mins.
- **Large Breed Dogs:** Short hair 35-45 mins, Long hair 45-55 mins.

6. **Power Off:** Turn the wind speed adjustment knob counter-clockwise until it clicks off. Unplug the unit from the power outlet.

3-Temperature Adjustable Settings

2-Temperature Cycling Modes



The pet blower offers three adjustable temperature settings for versatile drying.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your pet blower.

- Clean Filter:** The air filter should be cleaned regularly, especially after each heavy use, to prevent clogging and maintain airflow.
 - Unplug the unit from the power outlet.
 - Locate the filter cover, usually at the rear of the unit.
 - Remove the filter cover and carefully take out the filter.
 - Clean the filter by shaking off loose hair and debris, or by washing it with mild soap and water. Ensure the filter is completely dry before reinserting.
 - Replace the filter and secure the cover.
- Clean Nozzles and Hose:** Wipe down nozzles and the hose with a damp cloth to remove any residue.

3. **Storage:** Store the pet blower in a dry, cool place, away from direct sunlight and out of reach of children and pets.

TROUBLESHOOTING

If you encounter any issues, refer to the following troubleshooting guide:

Problem	Possible Cause	Solution
Unit does not turn on.	Not plugged in; power outlet issue; unit switch off.	Ensure the power cord is securely plugged into a working outlet. Check the power switch/knob is in the 'on' position.
Low airflow or weak performance.	Clogged air filter; obstructed hose/nozzle.	Clean the air filter. Check the hose and nozzle for any blockages.
Unit overheats or shuts off.	Blocked air vents; prolonged use; internal fault.	Ensure air inlets/outlets are clear. Allow the unit to cool down. If the problem persists, contact customer support.
Unusual noise during operation.	Loose component; foreign object inside.	Turn off and unplug the unit. Inspect for any visible foreign objects. If noise persists, contact customer support.

If the problem cannot be resolved using the above solutions, please contact Nobleza customer support.

SPECIFICATIONS

Feature	Detail
Model	Professional Pet Blower 2000W
Power	2000W
Temperature Settings	3 (Cool 30°C, Warm 50°C, Hot 60°C)
Speed Settings	Adjustable (Min to Max)
Noise Level	≤75dB (claimed <55dB in some conditions)
Hose Length	2 meters (extensible)
Nozzles Included	4 (Flat, Round, Narrow Flat, Comb)
Dimensions (Package)	41 x 31.4 x 25 cm
Weight (Package)	4.68 kg

WARRANTY AND SUPPORT

The Nobleza Professional Pet Blower 2000W comes with a **12-month warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use.

For warranty claims, technical support, or any questions regarding your product, please contact Nobleza customer service. Please have your purchase receipt and product model information ready when contacting support.

You can find contact information on the official Nobleza website or through your retailer.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question