Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Invicta 47527

Invicta Racing Men's 52mm Electronic Digital Watch Model 47527 Instruction Manual

Model: 47527

1. Introduction and Overview

This manual provides detailed instructions for the Invicta Racing Men's 52mm Electronic Digital Watch, Model 47527. This timepiece is designed for durability and functionality, featuring a digital display and water resistance suitable for various activities. Please read this manual thoroughly to understand the watch's features and ensure proper use and maintenance.



Figure 1.1: Invicta Racing Men's 52mm Electronic Digital Watch (Model 47527)

Key Features:

- **Case Size:** 52mm, designed for a prominent wrist presence.
- **Movement Type:** Digital for precise timekeeping.
- **Water Resistance:** 100 meters (10 ATM), suitable for swimming and snorkeling.

- **Band Material:** Durable Polyurethane with a buckle clasp.
- **Crystal Type:** Mineral Crystak, scratch-resistant for enhanced durability.
- **Display:** Digital display showing time, day, and date, with backlight functionality.

2. Safety Precautions

This manual contains important instructions that should be strictly followed at all times not only for optimal use, but to prevent any injuries to yourself, other persons or property. We encourage you to read the entire booklet and understand the meaning of the symbols below:

Symbol	Meaning
DANGER	Warning (caution) symbol followed by instructions that should be followed or precautions that should be observed.
CAUTION	Warning (caution) symbol followed by prohibited matters.

Battery Safety:

- **INGESTION HAZARD:** This product contains a button cell or coin battery. Ingestion can cause severe internal chemical burns in as little as 2 hours, leading to serious injury or death.
- KEEP new and used batteries OUT OF REACH OF CHILDREN.
- Seek immediate medical attention if a battery is suspected to be swallowed or inserted inside any part of the body.
- This product is intended to be opened only by professionals for battery replacement.
- Remove and immediately recycle or dispose of used batteries according to local regulations.
- Do NOT dispose of batteries in household trash or incinerate.
- Even used batteries may cause severe injury or death.
- Non-rechargeable batteries are not to be recharged.
- Do not force discharge, recharge, disassemble, heat above manufacturer's specified temperature rating, or incinerate. Doing so may result in injury due to venting, leakage, or explosion.

Water Resistance:

Refer to the watch dial and/or the case back for the indication of your watch's water resistance. The Invicta Racing Model 47527 is water resistant to 100 meters (10 ATM). This rating means the watch is suitable for recreational swimming and snorkeling, but not for diving. Avoid operating buttons underwater to prevent water ingress.

Storage:

Avoid storing the watch in places with strong magnetic fields, as this can affect the accuracy of the digital movement.

3. Product Components and Display

Familiarize yourself with the various parts of your Invicta Racing watch to ensure proper operation.



Figure 3.1: Watch Face and Buttons

Buttons:

- **LIGHT Button (Top Left):** Activates the backlight for visibility in low-light conditions.
- **MODE Button (Bottom Left):** Cycles through different display modes (Time, Alarm, Stopwatch, Timer).
- **START Button (Top Right):** Used to start/stop functions like the stopwatch or to adjust settings.
- **RESET Button (Bottom Right):** Used to reset functions or confirm settings.

Digital Display:

The digital display shows the following information:

- Day of the week (e.g., MON, TUE)
- Time (Hour, Minute, Second)
- Date (Month, Day)
- Indicators for Alarm (AL), Chronograph (CHRONO), and Timer (TIMER) modes.



Figure 3.2: Watch Features Diagram

4. Setup Instructions

Follow these steps to set the time and date on your watch.

Setting Time and Date:

1. From the normal time display, press the**MODE** button repeatedly until the seconds begin to flash. This indicates you are in setting mode.
2. Press the **START** button to cycle through the settings: seconds, hour, minute, month, day, day of the week.
3. While a value is flashing, use the **RESET** button to increase the value. Hold the**RESET** button to quickly advance the value.
4. Once all settings are correct, press the**MODE** button to exit the setting mode and return to the normal time display.

Setting the Alarm:

1. From the normal time display, press the**MODE** button until "AL" (Alarm) appears on the display and the alarm hour flashes.
2. Press the **RESET** button to adjust the alarm hour.
3. Press the **START** button to move to the alarm minute setting.
4. Press the **RESET** button to adjust the alarm minute.

5. Press the **MODE** button to confirm the alarm setting and return to the normal time display.
6. To activate/deactivate the alarm, in alarm mode, press the **START** button. An alarm icon will appear/disappear to indicate its status.

5. Operating Instructions

Learn how to use the various functions of your Invicta Racing watch.

Changing Display Modes:

Press the **MODE** button to cycle through the following display modes:

- Normal Time Display (shows time, day, date)
- Alarm Mode (AL)
- Stopwatch Mode (ST)
- Timer Mode (TR)

Using the Stopwatch:

1. Press the **MODE** button until "ST" (Stopwatch) appears on the display.
2. Press the **START** button to begin timing.
3. Press the **START** button again to pause timing.
4. Press the **RESET** button to clear the stopwatch to zero.
5. To resume timing after pausing, press the **START** button.

Using the Timer:

1. Press the **MODE** button until "TR" (Timer) appears on the display.
2. To set the timer, ensure the timer is stopped (if running). Press and hold the **RESET** button until the timer digits flash.
3. Use the **START** button to select hours, minutes, or seconds. Use the **RESET** button to adjust the value.
4. Once the desired countdown time is set, press the **MODE** button to exit setting mode.
5. Press the **START** button to begin the countdown.
6. Press the **START** button again to pause the countdown.
7. Press the **RESET** button to reset the timer to its set value.

Activating the Backlight:

Press the **LIGHT** button (top left) to illuminate the display for a few seconds, improving visibility in dark environments.

6. Maintenance

Proper care and maintenance will extend the life and functionality of your watch.

Cleaning:

- Wipe the watch case and band regularly with a soft, damp cloth to remove dirt and sweat.
- For stubborn dirt, use a mild soap solution and rinse thoroughly with clean water. Ensure the watch is completely dry

before wearing.

- Avoid using harsh chemicals, solvents, or abrasive cleaners, as these can damage the watch's materials.

Battery Replacement:

When the display becomes dim or the watch stops functioning, the battery may need replacement. Due to the specialized nature of watch batteries and the need to maintain water resistance, it is highly recommended to have the battery replaced by a qualified watch technician or an authorized Invicta service center.

Storage:

When not in use for extended periods, store your watch in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid areas with strong magnetic fields.

7. Troubleshooting

If you encounter any issues with your watch, refer to the following common troubleshooting steps.

Watch Display is Blank or Dim:

- **Possible Cause:** Low or depleted battery.
- **Solution:** Replace the battery. It is recommended to have this done by a professional to maintain water resistance.

Incorrect Time or Date:

- **Possible Cause:** Time/date was not set correctly or was accidentally reset.
- **Solution:** Follow the "Setting Time and Date" instructions in Section 4 to reset the time and date.

Buttons Not Responding:

- **Possible Cause:** Buttons may be stuck, or the watch may be in an unresponsive state.
- **Solution:** Ensure no debris is obstructing the buttons. If the issue persists, a battery replacement might resolve it, or contact customer support.

Water Inside the Watch:

- **Possible Cause:** Water resistance seal compromised, or buttons operated underwater.
- **Solution:** Immediately take the watch to an authorized service center. Do not attempt to open or dry the watch yourself, as this can cause further damage.

8. Specifications

Detailed technical specifications for the Invicta Racing Men's 52mm Electronic Digital Watch, Model 47527.

Feature	Specification
Model Number	47527
Case Size	52mm
Movement Type	Digital
Water Resistance	100 meters (10 ATM)

Band Material	Polyurethane
Clasp Type	Buckle
Crystal Type	Mineral Crystak
Product Dimensions	8.27 x 2.05 x 1.18 inches
Item Weight	2.19 ounces
Manufacturer	Invicta



Figure 8.1: Digital Movement Feature

9. Warranty and Support

Invicta offers warranty and support services for your watch.

Warranty Registration:

To upgrade to a 3-year warranty, please register your watch online.

- **Website:** www.invictawarranty.com
- Follow the instructions on the website to browse your model and enter purchase details to claim your extended warranty.



Figure 9.1: Warranty Information

Online Manual:

An online version of the manual can be accessed via the Invicta service website:

- **Manual Link:** https://www.invictaservice.com/manual/

Customer Support:

For support inquiries, you may contact Invicta Stores Europe:

- **Email:** support@invictastores.eu

© 2025 Invicta Watch Group. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D3QWBSX5

More documents and user manuals: **https://manuals.plus/**