

Invicta 47528

Invicta Racing Men's 52mm Digital Watch User Manual

Model: 47528

INTRODUCTION

This manual provides detailed instructions for the Invicta Racing Men's 52mm Digital Watch. To ensure proper use and longevity of your timepiece, please read this guide thoroughly before operation. Keep this manual for future reference.

SAFETY PRECAUTIONS

WARNING: This product contains a button cell or coin battery. Ingestion can cause severe internal chemical burns in as little as 2 hours, leading to serious injury or death. Keep new and used batteries OUT OF REACH OF CHILDREN. Seek immediate medical attention if a battery is swallowed or inserted inside any part of the body.

CAUTION: Do not dispose of batteries in household trash or incinerate. Non-rechargeable batteries are not to be recharged. Do not force discharge, recharge, disassemble, or heat batteries above the manufacturer's specified temperature rating, as this may result in injury due to venting, leakage, or explosion.

Important instructions are categorized and depicted with symbols:

DANGER: Indicates a hazardous situation which, if not avoided, will result in death or serious injury.

CAUTION: Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

When storing the watch, avoid places with strong magnetism.

INVINCIBLE IN SPIRIT

Discover the **Invicta Racing Collection**, where precision meets passion in every timepiece. Inspired by the adrenaline of motorsport, these watches embody the invincible spirit that drives champions forward. With sleek designs and championship-worthy features, elevate your style and performance both on and off the track with Invicta Racing.



An image displaying critical safety warnings about button cell batteries, including risks of ingestion, proper disposal, and handling instructions. It also shows symbols for danger and caution.

PRODUCT OVERVIEW

The Invicta Racing Men's 52mm Digital Watch features a robust design with a clear digital display, designed for durability and functionality.



A front view of the Invicta Racing Men's 52mm Digital Watch, showcasing its red polyurethane band, black case, and digital display with red accents. The display shows 'MON 10:10:00' and '3 4'.

Key Features

- **Crystal Type:** Mineral Crystak, scratch resistant for ultimate protection and durability.
- **Band:** High-grade silicone for ultimate durability and comfort.
- **Date and Day:** Accurately tracks the date and day with an easily visible and glow-in-the-dark display.
- **Case Size:** 52mm, anatomically designed for an optimal fit on your wrist.
- **Movement:** Digital movement for precise timekeeping with a long and superior battery life.



An image detailing the key features of the Invicta Racing watch, including its Mineral Crystak crystal, high-grade silicone band, date and day display, 52mm case size, and digital movement.

WATCH COMPONENTS

Familiarize yourself with the watch's buttons and their respective functions.



A side view of the Invicta Racing watch, highlighting the four control buttons: 'LIGHT' on the top left, 'MODE' on the bottom left, 'RESET' on the bottom right, and 'START' on the top right. The central button is not labeled.

- **LIGHT Button:** Activates the backlight for improved visibility in low-light conditions.
- **MODE Button:** Cycles through the watch's various operational modes (e.g., Time, Chronograph, Alarm, Timer).
- **START Button:** Used to initiate or pause functions in modes like Chronograph, and to increment values during setting procedures.
- **RESET Button:** Used to reset functions (e.g., Chronograph) and to decrement values or move to the next setting option during setting procedures.

SETUP AND BASIC OPERATION

Initial Power On

The watch is typically pre-set at the factory. If the display is blank or appears dim, ensure the battery is correctly installed or consider a battery replacement if necessary.

Setting Time and Date

1. Press the **MODE** button repeatedly until you reach the Time Setting mode. This is often indicated by flashing digits (e.g., hours or minutes).
2. Use the **START** button to select the digit or field you wish to adjust (e.g., hours, minutes, year, month, day).
3. Use the **RESET** button to change the value of the selected digit or field.

4. Continue pressing **START** to move between fields and **RESET** to adjust values until all desired settings are correct.
5. Press the **MODE** button to exit the setting mode and return to the normal time display.

Using the Backlight

Press the **LIGHT** button (top left) to illuminate the display. The backlight will typically remain active for a few seconds before automatically turning off.

ADVANCED FUNCTIONS

Chronograph (Stopwatch)

1. Press the **MODE** button until "CHRONO" or "STOPWATCH" appears on the display.
2. Press the **START** button to begin timing.
3. Press the **START** button again to pause timing.
4. Press the **RESET** button to clear the stopwatch to zero.
5. To record lap times, press the **RESET** button while the stopwatch is running. The lap time will display briefly, and the stopwatch will continue running in the background.

Alarm Function

1. Press the **MODE** button until "ALARM" appears on the display.
2. Use the **START** button to select the hour or minute digit you wish to set.
3. Use the **RESET** button to adjust the hour or minute value.
4. Press the **MODE** button to confirm the alarm time and exit the setting mode.
5. To activate or deactivate the alarm, typically press the **START** and **RESET** buttons simultaneously while in Alarm mode. Refer to specific watch model instructions if this combination does not work.

Timer Function (if available)

If your watch model includes a countdown timer, navigate to the Timer mode using the **MODE** button. Set the desired countdown time using the **START** and **RESET** buttons, then press **START** to begin the countdown. An alert will sound when the timer reaches zero.

WATER RESISTANCE

This Invicta Racing watch is rated for 100 meters (10 ATM) water resistance. This makes it suitable for recreational swimming and snorkeling. It is not designed for scuba diving. To prevent water ingress, avoid pressing any buttons while the watch is submerged in water.



An image displaying various water resistance icons, indicating suitability for rain, showering, swimming, and a 30-meter depth rating, confirming the watch's water-resistant capabilities.

MAINTENANCE AND CARE

Cleaning

Regularly wipe the watch case and band with a soft, damp cloth to remove dirt and sweat. For more stubborn dirt, a mild soap solution can be used, followed by thorough rinsing with clean water. Ensure the watch is completely dry before storage.

Battery Replacement

When the watch display dims, becomes erratic, or stops functioning, the battery may need replacement. It is highly recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and maintain the watch's water resistance.

Storage

Store your watch in a cool, dry place away from direct sunlight, extreme temperatures, and strong magnetic fields. Prolonged exposure to these conditions can affect the watch's performance and lifespan.

TROUBLESHOOTING

Watch Not Displaying Time

- **Check battery:** The battery may be depleted. Consider professional battery replacement.
- **Reset:** For some digital watches, a soft reset can be performed by pressing all buttons simultaneously for a few seconds. Consult a technician if this does not resolve the issue.

Buttons Not Responding

- **Check for locked mode:** Ensure the watch is not in a specific locked mode that prevents button interaction (refer to specific model features if applicable).
- **Clean buttons:** Dirt or debris might be obstructing button movement. Gently clean around the buttons.

Inaccurate Time

- **Re-set time and date:** Follow the instructions in the "Setting Time and Date" section to ensure the time is correctly set.
- **Battery low:** A weak battery can affect timekeeping accuracy. Consider battery replacement.

SPECIFICATIONS

Feature	Detail
Model Number	47528
Case Size	52mm
Movement Type	Digital
Water Resistance	100 meters (10 ATM)
Band Material	Polyurethane
Clasp Type	Buckle
Product Dimensions	8.27 x 2.05 x 1.18 inches; 2.19 ounces
Manufacturer	Invicta

WARRANTY AND SUPPORT

Invicta provides a standard warranty for its products. You may be eligible to upgrade to an extended 3-year warranty by registering your watch.

For detailed warranty information, terms and conditions, and to register your watch, please visit the official Invicta website or the dedicated warranty registration page.

Online Manuals and Support: For additional support, frequently asked questions, and to download the full manual for your specific model, please visit the Invicta Service Manuals page:





<https://www.invictaservice.com/manual/>





An image of the Invicta watch box lid, showing instructions to 'UPGRADE TO 3 YEARS WARRANTY' with a QR code to 'SCAN FOR MANUAL' and a website address for registration.

Invicta Racing Men's 52mm Digital Watch User Manual - Model 47528. All rights reserved.

Related Documents - 47528

	<p>Invicta 19289 S1 Rally Watch: Installation and User Guide</p> <p>This document provides installation and operational guidance for the Invicta Men's 19289 S1 Rally Analog Display Japanese Quartz Black Watch. It covers essential setup, features, and maintenance to ensure proper use of the timepiece.</p>
	<p>Invicta Watch Warranty and Service Guide</p> <p>Comprehensive guide to Invicta watch warranties, including registration, service procedures, repair pricing, shipping requirements, and policies. Learn how to maintain your Invicta timepiece for optimal performance and longevity.</p>
	<p>Invicta Watch Manual and Warranty Guide</p> <p>Explore the official Invicta watch manual and warranty details. This guide covers your 3-year limited warranty, service center information, watch care, and explanations of various watch features and movements.</p>
	<p>Invicta Watch Manual and Warranty Guide: Care, Service, and Features</p> <p>Official manual and warranty guide for Invicta watches. Learn about the 3-year warranty, service procedures, watch care, water resistance, and types of movements (Quartz, Automatic, Manual Wind).</p>

	<p>Asetek SimSports Direct Drive Wheelbase Manual: Setup, Safety, and Specifications</p> <p>Comprehensive user manual for the Asetek SimSports Direct Drive Wheelbase (Invicta, Forte, La Prima). Covers setup, safety guidelines, compatibility, specifications, software (RaceHub), troubleshooting, and sustainability.</p>
	<p>Assetto Corsa EVO Control Setup Guide</p> <p>A comprehensive guide to setting up your wheelbase, pedals, and steering wheel controls for Assetto Corsa EVO, ensuring optimal calibration and button mapping for a realistic racing simulation experience.</p>

Documents - Invicta – 47528

no relevant documents