



Manuals.plus /

› Zcvtbye /

› Zcvtbye 7-in-1 Hair Dryer Brush User Manual

Zcvtbye B0D3TKWCMC

Zcvtbye 7-in-1 Hair Dryer Brush User Manual

Model: B0D3TKWCMC | Brand: Zcvtbye

INTRODUCTION

Thank you for choosing the Zcvtbye 7-in-1 Hair Dryer Brush. This versatile hair styling tool is designed to provide professional-quality hair care in the comfort of your home. With its innovative design and multiple interchangeable attachments, you can easily dry, curl, straighten, and volumize your hair, saving you time and effort.

This manual provides detailed instructions on how to safely and effectively use, maintain, and troubleshoot your new hair dryer brush. Please read it thoroughly before first use and keep it for future reference.

IMPORTANT SAFETY INFORMATION

To reduce the risk of electric shock, burns, fire, or injury to persons, always follow basic safety precautions when using electrical appliances.

- Always use the ALCI safety plug provided with the device.
- Ensure the device is turned off and unplugged when not in use, especially before cleaning or attaching/detaching accessories.
- Do not use this appliance near water (e.g., in a bathtub, shower, or sink).
- Keep the appliance away from heated surfaces.
- Do not block the air inlets or outlets during operation.
- Do not use if the cord or plug is damaged.
- This appliance is designed for household use only.
- Keep out of reach of children.
- The appliance operates at 110V U.S. voltage standard.

PACKAGE CONTENTS

Your Zcvtbye 7-in-1 Hair Dryer Brush package includes the following items:

- Main Hair Dryer Unit

- Left Curling Barrel (x1)
- Right Curling Barrel (x1)
- Round Volumizing Brush (x1)
- Straightening Comb Brush (x1)
- Concentrator Nozzle (x1)
- Diffuser Nozzle (x1)
- Heat-Resistant Glove (x1)
- User Manual (this document)



Figure 1: All components included in the Zcvtbye 7-in-1 Hair Dryer Brush set.

PRODUCT OVERVIEW

The Zcvtbye 7-in-1 Hair Dryer Brush features a lightweight, ergonomic design for comfortable handling and ease of use. It is equipped with a 110,000 RPM high-speed brushless motor for fast drying and styling.



Figure 2: Labeled components of the main hair dryer unit and its attachment mechanism.

Main Unit Features:

- **Power Button:** Turns the device on/off.
- **Temperature Button:** Cycles through 3 temperature settings (Red: Highest, Blue: Mid-range, Green: Minimum).
- **Fan Speed Button:** Adjusts wind speed.
- **Safe Lock:** Mechanism to secure and release interchangeable heads.
- **Air Inlet:** Located at the bottom of the handle.

3 GEAR ADJUSTMENT



Figure 3: Temperature indicator lights and controls.

Interchangeable Attachments:

- **Hair Dryer Head:** For quick drying.
- **Curling Barrels (Left & Right):** Utilizes air wrapping for automatic curling.
- **Round Volumizing Brush:** For adding volume and shape.
- **Straightening Comb Brush:** For smoothing and straightening hair.
- **Concentrator Nozzle:** For precise drying and styling.
- **Diffuser Nozzle:** For enhancing natural curls and waves.



Figure 4: Overview of the main unit and all seven attachments.

SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Inspect:** Check all parts for any signs of damage. Do not use if damaged.
3. **Attach Head:**
 - Align the desired attachment (e.g., hair dryer head, curling barrel) with the main unit.
 - Push the attachment onto the main unit until it clicks into place.
 - Ensure the safe lock is engaged to secure the attachment. To remove, slide the safe lock to the unlock position and twist the attachment off.
4. **Connect Power:** Plug the ALCI safety plug into a standard 110V electrical outlet.

OPERATING INSTRUCTIONS

Ensure your hair is towel-dried before styling for best results and to minimize heat exposure.

General Operation:

1. **Power On:** Press the power button to turn on the device.
2. **Adjust Temperature:** Press the temperature button to cycle through the settings:
 - Red Indicator: Highest temperature
 - Blue Indicator: Mid-range temperature
 - Green Indicator: Minimum temperature
3. **Adjust Fan Speed:** Press the fan speed button to adjust the airflow intensity.
4. **Power Off:** Press the power button again to turn off the device.

Using Specific Attachments:

1. Hair Dryer Head (Hammer-Shaped Design)

Use this attachment for fast drying of wet hair. It provides a strong, controlled airflow.



Figure 5: Hair Dryer Head in use for quick drying.

- Attach the hair dryer head to the main unit.
- For concentrated airflow, attach the Concentrator Nozzle.
- For gentle drying and curl enhancement, attach the Diffuser Nozzle.
- Hold the dryer about 6-8 inches from your hair and move it continuously.

2. Curling Barrels (Left & Right)

These barrels use the Coanda effect to automatically wrap hair around the barrel, creating curls or waves. Use on damp or dry hair.



Figure 6: Air wrapping technology for curling.

- Select the appropriate barrel (Left for curls towards the face on the left side, Right for curls towards the face on the right side, or vice-versa for outward curls).
- Hold a section of hair (about 1-2 inches wide) near the barrel.
- The air will automatically wrap the hair around the barrel. Hold for 10-15 seconds.
- Use the cool shot function (if available, or switch to minimum temperature) to set the curl before releasing.

3. Round Volumizing Brush

Ideal for adding volume, bounce, and shape to your hair.

- Use on damp hair.
- Section your hair. Place the brush near the roots and brush downwards, rotating slightly to create volume.
- Repeat until desired volume and smoothness are achieved.

4. Straightening Comb Brush

For achieving smooth, straight hair with reduced frizz.

- Use on damp or dry hair.
- Section your hair. Slowly glide the brush through each section from root to tip.
- Ensure hair is fully dry and smooth before moving to the next section.

Any style after shampooing

Party

Casual

Retro

One step to dry hair and get ideal styles

Figure 7: Achieve various styles after shampooing.

MAINTENANCE AND CARE

Proper maintenance ensures the longevity and optimal performance of your Zcvtbye Hair Dryer Brush.

- **Cleaning:**

- Always unplug the appliance and allow it to cool completely before cleaning.
- Wipe the main unit and attachments with a soft, damp cloth. Do not use abrasive cleaners or immerse in water.
- Regularly clean the air inlet filter at the bottom of the handle to prevent dust and hair buildup, which can affect performance.
- Remove any tangled hair from the brush attachments.

- **Storage:**

- Store the appliance and its attachments in a cool, dry place.
- Do not wrap the power cord around the appliance, as this can damage the cord. Use the provided Velcro strap to keep the cord neatly rolled.

- **Heat Protection:** The device features upgraded heat protection. However, always handle attachments with care after use as they may retain heat. Use the included heat-resistant glove when changing hot attachments.



Figure 8: The hair dryer brush helps improve hair health.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not power on.	Not plugged in correctly; ALCI safety plug tripped; Power outlet issue; Device malfunction.	Ensure the plug is fully inserted. Reset the ALCI safety plug (press the "RESET" button). Try a different power outlet. If the issue persists, contact customer support.
Weak airflow or overheating.	Air inlet/outlet blocked by dust or hair.	Unplug the device and allow it to cool. Clean the air inlet filter and ensure air outlets are clear.
Attachments are difficult to attach/detach.	Safe lock not fully disengaged/engaged; Misalignment.	Ensure the safe lock is in the correct position (unlocked for removal, locked for use). Align the attachment properly before pushing/twisting.
Curling barrels not wrapping hair effectively.	Hair is too wet; Section of hair is too large; Incorrect barrel direction.	Ensure hair is damp or dry, not soaking wet. Use smaller sections of hair. Verify you are using the correct Left/Right curling barrel for the desired curl direction.

SPECIFICATIONS

Feature	Detail
Model	B0D3TKWCMC
Brand	Zcvtbye
Power Source	Corded Electric
Wattage	1400 watts
Voltage	110 volts (U.S. standard)
Motor Speed	110,000 RPM (High-speed brushless motor)
Product Dimensions	2.5 x 3 x 11 inches
Weight	3.57 Pounds
Material	Plastic
Country of Origin	China

WARRANTY AND SUPPORT

Zcvtbye values your satisfaction and is dedicated to the quality of its products. While specific warranty details are not provided in this manual, Zcvtbye offers customer support to assist with any questions or concerns.

- **Customer Support:** The support team aims to respond to inquiries within 24 hours.
- **Protection Plans:** Additional protection plans may be available for purchase separately. Please refer to your retailer for details.
- **Legal Disclaimer:** Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

For further assistance, please visit the official Zcvtbye store or contact their customer service directly.

Official Zcvtbye Store: [Visit Store](#)

