

Dreo DR-HHM004

Dreo 6L Top Fill Humidifier User Manual

Model: DR-HHM004

1. IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before operating the humidifier.
- Place the humidifier on a firm, flat, water-resistant surface at least 12 inches (30 cm) away from walls and appliances.
- Do not place the humidifier near heat sources such as stoves, ovens, or radiators.
- Always unplug the humidifier when not in use, before cleaning, or before moving it.
- Do not operate the humidifier with a damaged cord or plug.
- Keep the humidifier out of reach of children and pets.
- Use only clean, cool tap water. Distilled water is recommended to minimize white dust.
- Do not add essential oils directly into the water tank. Use the designated aroma tray.
- Do not block the mist outlet or air inlets.

2. PACKAGE CONTENTS

Verify that all items are present and in good condition:

- Dreo 6L Top Fill Humidifier (1 unit)
- Aroma Pad (1 unit)
- Cleaning Brush (1 unit)
- Cleaning Guide (1 unit)
- User Manual (1 unit)

3. PRODUCT DIAGRAM

Familiarize yourself with the components of your humidifier.



Figure 3.1: Front view of the Drezo 6L Top Fill Humidifier, showing the water tank, control panel, and mist outlet.

- **Mist Outlet:** Where the cool mist is released.
- **Water Tank:** Transparent reservoir for water, 6-liter capacity.
- **Control Panel:** Digital LED display and touch buttons for operation.
- **Base Unit:** Contains the ultrasonic atomizer and electronic components.
- **Aroma Tray:** Located at the back, for essential oils.

4. SETUP

Follow these steps for initial setup:

1. **Unpack:** Remove all packaging materials and place the humidifier on a flat, stable surface.
2. **Fill Water Tank:** Lift the top cover. Pour clean, cool tap water directly into the water tank. Do not exceed the maximum fill line. Distilled water is recommended to reduce mineral buildup and white dust.



Figure 4.1: The top-fill design allows for easy refilling of the water tank.

3. **Replace Cover:** Securely place the top cover back onto the humidifier.
4. **Connect Power:** Plug the power cord into a suitable electrical outlet. The humidifier will enter standby mode.

5. OPERATING INSTRUCTIONS

Understand how to use the various functions of your humidifier.

5.1 Power On/Off

- Press the **Power Button** (🔌) on the control panel to turn the humidifier on or off.

5.2 Mist Output Adjustment

The humidifier offers three mist settings (Low, Medium, High).

- Press the **Mist Level Button** (🌫️) repeatedly to cycle through the mist levels.
- The humidifier can emit mist up to 40 inches high, covering rooms up to 500 sq ft.



Figure 5.1: The humidifier's mist output is designed for effective room coverage.

5.3 Humidity Control (Auto Mode)

The humidifier features an advanced sensor for precise humidity control.

- Press the **Auto Mode Button** () to activate Auto Mode. The humidifier will automatically adjust mist output to maintain your desired humidity level.
- The sensor tracks moisture levels with approximately 5% accuracy.




Figure 5.2: The humidifier's precision humidistat and humidity indicator light.

5.4 Night Light and Quiet Operation

The humidifier operates quietly and includes a night light feature.

- Press the **Night Light Button** (🌙) to turn the ambient night light on or off.
- The humidifier operates at a noise level of 28dB, suitable for bedrooms.



Figure 5.3: The humidifier's quiet operation ensures minimal disturbance during sleep.

5.5 Timer Function

- Press the **Timer Button** (⏰) to set an operating duration from 0 to 12 hours. The humidifier will automatically turn off after the set time.

5.6 Aroma Diffuser

Add essential oils to the aroma tray for a pleasant scent.

- Locate the aroma tray at the back of the humidifier.
- Pull out the tray and add a few drops of essential oil onto the aroma pad.
- Slide the tray back into place.



Figure 5.4: The humidifier features a built-in aroma tray for essential oils.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the life of your humidifier.

6.1 Daily Maintenance

- Empty and rinse the water tank and base unit daily.
- Wipe down all surfaces with a clean, dry cloth.

6.2 Weekly Cleaning

1. **Unplug:** Always unplug the humidifier before cleaning.
2. **Disassemble:** Remove the top cover and water tank.
3. **Clean Water Tank:** Fill the tank with 1 cup (250ml) of white vinegar and let it soak for 30 minutes. Use the provided cleaning brush to scrub away any mineral buildup. Rinse thoroughly with clean water.

4. **Clean Base Unit:** Gently wipe the inside of the base unit with a soft cloth dampened with white vinegar. Pay attention to the ultrasonic atomizer. Do not immerse the base unit in water.
5. **Rinse and Dry:** Rinse all components thoroughly with clean water and allow them to air dry completely before reassembling.

6.3 Cartridge Replacement (Optional)

The humidifier is compatible with optional demineralization and clean mist cartridges (not included) to reduce limescale and ensure healthy humidifying. The ICON light will notify you when a cartridge needs replacing.

7. TROUBLESHOOTING

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
No mist or low mist output	No water in tank; Water tank not properly seated; Mineral buildup on atomizer; Mist outlet blocked.	Refill water tank; Ensure tank is correctly placed; Clean atomizer with brush and vinegar; Clear any obstructions from mist outlet.
White dust around humidifier	Hard water used.	Use distilled or demineralized water. Consider a demineralization cartridge.
Unusual odor	Dirty water or tank; New unit odor.	Clean the water tank and base thoroughly; The odor should dissipate after initial use.
Humidifier leaks	Water tank overfilled; Unit not on a level surface; Components not assembled correctly.	Do not overfill the tank; Place on a flat, stable surface; Reassemble all parts securely.

8. SPECIFICATIONS

Detailed technical information for your Dreo Humidifier.

12.4"

• Height

5.91"

• Width

11.42"

• Depth



Figure 8.1: Dimensions of the Dreo 6L Top Fill Humidifier.

- **Model:** DR-HHM004
- **Power Supply:** 120V ~ 60Hz
- **Rated Power:** 26W
- **Water Tank Capacity:** 6 Liters
- **Max Mist Output:** 300 ml/hour
- **Runtime:** Up to 60 hours (on sleep mode)
- **Noise Level:** ≤ 28 dB
- **Effective Area:** Up to 500 sq ft
- **Dimensions (D x W x H):** 5.91" x 11.42" x 12.4"
- **Net Weight:** 3.87 lbs

9. WARRANTY AND SUPPORT

Dreo provides a warranty for this product in accordance with the terms and conditions specified at the time of purchase. For warranty claims, technical support, or any questions regarding your product, please contact Dreo customer service.

You can typically find contact information on the official Dreo website or through your purchase platform.

Please have your model number (DR-HHM004) and proof of purchase ready when contacting support.