

[Manuals.plus](#) /

› [DMASUN](#) /

› DMASUN 8732B Exercise Bike Instruction Manual

DMASUN 8732B

DMASUN 8732B Exercise Bike Instruction Manual

Model: 8732B

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your DMASUN 8732B Exercise Bike. Please read all instructions carefully before assembly and operation. Retain this manual for future reference.

The DMASUN 8732B is an indoor exercise bike designed for home use, featuring magnetic resistance, a quiet belt drive, and Bluetooth connectivity for app integration.

MORE AND MORE **VERSATILE** EXERCISE BIKE

Achieve Your Goals While Enjoying



Image: The DMASUN 8732B Exercise Bike in a home environment, showcasing its design and suitability for indoor workouts.

2. SAFETY INFORMATION

WARNING: Before starting any exercise program, consult your physician. This is especially important for individuals over the age of 35 or those with pre-existing health conditions.

- Always place the exercise bike on a flat, stable surface.
- Ensure adequate space around the bike for safe operation and movement.
- Keep children and pets away from the equipment during use.
- Wear appropriate athletic footwear and clothing.
- Inspect the bike for loose or damaged parts before each use. Do not use if any components are compromised.
- The maximum user weight capacity for this bike is 350 pounds (158 kg).
- Adjust the seat and handlebars to a comfortable and safe position before beginning your workout.
- Stop exercising immediately if you feel faint, dizzy, or experience pain.

STRONGER SUPPORT FRAME

No Shaking at all

2.0mm thickened pipe



Others

1.0mm not durable



Thickened Pipe

350LBS

Image: The robust frame of the DMASUN 8732B Exercise Bike, illustrating its thickened steel construction for stability and safety during use.

3. PACKAGE CONTENTS

Carefully unpack all components and verify that you have received all parts listed below. If any parts are missing or damaged, contact customer support immediately.

- Main Frame (pre-assembled)
- Front Stabilizer
- Rear Stabilizer
- Seat Post and Seat
- Handlebar Post and Handlebars
- Left and Right Pedals
- Electronic Device Holder
- Water Bottle Holder
- Hardware Kit (bolts, washers, nuts)

- Assembly Tools (wrenches, hex keys)
- User Manual

4. ASSEMBLY AND SETUP

The DMASUN 8732B Exercise Bike is designed for straightforward assembly, with most major components pre-assembled. The complete setup typically takes 15-20 minutes. All necessary tools are included in the package.

1. **Attach Stabilizers:** Secure the front and rear stabilizers to the main frame using the provided bolts and washers. Ensure they are tightened firmly for stability.
2. **Install Pedals:** Identify the Left (L) and Right (R) pedals. The left pedal screws counter-clockwise, and the right pedal screws clockwise. Ensure they are fully tightened to prevent loosening during use.
3. **Mount Seat:** Insert the seat post into the main frame and adjust to your desired height. Secure with the adjustment knob. Attach the seat to the seat post.
4. **Install Handlebars:** Insert the handlebar post into the main frame and attach the handlebars. Adjust the height and secure with the adjustment knob.
5. **Attach Electronic Device Holder and Water Bottle Holder:** Secure these accessories to their designated positions on the bike.

FIT FOR ALL FAMILY MEMBERS

Suitable for Users: 4.8"-6.3"



Image: Illustration of the adjustable seat (horizontal and vertical) and handlebar (vertical) positions, accommodating users from 4.8 to 6.3 feet in height.

Adjusting for Comfort:

- **Seat Height:** Adjust the seat so that your leg has a slight bend at the knee when the pedal is at its lowest point.
- **Seat Forward/Backward:** Adjust the seat horizontally so your knee is directly above the pedal axle when the pedals are horizontal.
- **Handlebar Height:** Adjust the handlebars to a height that allows for a comfortable posture without excessive strain on your back or shoulders.

5. OPERATING INSTRUCTIONS

Starting Your Workout:

1. Ensure the bike is on a stable surface and all adjustments are secure.
2. Step onto the bike, placing your feet securely in the pedal straps.
3. Begin pedaling at a comfortable pace.

Adjusting Resistance:

The DMASUN 8732B features a magnetic resistance system with 100 levels, controlled by the red knob located on the main frame.

- **Increase Resistance:** Turn the knob clockwise to increase the resistance, making pedaling more challenging.
- **Decrease Resistance:** Turn the knob counter-clockwise to decrease the resistance, making pedaling easier.
- **Emergency Stop:** Press down firmly on the red knob to engage the emergency brake and quickly stop the flywheel.



Image: The resistance adjustment knob, indicating a range from easy (warm-up) to hard (muscle training) settings.

Bluetooth and App Connectivity:

The DMASUN 8732B is Bluetooth compatible, allowing connection to various cycling applications for enhanced workout tracking and interactive experiences. Please note that the bike's Bluetooth is designed to connect directly with compatible apps and may not appear in your device's general Bluetooth settings.

1. Ensure your smartphone or tablet's Bluetooth is enabled.
2. Download and open a compatible cycling app (e.g., Kinomap, Zwift).
3. Follow the app's instructions to search for and connect to your DMASUN 8732B Exercise Bike.

4. Place your device on the electronic device holder for easy viewing during your workout.




Image: The exercise bike integrated with a tablet running fitness applications, demonstrating features like real-time data tracking and virtual routes.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your DMASUN 8732B Exercise Bike.

- **Cleaning:** Wipe down the bike with a damp cloth after each use to remove sweat and dust. Avoid abrasive cleaners or solvents.
- **Check Connections:** Periodically inspect all bolts, nuts, and screws to ensure they are tight. Tighten any loose connections.
- **Belt Drive System:** The bike features a maintenance-free belt drive system, which does not require lubrication or tension adjustments.
- **Magnetic Resistance:** The magnetic resistance system is designed for smooth, long-lasting performance and requires no specific maintenance.



YOU CAN TRUST US!



High Quality: ★★★★★
Hundreds of Anti-fall Tests



Comfort Experience: ★★★★★
Quiet and Smooth



We Are Here: ★★★★★
We Prepare Parts for Replacement

Image: Internal components of the exercise bike, illustrating the non-touch magnetic resistance and noise-reducing belt drive for maintenance-free operation.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Bike feels unstable or wobbles.	Loose stabilizer bolts or uneven surface.	Ensure all stabilizer bolts are tightened. Adjust the leveling feet on the stabilizers to compensate for uneven floors.
Pedals feel loose or make noise.	Pedals not fully tightened.	Re-tighten pedals. Remember the left pedal tightens counter-clockwise, and the right pedal tightens clockwise.
Difficulty connecting via Bluetooth.	Attempting to connect through general device Bluetooth settings; incompatible app.	Ensure you are connecting directly through a compatible cycling app (e.g., Kinomap, Zwift). The bike's Bluetooth is not typically discoverable through your phone's general Bluetooth settings.
Unusual noise during operation.	Loose components; foreign object.	Check all visible bolts and connections for tightness. Inspect for any foreign objects near the flywheel or belt. The belt drive is designed to be ultra-quiet.

8. SPECIFICATIONS

Feature	Detail
Model Number	8732B
Brand	DMASUN
Resistance Mechanism	Magnetic

Feature	Detail
Number of Resistance Levels	100
Drive System	Belt
Maximum Weight Recommendation	350 Pounds (158 kg)
Recommended User Height	4.8 - 6.3 Feet (146 - 192 cm)
Product Dimensions (L x W x H)	114D x 50W x 114H Centimetres (approx. 45 x 19.7 x 45 inches)
Item Weight	29 Kilograms (63.93 pounds)
Material	Alloy Steel
Power Source	Battery Powered
Special Features	Bluetooth, App Compatible, Full Filled Solid Flywheel, Ultra Quiet, Heavy Duty, Thickened Steel, Electronic Device Holder, Water Bottle Holder

9. WARRANTY AND SUPPORT

DMASUN is committed to providing high-quality products and excellent customer service. For any questions, concerns, or assistance with your DMASUN 8732B Exercise Bike, please contact our customer support team.

- **Customer Support:** Refer to the contact information provided with your purchase or on the official DMASUN website for prompt assistance.
- **Parts Protection:** DMASUN offers support for replacement parts. Contact customer service for details.
- **Warranty Information:** Specific warranty terms and conditions may vary. Please contact DMASUN customer support for detailed warranty information applicable to your product.

© 2026 DMASUN. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question