

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [JISULIFE](#) /

› JISULIFE FA14 Neck Fan & Life7 Handheld Fan User Manual

JISULIFE FA14 & Life7

JISULIFE FA14 Neck Fan & Life7 Handheld Fan User Manual

Model: FA14 & Life7

1. INTRODUCTION

Thank you for choosing the JISULIFE FA14 Hands-Free Neck Fan and the JISULIFE Life7 3-IN-1 Handheld Fan. This comprehensive user manual provides detailed instructions for the safe and efficient operation, maintenance, and troubleshooting of both devices. Please read this manual thoroughly before use and retain it for future reference.



Image: The JISULIFE FA14 Neck Fan (left) and the JISULIFE Life7 Handheld Fan (right), showcasing both products included in the package.

Package Contents:

- 1 x JISULIFE FA14 4000mAh Neck Fan
- 1 x JISULIFE Life7 Handheld Fan
- Charging Cables (USB-C)

- User Manual

2. JISULIFE FA14 NECK FAN OVERVIEW

Key Features:

- Hands-free and fashionable design for comfortable wear.
- Up to 16 hours of running time on a single charge.
- 3 adjustable fan speeds for personalized cooling.
- Compact and lightweight for portability.
- 360° surrounding air movement for comprehensive cooling without direct hair inhalation.
- Dual-channel air outlet design with double power.




Image: A woman wearing the JISULIFE FA14 Neck Fan around her neck, demonstrating its hands-free design and comfortable fit.



Tradition Neck Fan
uneven cooling, blowing directly



Our Turbon Fan
surroundly cooling, soft wind.

Image: A thermal comparison illustrating the difference between a traditional neck fan (left, uneven cooling) and the JISULIFE FA14 Turbon Fan (right, surround cooling with soft wind).

Setup & Operation:

1. **Wearing the Fan:** Place the neck fan around your neck, ensuring the air outlets are positioned towards your face and neck for optimal airflow.
2. **Power On/Off:** Locate the power button on the device. Press and hold the button for a few seconds to turn the fan on or off.
3. **Adjusting Fan Speed:** Briefly press the power button to cycle through the 3 available fan speeds (Low, Medium, High). The fan will indicate the current speed setting (e.g., via LED indicators or sound).



Three-gear Speed Settings

Dual-channel Air Outlet Design, Double Power

Image: An exploded view of the JISULIFE FA14 Neck Fan, highlighting its internal dual-channel air outlet design and illustrating the three-gear speed settings for double power.

3. JISULIFE LIFE7 HANDHELD FAN OVERVIEW

Key Features:

- Versatile 3-IN-1 design: functions as a handheld, desk, or neck fan.
- Powerful wind with 12 fan blades and an upgraded brushless motor.
- Visual LED display for easy monitoring of speed level and remaining battery.
- Up to 19.5 hours of cooling time (with 5000mAh battery).
- 5 adjustable fan speeds for precise airflow control.



Image: The JISULIFE Life7 Handheld Fan shown in its compact, folded desk fan mode (left) and its extended handheld fan mode (right), demonstrating its versatility.

Super Strong Wind Beat The Heat On Summer Days

12 fan blades & upgraded brushless motor,
stay cool and refreshed wherever you go!



Image: An illustration of the JISULIFE Life7 Handheld Fan's internal components, highlighting its 12 fan blades and upgraded brushless motor for super strong wind.

Setup & Operation:

1. **Handheld Use:** Unfold the fan handle completely for comfortable handheld operation.
2. **Desk Fan Use:** Fold the handle to create a stable base, allowing the fan to stand upright on a flat surface.
3. **Neck Fan Use:** Attach the included lanyard to the designated loop on the fan and wear it around your neck.
4. **Power On/Off:** Press the power button once to turn the fan on. Press and hold to turn it off.
5. **Adjusting Fan Speed:** Briefly press the power button repeatedly to cycle through the 5 available fan speeds. The LED display will show the current speed level.
6. **Checking Battery:** Double-click the power button to check the remaining battery percentage on the LED screen.

Visual LED Screen Easy Monitoring

Checking the speed level and remaining battery at a glance

*Tips: Double-click to check the remaining battery



Image: A close-up of the JISULIFE Life7 Handheld Fan's visual LED screen, showing the battery percentage and speed level, with an inset demonstrating how to double-click to check the remaining battery.

4. CHARGING INSTRUCTIONS (BOTH FANS)

Both the JISULIFE FA14 Neck Fan and Life7 Handheld Fan are equipped with rechargeable batteries. Use the provided USB-C charging cable to charge your devices.

1. Connect the USB-C end of the charging cable to the charging port on the fan.
2. Connect the USB-A end of the cable to a compatible USB power adapter (e.g., wall charger, computer USB port, power bank).
3. The LED indicator on the fan (or LED screen for Life7) will show the charging status. For Life7, the battery percentage will increase.
4. Charging time for the Life7 fan is approximately 4-5 hours for a full charge. The FA14 fan has a similar charging duration.

5. Once fully charged, disconnect the charging cable.



Image: The JISULIFE Life7 Handheld Fan with an overlay indicating its 5000mAh battery capacity, providing up to 19.5 hours of cooling time and requiring 4-5 hours for charging.

5. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your JISULIFE fans.

- **Cleaning:** Use a soft, dry cloth to wipe the exterior of the fans. Do not use harsh chemicals or abrasive materials. For the fan grilles, use a cotton swab or a soft brush to gently remove dust. Do not immerse the fans in water or any other liquid.
- **Storage:** When not in use for extended periods, store the fans in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the battery is partially charged (around 50%) before long-term storage to preserve battery health.
- **Battery Care:** Avoid fully discharging the battery frequently. Recharge the fan when the battery is low to extend its lifespan.

6. TROUBLESHOOTING

If you encounter any issues with your JISULIFE fans, please refer to the following common troubleshooting steps:

- **Fan Not Turning On:**

- Ensure the fan is fully charged. Connect it to a power source and allow it to charge for at least 30 minutes.
- Press and hold the power button for a few seconds to ensure it's not just a brief press.

- **Weak Airflow:**

- Check the fan speed setting and increase it if necessary.
- Ensure the air inlets and outlets are not obstructed by dust or debris. Clean them gently if needed.

- **Fan Not Charging:**

- Verify that the charging cable is securely connected to both the fan and the power adapter.
- Try using a different USB-C cable or power adapter to rule out faulty accessories.
- Ensure the power outlet is functional.

- **Unusual Noise:**

- Check for any foreign objects caught in the fan blades or grilles.
- If the noise persists and is significant, discontinue use and contact customer support.

If the problem persists after trying these steps, please contact JISULIFE customer support for further assistance.

7. SPECIFICATIONS

Feature	JISULIFE FA14 Neck Fan	JISULIFE Life7 Handheld Fan
Model Name	FA14	Life7
Brand	JISULIFE	
Power Source	Battery Powered	
Battery Capacity	4000mAh	5000mAh
Running Time	4-16 Hours	3.5-19.5 Hours
Charging Time	Approx. 4-5 Hours	4-5 Hours
Number of Speeds	3	5
Control Method	Push Button	
Special Features	Hands-free, Lightweight, Portable	Portable, Lightweight, Foldable, LED Display
Form Factor	Wearable	Wearable + Portable + Foldable
Blade Material	Plastic	
Color	Green (FA14), Black (Life7)	

8. WARRANTY & SUPPORT

JISULIFE products are manufactured with high-quality standards. For warranty information and customer support, please refer to the warranty card included in your product packaging or visit the official JISULIFE website. If you have any questions or require assistance, do not hesitate to contact our customer service team.

© 2024 JISULIFE. All rights reserved.